

**DELIXI**

## CDI-E Series Frequency Inverter

### User Manual

Standard:GB/T 12668.2-2002  
GB 12668.3-2003

- Please carefully read this User Manual before installation and operation, and keep it properly for further use.

#### **DELIXI HANGZHOU INVERTER CO., LTD.**

Address: No.8, Economic Plot, Zhuantang Science and  
Technology Park, Zhuantang Street, Xihu District, Hangzhou,  
Zhejiang  
Technical support: 400-188-8155  
Sales Tel: 0086-571-87761308  
Website: <http://www.hz-delixi.com>  
Email: hzdlxsales1@delixi.com ; helen-delixi@163.com

Version: September 2013



## To Users

### —Notices of Onsite Installation and Operation

Respectful User:

Thanks for your Option of E Series Frequency inverter manufactured by Delixi (Hangzhou) Inverter Co., Ltd. In order that you can better use the product, please pay attention to the following:

1. After frequency inverter is installed and commissioned, fasten the components, especially connecting bolt of the line, which shall cause fire accident due to heat at the connection if not fastened.
2. Design of installation on the site should be reasonable to maintain excellent ventilation.
3. In and out lines of the frequency inverter should not be connected reversely. Otherwise, it shall lead to frequency inverter explosion.
4. Starting and stopping the motor directly by power-on and power-off the main circuit of the frequency inverter shall cause frequent jumping faults to the frequency inverter.
5. When selecting frequency inverter type, configure the frequency inverter as per actual load power (load working current). When there is heavy load, type selection can be magnified by 1 to 2 shifts. Smaller type shall cause overcurrent or overload jumping faults to the frequency inverter.
6. Protection level of the frequency inverter is IP20, that is, it can prevent a foreign matter with a diameter of 12.5mm or greater from completely entering, without waterproof function.
7. Frequency inverter if stored for more than half a year should be powered with a voltage regulator to increase voltage gradually. Otherwise, there is danger of electric shock and explosion.
8. If line connecting the frequency inverter to the motor exceeds 50m, it is required to add AC output inductor. Otherwise, the frequency inverter and the motor are in danger of damage

In order that you can use the product safely for a long time, you need to carefully inspect the product, regularly power off it to clean and maintain. For any trouble in process of inspection, please notify us by phone or mail. Our service hotline is 0571-85243785. We shall send professional to your site as per your trouble to assist you in solving the trouble and ensure the product is operated safely and reliably.

## Content

Foreword	IV
Chapter 1 Safety Operation and Notices	1
1.1 Examination and Acceptance	1
1.2 Precautions for safe operation	2
Chapter 2 Product Information	4
2.1 Nameplate data and naming rule	4
2.2 Technical Specifications	5
2.3 Product List	8
2.4 Appearance and installation size	9
2.5 Routine maintenance	12
Chapter 3 Installation and Connection of Frequency inverter	15
3.1 Option of the Site and Space for Installation	15
3.2 Wiring of the Peripherals and Optional parts	17
3.3 Wiring of the main circuit	18
3.3.1 Wiring diagram for the main circuit and precautions	18
3.3.2 Precautions for wiring the input side of the main circuit	20
3.3.3 Precautions for wiring the output side of the main circuit	21
3.3.4 Wiring and Supporting Peripherals for Main Circuits with Reference to the Table below	23
3.4 Connection of control circuit	24
3.4.1 Arrangement and connection of controlling circuit terminals	24
3.4.2 Function of control circuit terminal	26
3.4.3 Wiring Instruction for Control Circuit	27
3.5 Grounding	31
Chapter 4 Keyboard Operation and Running	32
4.1 Option of operating mode	32
4.2 Test run and inspection	32
4.2.1 Precautions and inspection before test run	32
4.2.2 Test run	32
4.2.3 Operating inspection	33
4.3 Operating method of keyboard	33
4.3.1 Keys on keyboard and their functions	33
4.3.2 Data Monitoring Mode	38
4.3.3 Use of Multi- Function Key JOG	38
4.3.4 Parameter check and set methods (using digital keyboard)	39
4.4 Function Code Display Mode	40
Chapter 5 Tables of Function Parameters	41
5.1 P0 Group - Basic Function	42

## Content

---

5.2 Group P1 - Motor Control Parameter	45
5.3 Group P2 - Input/Output Terminal Function	47
5.4 Group P3 - Programmable Function	54
5.5 Group P4 - Pid Control And Communication Control	60
5.6 Group P5 - Keyboard Display	62
5.7 Group P6 - Fault Display and Protection	65
5.8 Group P7 - User Function Customization	69
5.9 Group P8 - Manufacturer Function	70
5.10 Group P9 - Monitoring Parameter	70
Chapter 6 Description of Parameters	72
6.1 Group 0 - Basic Function	72
6.2 Group P1 - Motor Control Parameter	88
6.3 Group P2 - Input/Output Terminal Function	100
6.4 Group P3 - Programmable Function	122
6.5 Group P4 - Pid Control And Communication Control	133
6.6 Group P5 - Keyboard Display	140
6.7 Group P6 - Fault Display and Protection Control	146
6.8 Group P7 - User Function Customization	153
6.9 Group P8 - Manufacturer Function	154
6.10 Group P9 - Monitoring Parameter	156
Chapter 7 Common Function and Application Case	158
7.1 Common Function	158
7.1.1 Start and Stop Control	158
7.1.2 Start and Stop Mode	160
7.1.3 Acceleration and Deceleration Mode	163
7.1.4 Jogging Function	163
7.1.5 Running Frequency Control	163
7.1.6 Multi-speed Function	165
7.1.7 Simple PLC	165
7.1.8 Timing Function	166
7.1.9 Fixed-length Function	167
7.1.10 Counting Function	168
7.1.11 Distance Control Function	169
7.1.12 Simple Internal Relay Programmable Function	170
7.1.13 Internal Timer Function	173
7.1.14 Internal Operation Module Function	174
7.1.15 PID FUNCTION	176
7.1.16 Wobulating Function	177

---

7.1.17 Analog Input/Output Use	178
7.1.18 Digital Input/Output Use	179
7.1.19 Communication of Upper Computer	181
7.1.20 Parameter Identification	182
7.2 Application Case	184
7.2.1 PID control for Water Supply at Permanent Pressure	184
7.2.2 Application for Injection Molding Machine Energy-saving Transformation	187
7.2.3 PID Constant Speed and Fixed-length Control Function	190
7.2.4 PID Constant Speed and Fixed-distance Control Function	194
7.2.5 Double Pumps Switching Function	198
Chapter 8 E Series Frequency inverter RS-485 Communication	200
Chapter 9 Fault Handling	208
9.1 Frequency inverter Fault and Exclusion Measure	208
9.2 Motor Fault and Exclusion Measure	212
Appendix 1 Regular Maintenance and Inspection Methods	213
Appendix 2 Guideline for Option of Optional parts	215
A2.1 Alternative Current Reactor (ACL)	215
A2.2 DC reactor	215
A2.3 Radio noise filter	216
A2.4 Remote Operation Keyboard	216
A2.5 Energy Consumption Brake Unit and Brake Resistance	216
Appendix 3 Multi-function I/O Expansion Card	219
Appendix 4 Expansion Card of Encoder	221
Appendix 5 Expansion Card of RS485 Communication	223
Appendix 6 Expansion Card of Injection Molding Machine	224

## Foreword

Thank you for choosing E Series Frequency inverter manufactured by Delixi (Hangzhou) Inverter Co., Ltd. It includes CDI-E100 Series and CDI-E180 Series, in which CDI-E180 Series can also connect the expansion card externally.

Before using it, please read this manual carefully so as to guarantee correct operation. Erroneous operation might result in malfunction, faults or shortened life span of the equipment, or even personal injury. Therefore, users are advised to read carefully this manual and abide by it during operation. The manual is a standard attached document. Please keep it for maintenance and repair in the future.

Aside from operation instructions, this manual also presents some wiring diagrams for your reference. If you have any difficulty or special demands for using the frequency inverter, please contact our offices or distributors. You may also contact the customer service centre of our head office for our quality service. The manual noted that its content might change without further notice.

Please confirm following content during unpackaging:

1. If the product is damaged during process of transportation, if parts are damaged and dropped, or if main body is bruised.
2. If rated value marked on nameplate is consistent with your order requirement, or if there are ordered Unit, acceptance certificate, operation manual and guarantee shed in package.

The Company strictly complies with quality system during production and packaging, for any inspection miss, please contact our Company or supplier for settlement.



### Warning

People should not reprint, transmit, and use the manual or content relating to it without written permission of the Company, who will assume legal responsibility for damage caused in violation of the item.

## Chapter 1 Safety Operation and Notices

Please read the manual carefully before install, operate, maintain or check E Series Frequency inverter.

To protect yourself, the equipment, and the property from any possible harm, please do read this chapter before using our E Series Frequency inverters. Precautions relevant to operation safety are categorized as “Warning” and “attention” .



**Warning**

: Potentially dangerous condition, which maybe cause severe body injuries or dead if relevant requirement is ignored.



**Attention**

: Potentially dangerous condition, which maybe cause middle, light injuries or device damage if relevant requirement is ignored, it also applies to unsafe operation.



### 1.1 Examination and Acceptance

Items to be examined are as follows:


Items	Note
1. Does the model conform to your order?	Check the Model indicated on the nameplate on one side of the frequency inverter.
2. Is there any damage to the components?	Survey the external appearance of the frequency inverter and make sure that no damage has occurred during transportation
3. Are the components properly fastened?	Remove the front cover and examine all visible components with appropriate tools.
4. Do you have the user's manual, the quality certificate and the warranty claims form?	Check for the user's manual, the quality certificate and the warranty claims form

If any of the above items is problematic, please contact us or our distributors.

**1.2 Precautions for safe operation:**

 <b>Warning</b>	1. Installation and maintenance should be performed by professional only.	
	2. Verify that rated voltage of the frequency inverter should conform with voltage level of AC power supply. Otherwise it shall cause hurt to human body or fire accident.	
	3. Do not make supply power of AC loop connect with outputting terminal U, V and W. The connection will damage converser, thus guarantee card should be nonserviceable.	
	4. Only connect it to input power supply after the panel is well installed. Do not remove the external lid when it is powered; otherwise it may cause electric shock.	
	5. Forbid touching high voltage terminal inside the frequency inverter when it is powered on; otherwise, there is danger of electric shock.	
	6. Because there is an amount of capacitance stored electric energy inside the frequency inverter, maintenance should be implemented at least 10 minutes after the power is off. At this time, charging indicator should be off thoroughly or positive or negative bus voltage is confirmed to be below 36V; otherwise there is danger of electric shock.	
	7. Do not turn on or off line and connector when the circuit is powered on; otherwise it can cause hurt to human body.	
	8. Electric elements can be easily damaged by static electricity. Do not touch electric elements.	
	 <b>ESD</b> <b>Electro Static Discharge (ESD)</b>	9. This frequency inverter should not undergo voltage withstand test, which might result in damages to the semiconductor devices in it.
		10. Before switching on the power supply, please put the cover board in position. Otherwise, electric shock or explosion might occur.
		11. Never confuse the input terminals. Otherwise, explosion or damage to the property might occur.
		12. For frequency inverter of which storage period exceeds half year, please increase the input voltage gradually by using regulator, to prevent from electric shock and explosion.
		13. Do not operate the frequency inverter with wet hand; otherwise, there is danger of electric shock.
		14. All parts should be replaced by professional only. It is strictly prohibitive to remain stub or metal object in machine, to prevent from fire.
		15. After replaced control board, please perform relevant parameter setting before operation to prevent from damage of materials.





 <p><b>Attention</b></p>	<p>1. If the motor is used for the first time or has been in leisure for a long time, remember to check its insulation first. It is advisable to use a 500V megger. Make sure the insulation resistance should not be less than 5 MΩ.</p>
	<p>2. If you need to operate the frequency inverter at frequencies beyond 50Hz, please consider the support capability of the mechanical devices.</p>
	<p>3. The output at certain frequencies might encounter the resonance points of load devices. This can be avoided by resetting the jump frequency parameter of the frequency inverter.</p>
	<p>4. Do not use three-phase frequency inverters as two-phase ones. Otherwise, fault or damage might occur.</p>
	<p>5. In regions at an altitude of more than 1000 meters, the heat dissipation capability of the frequency inverter might be compromised because of the thin air. Therefore, de-rated operation will be necessary. In such cases, please contact us for technical advice.</p>
	<p>6. The standard matched motor is a four-pole squirrel-cage asynchronous machine. In case of discrepancy, please choose appropriate frequency inverters in accordance with the rated current of the motor.</p>
	<p>7. Do not start or stop the frequency inverter with contactors. Otherwise, damage might occur to the equipment.</p>
	<p>8. Do not modify factory parameter of frequency inverter without authorization, or damage might be caused.</p>

## Chapter 2 Product Information

### 2.1 Nameplate data and naming rule

Nameplate data: for example CDI-E180G055T4BHL:



## 2.2 Technical Specifications

Item		Specification		
Control	Control mode	V/F Control Open-loop Vector Control (SVC) Closed-loop Vector Control (VC) (Invalid CDI-E100 Series)		
	Frequency Resolution	Digital: 0.02% Analog: 0.1%		
	V/F curve	Linear, square root, random V/F		
	Overload Capability	G Model: 60s for 150% of the rated current; 3s for 180% of the rated current; P Model: 60s for 120% of the rated current; 3s for 150% of the rated current;		
	Start Torque	G Model: 0.5Hz/150% (SVC); 0Hz/180% (VC) P Model: 0.5Hz/100%		
	Speed Regulation Range	1:100 (SVC)	1:1000 (VC)	
	Stable Speed Accuracy	±0.5% (SVC)	±0.02% (VC)	
	Torque Control Accuracy	±5% (VC)		
	Torque Compensation	Manual torque compensation (0.1%~30.0%), automatic torque compensation		
	Running	Operating mode	Keyboard, terminal, RS485 communication	
Frequency Source		14 kinds of main frequency sources and 14 kinds of auxiliary sources. Adopt various combination modes to switch. Diversification to Each Frequency Source Input Mode: keyboard potentiometer, external analog, digital reference, impulse reference, Multiplex Directive, simple PLC, communication, arithmetic results, etc.		
Torque Source		14 kinds of Torque Sources, including digital reference, external analog, impulse reference, Multiplex Directive, communication, arithmetic results, etc.		
Acceleration and Deceleration Time		Four groups of straight lines (select the terminal to switch through acceleration and deceleration time), S Curve 1 and S Curve 2		
Emergency stop		Interrupt output of frequency inverter.		
Multiplex Speed		16 speed is allowable to set at most and use various combination of multiplex directive terminal to switch		
Simple PLC Function		Continuously, run 16-phase speed and independently set acceleration and deceleration time and running time		
Jogging Control		Independently set Jogging frequency and jogging acceleration and deceleration time, additionally, set the unit under running state and confirm whether the jogging is preferential		
Rotating Speed Tracking		Frequency inverter starts operation by tracking the load speed		
Fixed-length and Fixed-distance Control		Realize fixed-length and fixed-distance control function through Impulse Input		
Counting Control		Realize counting function through Impulse Input		
Wobblating Function		Apply for textile winding equipment		
Built-in PID		Realize process control closed loop system		

Item		Specification	
Running	AVR Function	When the grid voltage fluctuates, ensure constant output	
	DC Braking	Realize fast and stable shut-down	
	Slip Compensation	Compensate the speed deviation caused by the increase of load	
	Hopping Frequency	Prevent resonance from occurring with load	
	Sagged Function	Balance the load of multiple motors with same load	
	Timing Control	Be able to realize automatic shutdown of the frequency inverter when reaching given time	
	Built-in Virtual Delay Relay	Realize simple logic Programming to multi-functional output terminal function and digital input terminal signal, the logic results can not only be equivalent to digital input terminal function, but can be output through multi-functional terminal output	
	Built-in Timer	Built in 2 timers and acquire the timing input signal to realize timing signal output. Use alone or in combination	
	Operation Module Built-in Operation Module	One built-in 4-way Operation Module to realize simple addition, subtraction, multiplication and division, size judgment and integral operation	
	Input Terminal	E100	6-way Digital Input Terminal (DI1~DI6), in which DI6 can access to high-speed Impulse Input 2-way Analog Input Terminal (VF1、VF2), which can be used as voltage (0V~10V) or current (0/4mA~20mA) input. It can be used as Digital Input Terminal through reference.
		E180	6-way Digital Input Terminal (DI1~DI6), in which DI6 can access to high-speed Impulse Input. Through external I/O expansion card, it can be expanded to 4-way(DI7~DI10). 2-way Analog Input Terminal (VF1、VF2), which can be used as voltage (0V~10V) or current (0/4mA~20mA) input. It can be used as Digital Input Terminal through setting
	Output Terminal	E100	2-way Analog Input Terminal (FM1、FM2), which can not only be used as output voltage (0V~10V),but output current (0/4mA~20mA) . 1-way open collector output (YO), DC 48V 50Ma below 1-way Impulse output (FMP), Frequency Range between 0.01kHz~100.00kHz 2-way Relay Output (T1、T2), DC 30V/1A below and AC 250V/3A below <b>Note: YO and FMP are common YO/FMP terminal, but only one can be used at the same time.</b>
		E180	2-way Analog Input Terminal (FM1、FM2), which can not only be used as output voltage (0V~10V),but output current (0/4mA~20mA) . 1-way open collector output (YO), DC 48V 50Ma below. Additional 2-way open collector output (YO1, YO2) can be added through external I/O expansion card. 1-way Impulse output (FMP), Frequency Range between 0.01kHz~100.00kHz 2-way Relay Output (T1、T2), DC 30V/1A below and AC 250V/3A below <b>Note: YO and FMP are common YO/FMP terminal, but only one can be used at the same time.</b>

Item		Specification
Communication	E100	The control panel is directly equipped with RS485 Communication Interface and supports Standard MODBUS Protocol
	E180	The control panel is not equipped with built-in RS485 Communication Interface, so external communication expansion card is required. It supports Standard MODBUS Protocol (External Connection of E180-485 Expansion Card)
Encoder	E100	Be able to connect the encoder through Terminal DI5 & DI6 on control panel such an encoder connection method can realize simple closed-loop control through PID Control and used for occasions without high requirements to control accuracy.
	E180	The control panel is not equipped with encoder interface, so external encoder expansion card is required. It supports ABZ Incremental Encoder, UVW Incremental Encoder and Rotary Transformer. This encoder connection method can realize high-performance closed-loop vector control and be used for occasions with high requirements to control accuracy.
Type of Model	E100	Only be equipped with asynchronous motor
	E180	Not only be equipped with asynchronous motor, but synchronous motor
Display	Running information	Given frequency, output current, output voltage, bus voltage, input signal, feedback value, module temperature, output frequency, motor synchronous speed, etc. Through >> Key, display 32 loops at most
	Error information	Save the historical information of 3 faults under running state of fault protection. Every piece of fault information includes frequency, current, bus voltage and input/output terminal status when fault happens.
Protection	Frequency inverter protection	Overcurrent, overvoltage, module fault protection, undervoltage, overload, external fault protection, EEPROM fault protection, ground protection, default phase, etc.
	Frequency inverter alarm	Locked protection, overload alarm
	Instantaneous power-off	Lower than 15 ms: Continuous operation Bigger than 15 ms: Automatic restart is allowable
Environment	Ambient temperature	-10°C~40°C
	Storage temperature	-20°C~65°C
	Ambient humidity	90 % RH in max .(no dewing)
	Height/vibration	Below 1,000 m, below 5.9m/sec <sup>2</sup> (=0.6g)
	Application position	No corrosive gas, inflammable gas, oil mist, dust and others
Cooling	Air-blast cooling	

## 2.3 Product List

### (1) CDI-E100 Series

Frequency inverter type	Rated capacity (KVA)	Rated input current (A)	Rated output current (A)	Matchable Motor(kW)
<b>S2 (Single-phase 220V, 50/60Hz) (Built-in Brake Unit)</b>				
CDI-E100G0R4S2B	0.8	5.0	2.0	0.4
CDI-E100G0R75S2B	1.5	9	4.0	0.75
CDI-E100G1R5S2B	2.7	15.7	7.0	1.5
CDI-E100G2R2S2B	3.8	27	10.0	2.2
<b>T2 (Three-phase 220V, 50/60Hz) (Built-in Brake Unit)</b>				
CDI-E100G0R4T2B	0.8	2.3	2.0	0.4
CDI-E100G0R75T2B	1.5	6	4.0	0.75
CDI-E100G1R5T2B	2.7	8.8	7.0	1.5
CDI-E100G2R2T2B	3.8	12.5	10.0	2.2
<b>T4 (Three-phase 380V, 50/60Hz) (Built-in Brake Unit)</b>				
CDI-E100G0R75T4B	1.5	3.4	2.3	0.75
CDI-E100G1R5T4B	3.0	5.0	3.7	1.5
CDI-E100G2R2T4B	4.0	5.8	5.1	2.2
CDI-E100G3R7T4B	5.9	10.5	8.8	3.7

### (2) CDI-E180 Series

Frequency inverter type	Rated capacity (KVA)	Rated input current (A)	Rated output current (A)	Matchable Motor (kW)
CDI-E180G0R75T4B	1.5	3.4	2.3	0.75
CDI-E180G1R5T4B	3	5.0	3.7	1.5
CDI-E180G2R2T4B	4	5.8	5.0	2.2
CDI-E180G3R7/P5R5T4B	5.9/8.5	10.5/15.5	8.8/13	3.7/5.5
CDI-E180G5R5MT4B	8.5	15.5	13	5.5
CDI-E180G5R5/P7R5T4B	8.5/11	15.5/20.5	13/17	5.5/7.5
CDI-E180G7R5/P011T4B	11/17	20.5/26	17/25	7.5/11
CDI-E180G011MT4B	17	26	25	11
CDI-E180G011/P015T4BL	17/21	26/35	25/32	11/15
CDI-E180G015/P018.5T4BL	21/24	35/38.5	32/37	15/18.5
CDI-E180G018.5/P022T4	24/30	38.5/46.5	37/45	18.5/22
CDI-E180G022/P030T4	30/40	46.5/62	45/60	22/30
CDI-E180G030/P037T4	40/50	62/76	60/75	30/37
CDI-E180G037/P045T4	50/60	76/92	75/90	37/45
CDI-E180G045/P055T4	60/72	92/113	90/110	45/55
CDI-E180G055/P075T4	72/100	113/157	110/152	55/75
CDI-E180G075/P093T4	100/116	157/180	152/176	75/93




#### Order explanation:

During order, please enter type, specification of the product, and provide parameter, load type, or other information relating to the motor as much as possible. For any special requirement, please consult with technology department of the Company.



## 2.4 Appearance and installation size

## (1) CDI-E100 Series

Model 1



Main Circuit Wiring Diagram







Note:



1. Plastic shell
2. The ordering of the terminals is subject to material object

Model	W	W1	H	H1	D	D1	$\phi$ d
CDI-E100G0R4S2B							
CDI-E100G0R7S2B							
CDI-E100G1R5S2B							
CDI-E100G0R4T2B							
CDI-E100G0R75T2B	109	99	167	153	161	148	5
CDI-E100G1R5T2B							
CDI-E100G0R75T4B							
CDI-E100G1R5T4B							
CDI-E100G2R2T4B							

Model 2



Main Circuit Wiring Diagram



Note:


1. Plastic shell
2. The ordering of the terminals is subject to material object

Model	W	W1	H	H1	D	D1	$\phi$ d
CDI-E100G2R2S2B							
CDI-E100G2R2T2B	135	122	167	153	171	158	5
CDI-E100G3R7T4B							

## Chapter 2 Product Information


### (2) CDI-E180 Series

#### Model 1




Model	W	W1	H	H1	H2	D	D1	c d
CDI-E180G0R75T4B	134	120	184	170	154	148	85	5
CDI-E180G1R5T4B								
CDI-E180G2R2T4B								

#### Main Circuit Wiring Diagram




- Note:  
 1 Model 1 adopts plastic shell  
 2 The ordering of the terminals is subject to material object

#### Model 2




Model	W	W1	H	H1	H2	D	D1	c d
CDI-E180G3R7/P5R5T4B	159	145	299	215	199	160	95	5
CDI-E180G5R5MT4B								

#### Main Circuit Wiring Diagram




- Note:  
 1 Model 2 adopts plastic shell  
 2 The ordering of the terminals is subject to material object

#### Model 3



Model	W	W1	H	H1	H2	D	D1	g d
CDI-E180G5R5/P7R5T4B	204	188	304	288	270	194	142	5
CDI-E180G7R5/P011T4B								
CDI-E180G011MT4B								


#### Main Circuit Wiring Diagram



- Note:  
 Model 3 adopts plastic shell  
 The ordering of the terminals is subject to material object



Model 4




Main Circuit Wiring Diagram

Model	W	W1	H	H1	D	D1	D2	$\phi d$
CDI-E180G011/P015T4								
CDI-E180G015/P018.5T4	250	180	420	405	197	187	126	7
CDI-E180G018.5/P022T4								
CDI-E180G022/P030T4	300	190	460	445	219	209	148	7
CDI-E180G030/P037T4								
CDI-E180G037/P045T4	355	290	530	515	267	257	174	9
CDI-E180G045/P055T4								
CDI-E180G055/P075T4	390	290	600	585	267	257	174	9
CDI-E180G075/P093T4								


11 ~ 30kW



37 ~ 45kW



55 ~ 75kW



Note: the ordering of the terminals is subject to material object

## 2.5 Routine maintenance

### (1) Routine maintenance

Under influence of temperature, humidity, dust and vibration, internal elements of frequency inverter should be aged, which should cause potential fault, or decrease service life of frequency inverter. Therefore, it is significant to perform routine maintenance and regular inspection with the frequency inverter.

Routine maintenance item:

- A. If running sound of motor is abnormal.
- B. If vibration is created during operation of motor.
- C. If installing condition of frequency inverter is changed.
- D. If radiating fan of frequency inverter works normally.
- E. If frequency inverter is in state of overheat.

Daily cleanness:

- A. Keep cleanness of frequency inverter.
- B. Remove dust from surface of frequency inverter effectively, to prevent frequency inverter from incursion of dust, or metal dust.
- C. Remove oil sludge form radiating fan of frequency inverter effectively.

### (2) Regular inspection

Please inspect corner pockets of frequency inverter regularly.

Regular inspection item:

- A. Inspect air flue, and clean it regularly.
- B. Inspect if screw is loosened.
- C. Inspect if frequency inverter is corrosive.
- D. Inspect if there is arc on surface connecting terminal.
- E. Insulated test of major loop

Note: Please disconnect major loop and frequency inverter while testing insulation resistance by using megohmmeter (500V DC megohmmeter). Do not measure insulation of control loop with megohmmeter. And high voltage test is needless (finished in ex works).

### (3) Replacement of wearing parts

Wearing parts of frequency inverter includes cooling fan, filter ELCC, of which service life depend on operating environment and maintenance condition closely.

User could confirm replacement period according to the operating time.

A. Cooling fan

Potential damage reason: Shaft abrasion and vane aging.

Critical standard: If there is crack on vane of fan, or if abnormal sound occurs during starting.

B. Filter ELCC

Potential damage reason: Bad input power, higher ambient temperature, frequent load switch, or aging of electrolyte.

Critical standard: If liquid leaks, if safety valve bulged out, measure of static capacitance, and measure of insulated resistance.

(4) Storage of frequency inverter

After purchased the device, please pay attention to following points while storing it:

A. Please store it in original package as much as possible.

B. Long term storage should cause aging of ELCC, please electrify it for 5 hours above twice a year during storing, in mode of raising voltage to rated voltage slowly via transformer.

(5) Guarantee of frequency inverter

Maintenance free is limited to the frequency inverter only.

The Company will provide guaranteed repair for fault or damage occurs during normal application. For device sold, shall be repaired in China in reference to the bar code date, and for exported device (not included China) shall be repaired at purchase site if the date is within six months after delivery.

For products manufactured by the Company, we will provide paid service for life anytime, or anywhere applied it.

All sale, product, and agent units of the Company should provide products with after sale service, of which service terms include:

A. Provide “Class III” inspection service at site of the unit. (Include fault elimination)

B. Refer to after sell service contract concluded between the Company and agents.

C. Request for compensated after-sell service from the agent of the Company (without reference to guaranteed repair).

Our Company should take responsibility of guaranteed repair, guaranteed exchange, and guaranteed return for quality and accident responsibility relating to the product, but user could affect insurance for further responsibility compensation guarantee from insurance agent.

**Guarantee term of the product should be effective in 18 months after Bar code date.**

For fault caused in following reason, user could obtain compensated maintenance only even guarantee term is effective:

A. Problem caused in incorrect operation (based on user's manual) or repair, modification without authorization.

B. Problem caused in violation of critical requirement.

C. Damage caused in undeserved transportation after purchased.

D. Aging or fault caused in bad environment.

E. Damage caused in earthquake, fire, disaster, lightning strike, abnormal voltage or other natural disaster and incidental disaster.

F. Damage occurs in transportation. (Note: transportation mode should be appointed by user of themselves, the Company should assist agent to conduct transfer of goods).

G. Brand, trade mark, SN, nameplate marked by manufacturer is damaged or unjustifiable.

H. Failure to pay off fund according to purchase contract.

I. Failure to describe actual conditions relating to installation, distribution, operation, maintenance, or other condition to the Company.

The Company should carry out responsibility of “Three guarantee” abovementioned only after received the returned goods, and confirmed responsibility attribution.


Should it involve an unpaid or untimely settlement due to the buyer, the ownership hereof still belongs to the supplier. In addition, the latter will assume no liability her einabove, and the buyer shall have no disagreement.

All relevant service fees shall be calculated in accordance with the identical standards of the factory. In the event that an agreement or a contract exist, its priority shall be performed.

## Chapter 3 Installation and Connection of Frequency inverter

### 3.1 Option of the Site and Space for Installation


Option of installing position:

 <p><b>Warning</b></p>	1. Prevent from sunniness; Don't use in the open air directly.
	2. Don't use in the corrosive gas and liquid environment.
	3. Don't use in the oil fog and splash environment.
	4. Don't use in the salt spray environment.
	5. Don't use in the moist and rain environment.
	6. Please equip the unit with filters device if metal dust or fiber wadding existing in air.
	7. Do not use the unit in mechanical shock or vibration condition.
	8. It is necessary to adopt cooling measure if ambient temperature is higher than 40°C.
	9. It is recommended to use the unit in temperature range of -10°C~+40°C because fault maybe occur in overcool or overheat condition.
	10. Keep the unit away from power supply noise, high-power application, such as electric welder should impact application of the unit.
	11. Emissive material should impact application of the unit.
	12. Keep the unit away from combustible material, attenuant and solvent.


For ensuring perfect performance and long-term service life, please comply with the abovementioned advices while installing E Series Frequency inverter to prevent the unit from damage.

Option of the installation space:

For vertical installation of E Series Frequency inverters, adequate cooling room should be left, so as to ensure effective cooling




Installation space of E frequency inverters

 <b>Attention</b>	1. The spaces to be left above / below and on the two sides of the frequency inverter are required both for the model with open bracket (IP00) and that with closed bracket (IP20)
	2. Permissible temperature at the air inlet: -10°C ~ +40°C
	3. Adequate cooling spaces should be reserved both above and below the frequency inverter, so as to facilitate gas admission and emission.
	4. Do not drop anything into the air passage during installation. Otherwise the fan might be damaged.
	5. Mount filtering devices at the air inlet in cases of floating fiber or cotton or heavy dust.

### 3.2 Wiring of the Peripherals and Optional parts


The standard method to connect E Series Peripheral Equipment and Optional Components is as below:  
Three-phase AC Power Supply




### 3.3 Wiring of the main circuit


#### 3.3.1 Wiring diagram for the main circuit and precautions

This section describes connection of main circuit of E frequency inverters.


 Dangerous	1. Do not make power supply of AC main loop connect with output terminal U, V, and W.
	2. Please connect unit only after shut down the power supply.
	3. Verify if the crating voltage of frequency inverter is same as the input voltage of it.
	4. Do not perform withstand test with frequency inverter.
	5. Fasten terminal screw with appointed fasten torque.

 Attention	1. Please check if grounding terminal is grounded before connect main loop. (Refer to 3.5)
	2. Terminal sequence should base on actual object.
	3. Rated input voltage: 220V (AC single phase), frequency: 50/60Hz 220V (AC three-phase), frequency: 50/60Hz 380V (AC three-phase), frequency: 50/60Hz
	4. Allowable fluctuation voltage: +10% (fluctuation $\pm 15\%$ ) Allowable fluctuation Frequency: $\pm 2\%$


Wiring Diagram of Main Circuit of Model 1 of Machine Type E100



Wiring Diagram of Main Circuit of Model 2 of Machine Type E100




Wiring Diagram of Main Circuit of Model 1 of Machine Type E180






Wiring Diagram of Main Circuit of Model 2 of Machine Type E180




Wiring Diagram of Main Circuit of Model 3 of Machine Type E180




Wiring Diagram of Main Circuit of Model 4 of Machine Type E180


11kW~30kW



37kW~45kW



55kW~75KW



**3.3.2 Precautions for wiring the input side of the main circuit**

1. Installation for Circuit Breaker (MCCB)

To protect the circuit, a MCCB or fuse should be installed between the power supply of the AC main circuit and the input terminals of R, S, or T.

2. Residual current circuit breaker

When selecting residual current circuit breakers for connection to input terminals of R, S, or T, the one that is not affected by Highest Frequency is preferred, in order to avoid any possible misoperation.

For example: NV series (manufactured in 1988 or later on) by Mitsubishi Electric;  
EG and SG series (manufactured in 1984 or later on) by Fuji Electric;  
CDM1 Series Circuit Breakers made by DELIXI Group Co., Ltd.

3. Installation of the electromagnetic contactor (MC)

The frequency inverter may be used even if no electromagnetic contactor is installed on the power supply side.

Electromagnetic contactor can take the place of MCCB for the sequence break of the main circuit. However, when the primary side is switched off, the regeneration brake will not function and the motor will stop running.

When the primary side is closed/open, the electromagnetic contactor can cause loads to start/stop, but frequent close/open will lead to frequency inverter fault. Therefore, while using the brake resistor unit, you can always realize sequential control through the trip contact of the overload relay when the electromagnetic contactor is switched off.

4. Phase sequence connection of the terminals

The phase lines of the input power supply can be connected to any one of the terminals R, S or T on the terminal board, regardless of phase sequences.

5. AC reactor

When an frequency inverter is connected to a large-capacity power transformer (600KVA or beyond), or when a phase lead capacitor (power factor compensator) is connected or disconnected, the peak current through the input power circuit will be so strong that it will damage the rectifier-frequency inverter. Installing a DC reactor (optional) in the frequency inverter or adding an AC reactor (optional) at the input end can effectively improve the power factors at the power supply side.

6. Surge absorber


If a perceptual load (such as electromagnetic contactor, relay, solenoid valve, electromagnetic coil, electromagnetic brake and so on) is connected in the adjacent area, a surge suppressor should also be used while operating the frequency inverter.

7. Setting of a noise filter at the power supply side

Noise filter can be used to reduce the high-frequency noise flowing from the frequency inverter to the power supply.

Wiring example 1: please use noise filters exclusively designed for frequency inverters.

It is set as follows:



### 3.3.3 Precautions for wiring the output side of the main circuit

#### 1. Connection of the output terminals to the load

Connect the output terminals U, V and W respectively to the leading-out wires U, V and W of the motor. Use the forward rotation instruction for verification. (CCW: observed from the load side, the motor runs counterclockwise). If the motor is not running in the right direction, switch any two of terminals U, V and W.

2. It is absolutely forbidden to connect input power supply to terminals U, V or W!!!

3. Short circuit or grounding of the output circuit is forbidden.

Refrain from directly touching the output circuit or bringing the output wire in contact with the chassis of the frequency inverter. Otherwise, electric shock or grounding fault might occur. In addition, always guard the output wire against short circuit.

4. It is forbidden to connect phase-lead capacitors or LC/RC noise filters

Do not connect phase-lead capacitor or LC/RC noise filters to the output circuit.

5. Refrain from installing magnetic starter

If a magnetic starter or electromagnetic contactor is connected to the output circuit, the frequency inverter will trigger the operation of over-current protection circuit because of the surge current resultant from the frequency inverter's connection to the load. The magnetic contactor should not operate until the frequency inverter has stopped outputting.

6. Installation of thermal overload relay

The frequency inverter consists of an electronic overload protection mechanism. Admittedly, a thermal over-load relay should be installed when a frequency inverter is used in driving several motors or when a multi-pole motor is used. In addition, the rated current of the thermal over-load relay should be the same as the current indicated on the nameplate of the motor.

7. Setting of noise filter on the output side

Mounting a special-purpose noise filter on the output side of the frequency inverter can reduce radio noise and interfering noise.

Interfering noise: because of electromagnetic interference, the noise might affect the signal line and result in the misoperation of the controller.

Radio noise: the noise can be produced from radio transmitters because of high-frequency waves emitted from the frequency inverter or cables.

8. Countermeasures for interfering noise

Aside from using noise filters, threading all the connecting wires into a ground metal pipe can also restrain interfering noise generated at the output terminal. If we put signal lines over 30cm away, the effect of interfering noise will be abated.

9. Countermeasures for radio noise

Aside from input and output wires, the frequency inverter itself also emits noise. It will help to handle the problem if we install noise filters at the input and output sides of the frequency inverter or apply shielded lines to the iron case of the frequency inverter. It is also very important to make sure that the connecting wire between the frequency inverter and the motor should be as short as possible.

10. The wire distance between the frequency inverter and the motor

If the total wire length between the frequency inverter and the motor is too long or the carrier frequency of the frequency inverter (primary IGBT switch frequency) is rather high, the harmonic leakage current from the cables will exert negative influence on the frequency inverter and other external devices.

If connection line between the frequency inverter and the motor is too long, carrier frequency of the frequency inverter can be reduced as below. The carrier frequency can be given by Function Code P1.0.22.

Table of wire distance between the frequency inverter and the motor

Wire distance between the frequency inverter and the motor	Carrier frequency(P)
Not exceeding 50m	10KHz or lower
Not exceeding 100m	5KHz or lower
Beyond 100m	3KHz or lower

Output reactors should be installed when the wire distance exceeds 50 meters. Otherwise, the motor may get burnt down.

External thermal relays may cause unnecessary operations due to the Highest Frequency current from the distributed capacitance in the output lines of the frequency inverter. As far as Low-capacity models of the 400V Series (especially those below 7.5KW) is concerned, the ratio of their current to the rated current of the frequency inverter will become bigger if their wiring lines are rather long (over 50m). As a result, external thermal relays may carry out unnecessary operations.

### 3.3.4 Wiring and Supporting Peripherals for Main Circuits

#### (1) CDI-E100 Series

Type of Frequency inverter	Main Circuit Wire Gage(mm <sup>2</sup> )	Control Circuit Wire Gage(mm <sup>2</sup> )	Use-free air breaker MCCB(A)	Electromagnetic contactorMC(A)
S2 (Single Phase 220V)				
CDI-E100G0R4S2B	2.5	1.0	16	10
CDI-E100G0R75S2B	2.5	1.0	16	10
CDI-E100G1R5S2B	2.5	1.0	20	16
CDI-E100G2R2S2B	4.0	1.0	32	20
T2 (Three-phase 220V)				
CDI-E100G0R4T2B	2.5	1.0	10	10
CDI-E100G0R75T2B	2.5	1.0	16	10
CDI-E100G1R5T2B	2.5	1.0	16	10
CDI-E100G2R2T2B	4.0	1.0	25	16
T4 (Three-phase 380V)				
CDI-E100G0R75T4B	2.5	1.0	10	10
CDI-E100G1R5T4B	2.5	1.0	16	10
CDI-E100G2R2T4B	2.5	1.0	16	10
CDI-E100G3R7T4B	4.0	1.0	25	16


#### (2) CDI-E180 Series

Type of Frequency inverter	Main Circuit Wire Gage(mm <sup>2</sup> )	Control Circuit Wire Gage(mm <sup>2</sup> )	Use-free air breaker MCCB(A)	Electromagnetic contactorMC(A)
CDI-E180G0R75T4B	2.5	1.0	10	10
CDI-E180G1R5T4B	2.5	1.0	16	10
CDI-E180G2R2T4B	2.5	1.0	16	10
CDI-E180G3R7/P5R5T4B	4.0	1.0	25	16
CDI-E180G5R5MT4B	4.0	1.0	32	25
CDI-E180G5R5/P7R5T4B	4.0	1.0	32	25
CDI-E180G7R5/P011T4B	4.0	1.0	40	32
CDI-E180G011MT4B	4.0	1.0	63	40
CDI-E180G011/P015T4BL	4.0	1.0	63	40
CDI-E180G015/P018.5T4BL	6.0	1.0	63	40
CDI-E180G018.5/P022T4	6.0	1.5	100	63
CDI-E180G022/P030T4	10	1.5	100	63
CDI-E180G030/P037T4	16	1.5	125	100
CDI-E180G037/P045T4	16	1.5	160	100
CDI-E180G045/P055T4	25	1.5	200	125
CDI-E180G055/P075T4	35	1.5	200	125
CDI-E180G075/P093T4	50	1.5	250	160


### 3.4 Connection of control circuit

#### 3.4.1 Arrangement and connection of controlling circuit terminals


(1) CDI-E100 Series




The wiring diagrams of E 100 Main Circuit and Control Circuit are as below:



(2)CDI-E180 Series



The wiring diagrams of E 180 Main Circuit and Control Circuit are as below:



### 3.4.2 Function of control circuit terminal:

Following sheet summarize function of control circuit terminal, which is connected according to function respectively.

Category	Terminal	Name of Terminal	Description of Function
Digital Input Terminal	OP	External Power Input	Take P24V short circuit by factory default. When adopting external power to drive the digital input terminal, disconnect OP and P24V and connect with external power
	DI1-OP	Digital Input 1	Terminals are equipped on E Series Control Panel, in which Terminal DI16 can be used for high-speed Impulse Input and has maximum input frequency of 100kHz.
	DI2-OP	Digital Input 2	
	DI3-OP	Digital Input 3	
	DI4-OP	Digital Input 4	Specific function refers to the description for use of Function Code P2.0.00~P2.0.05.
	DI5-OP	Digital Input 5	
	DI6-OP	Digital Input 6	Refer to the terminal on CDI-E180 Series expansion Card I/O. CDI-E180 Series hasn't had these terminals. Specific function refers to the description for use of Function Code P2.0.06 and P2.0.09
	DI7-COM	Digital Input 7	
	DI8-COM	Digital Input 8	
	DI9-COM	Digital Input 9	
	DI10-COM	Digital Input 10	
Multi-functional Output Terminal	T1A	Multi-functional Relay 1 Output	TA-TB is normally open TA-TC is normally closed Drive Capability: AC250V 3A below DC30V 3A below
	T1B		
	T1C		
	T2A	Multi-functional Relay 2 Output	Refer to the terminal on CDI-E180 Series expansion Card I/O. CDI-E180 Series hasn't had these terminals. Specific function refers to the description for use of Function Code P2.0.28 and P2.0.31 Drive Capability: DC48V 50mA below
	T2B		
	T2C		
	YO1	Multi-functional Open Collector Output 1	
	CME	Collector Output 1	
YO2	Multi-functional Open Collector Output 2		
CME	Collector Output 2		
Analog Input Signal	10V	10V Power Output	Provide DC 10V supply voltage externally and generally adopt it as working power for external potentiometer Drive Capability: 50mA below
	GND		
	VF1-GND	Analog Input Terminal 1	Be used for receiving external analog signal input, 0V~10V voltage signal or 0/4mA~20mA current signal
	VF2-GND	Analog Input Terminal 2	



Category	Terminal	Name of Terminal	Description of Function
Analog Output Signal	FM1-GND	Analog Output Terminal 1	Output 0~10V voltage or 4~20mA current
	FM2-GND	Analog Output Terminal 2	
Dual-purpose Terminal	YO/FMP	Multi-functional Open Collector Output and Common Terminal for Impulse Output	When P2.1.20=1, this terminal is used as multi-functional collector output YO Drive Capability: DC48V 50mA below
	COM	Common Terminal for Impulse Output	When P2.1.20=0, this terminal is used as Impulse Output FMP Impulse frequency: 0.01kHz~100.00kHz
24V Power	COM	24V Power Output	Provide DC 24V supply voltage externally and generally adopt it digital input terminal or as working power for external low-voltage equipments Drive Capability: Max. Output Current 300mA
	P24		
Communication Terminal	SG+	Positive Signal Terminal of RS485 Communication	CDI-E100 Series directly has two terminals on control panel. CDI-E180 Series is not equipped with two terminals on control panel, but on expansion card of communication
	SG-	Negative Signal Terminal of RS485 Communication	

### 3.4.3 Wiring Instruction for Control Circuit

To avoid interfere, please distribute control loop apart from main loop and heavy current loop (relay contact, 220V program loop), the Shielded Twisted Cable or Shielded Twisted Pair should be used in wiring the control circuit; the shielding sheath should be connected to terminal PE of the frequency inverter and the wire distance should be less than 50 meters to prevent misoperation from interference.

#### 1. Description for Circuit Wiring of Analog Input Terminal

J5-1 controls VF1 channel to select voltage/current signal input. When current signal input is selected, switch of J5 is at I side; when voltage signal input is selected, switch of J5 is at U side.

J5-2 controls VF2 channel to select voltage/current signal input. When current signal input is selected, switch of J5 is at I side; when voltage signal input is selected, switch of J5 is at U side.

#### 2. Description for Circuit Wiring of Analog Output Terminal


J6 controls FM1 channel to select voltage/current signal input. When current signal input is selected, switch of J6 is at I side; when voltage signal input is selected, switch of J6 is at U side.

J7 controls Fm1 channel to select voltage/current signal input. When current signal input is selected, switch of J7 is at I side; when voltage signal input is selected, switch of J7 is at U side.



3. Description for Circuit Wiring of Digital Input Terminal

Shielded Cable or Shielded Twisted Pair should try to be used for digital input to avoid interference from external type and the wire distance should be less than 50 meters.



The wiring diagram on digital input circuit control panel is as below




● Dry Contact Common Cathode Wiring Method




● Dry Contact Common Anode Wiring Method



● Leaking-type Wiring Method




● Source-type Wiring Method



4. Description for Circuit Wiring of Multi-functional Output Terminal


● AC Circuit

The AC Circuit can only be used for multi-functional relay output terminal. If it is to drive inductive load (e.g. electromagnetic relay and contactor), the surge voltage absorber shall be installed, e.g. RC Absorber (the leakage current shall be less than the holding current of controlled contactor or relay), as shown in the figure below:



● DC Circuit


The DC Circuit can not only be used for multi-functional open collector output terminal (attention for wiring polarity), but for multi-functional relay output terminal. If it is to drive DC Magnetic Circuit, the fly-wheel diode (attention for polarity), as shown in the figure below:



5. Description for Circuit Wiring of Impulse Output Terminal

When the function code is P2.1.20=0, Terminal YO/FMP is used as Impulse Output Terminal. The default circuit is passive impulse output. If the active impulse is required to output, the users need to match the power (internal power or external power of the frequency inverter available) and pull-up resistor.

**Note: allowable limit of internal circuit: DC48V 50mA below**



### 3.5 Grounding

1. Grounding resistance value:

200V level: 100  $\Omega$  or value below it

400V level: 10  $\Omega$  or value below it


660V level: 5  $\Omega$  or value below it

2. Prevent E frequency inverter, welding machine, motor or other huge current electrical equipment from earthing. Ensure all earthing lines and wires of huge current electrical equipment are separately laid inside the pipe.


3. Please use approved grounding wire of which length should be as shorter as possible.

4. When several E frequency inverters are used in parallel, please ground the device as shown by Figure (a), instead of Figure (c) which may form a loop.


5. Grounding of frequency inverters and motor can be connected as per Figure (d).




(a) Correct




(b) Incorrect



(c) Non-recommended



(d) Correct



(e) Non-recommended

6. Connection inspection:

Please perform following items if installation and connection are completed.

A If connection is correct.

B If stub or screw remains in device.

C If screws are fastened firmly.

D If bare conductor on terminal contacts with other terminals.



## Chapter 4 Keyboard Operation and Running

### 4.1 Option of operating mode

E Series Frequency inverters provide 3 control modes, including keyboard operation, terminal operation and communication operation. The user can select relative control mode as per onsite circumstances and working requirements. See 7.1 for specific selection.

### 4.2 Test run and inspection

#### 4.2.1 Precautions and inspection before test run

 <p><b>Dangerous</b></p>	<ol style="list-style-type: none"> <li>1. Input power can be connected only after front lid is installed. Do not remove external lid when powered, otherwise it may lead to electric shock.</li> <li>2. Do not get close to the frequency inverter or the load when selecting re-start because it may suddenly restart after being stopped just a moment ago. (Even though the frequency inverter can restart, its mechanical system can safeguard individual safety) otherwise it may cause hurt to human body.</li> <li>3. Because function setting can defunction the stop button, it is required to install an independent emergency button; otherwise it may cause hurt to human body.</li> </ol>
 <p><b>Attention</b></p>	<ol style="list-style-type: none"> <li>1. Do not touch the radiator or resistor because its temperature is very high; otherwise it may lead to burn.</li> <li>2. Because low speed can be easily changed to high speed, it is required to confirm safe working scope of the motor and mechanical equipment before operation; otherwise it may cause hurt to human body and damage to equipment.</li> <li>3. If necessary, separately install a contracting brake; otherwise it may cause hurt to human body.</li> <li>4. Do not change connection during operation; otherwise the equipment or frequency inverter may be damaged.</li> </ol>

For ensuring operation safety, please relieve mechanical connector before first operation to separate motor from mechanical equipment and prevent from dangerous. Please perform following inspection before test run:

- A. If connection between lead and terminal is correct.
- B. If lead thrum cause short circuit.
- C. If screw terminal is fastened firmly.
- D. If motor is installed firmly.

#### 4.2.2 Test run

After preparation, connect to power supply and inspect if frequency frequency inverter works normally.

After connected to power supply, indicator of number keyboard is luminous.

Please cut off power supply immediately if any problem abovementioned occurs.

4.2.3 Operating inspection


Please verify following items during operation:

- A. If motor rotates smoothly.
- B. If rotation direction of motor is correct.
- C. If abnormal vibration or noise occurs accompanying with operation of motor.
- D. If acceleration and deceleration are smooth.
- E. If current match with load value.
- F. If LED state indicator and number keyboard displays correctly.


4.3 Operating method of keyboard.

4.3.1 Keys on keyboard and their functions

(1) CDI-E100 Series LED Keyboard



Installation Dimension of Operation Keyboard




Function of Indicator

NO	Name	Description of Function
1	FWD	When rotating in the forward direction, the indicator lights up, but when rotating in the backward direction, the indicator doesn't work,
2	TUNE	When the parameter identification function operates, the light flickers. The light is normally on at torque control mode
3	RUN	The frequency inverter lights up under running state
4	V	Indicate voltage value
5	A	Indicate current value
6	Hz	Indicate frequency
7	V-%-A	Indicate percentage
8	A-RPM-Hz	Indicate rotating speed

## Chapter 4 Keyboard Operation and Running

### (2) CDI-E180 Series 0.75~7.5kW LED Keyboard



### Installation Dimension of Operation Keyboard




### Function of Indicator

NO	Name	Description of Function
1	FWD	When rotating in the forward direction, the indicator lights up, but when rotating in the backward direction, the indicator doesn't work,
2	RUN	The frequency inverter lights up under running state
3	V	Indicate voltage value
4	A	Indicate current value
5	Hz	Indicate frequency
6	V-%-A	Indicate percentage
7	A-RPM-Hz	Indicate rotating speed



(3) CDI-E180 Series11~75kW LED Keyboard



Installation Dimension of Operation Keyboard





Function of Indicator

NO	Name	Description of Function
1	FWD	When rotating in the forward direction, the indicator lights up, but when rotating in the backward direction, the indicator doesn't work.
2	TUNE	When the parameter identification function operates, the light flickers. The light is normally on at torque control mode
3	RUN	The frequency inverter lights up under running state
4	V	Indicate voltage value
5	A	Indicate current value
6	Hz	Indicate frequency
7	V-%-A	Indicate percentage
8	A-RPM-Hz	Indicate rotating speed



Chapter 4 Keyboard Operation and Running

(4) CDI-E180 Series 0.75~7.5Kw LCD Keyboard



Statement: the maximum four lines can be simultaneously displayed under surveillance screen. Specific displayed contents are determined by Function Code P5.0.06~P5.0.13 (Details refer to the Description for P5.0.06~P5.0.13). Press Key >> and select one line. If the parameter attribute is writable, press Key ENTER and directly enter into parameter modification page, after completing the modification, press ENTER and return to surveillance screen.


(5) CDI-E180 Series 11~75kW LCD Keyboard




4.3.2 Data Monitoring Mode

1. Cycle Monitor Mode

In Monitor Mode, press Key >> per time and change one display item to check current state information of the frequency inverter



In shut-down state, the contents for 16 downtimes can be cycled at most, and specific contents shown in the cycle shall be determined by Function Code P5.0.05 (Details refer to the Description for P5.0.05)



Under running state, the contents for 32 running surveillance can be cycled at most, and specific contents shown in the cycle shall be determined by Function Code P5.0.02 and P5.0.03 (Details refer to the Description for P5.0.02 and P5.0.03).

2. Fault/Alarm Monitor Mode

A. Under state of running monitor, the unit should display information relating to fault and warning if fault and alarm occurs.

B. Reset fault by press STOP/RESET if fault disappears.


C. Please cut off power supply and reset the unit if serious fault occurs.

D. Keyboard should display fault code continuously until fault is eliminated (refer to Chapter IX).

4.3.3 Use of Multi- Function Key JOG

Upon the demand of the users, set Function Code P5.0.00 and realize the definition of the users to Function Key JOG, and the Key JOG can choose dead and forward rotation jogging running, reverse rotation jogging running and switch between forward rotation and reverse rotation, in which forward rotation jogging running and reverse rotation jogging running are valid under any running control, and the switch between forward rotation and reverse rotation is only valid under keyboard control mode.

## 4.3.4 Parameter check and set methods (using digital keyboard)



Example: the following is an example to change value of P0.0.10 from 010.0 to 016.1:

1	50.00	Display set frequency 50.00Hz; Press MODE key to enter parameter setting mode
2	P0.0.00	Parameter P0.0.00 appears, at the same time the pointer points to the last digital bit "0" and twinkles. Press >> to select parameter code to set; press $\Delta$ , $\nabla$ key to move the data bit.
3	P0.0.10	Press $\Delta$ , $\nabla$ , >> to change value displayed to P0.0.10, the ENTER
4	010.0	Check whether factory-set, value of the parameter is 010.0; at the same time the pointer points to the last digital bit "0".
5	016.0	Press $\Delta$ , $\nabla$ , >> to change value displayed to 016.1, then ENTER.
6	P0.0.12	Data storage writes in 016.0; the parameter displays that the acceleration time is changed to 016.0 from 010.0, and then it is to return to the parameter that displays P0.0.12 at this time
7	P0.0.10	If directly press MODE instead of ENTER is step 5, the keyboard shall return to display P0.0.10, and the data changed is not stored. Acccheyt'u8\654546y41ion times is still 010.0.
8	50.00	Then press MODE again return to running under monitoring mode to display the set frequency.

**Note:** And it is impossible to modify data under following conditions.

1. It is impossible to adjust parameter during operation of frequency inverter. (Refer to function sheet)
2. Start parameter protection in P5.0.18 (parameter write-in protection)

### 4.4 Function Code Display Mode

E Series Frequency inverter provides three kinds of Function Code Display Modes: Basic Mode, User Mode and Verification Mode.

● Basic Mode (P0.0.01=0)

In basic mode, the function code has the prefix with 'P'. At this time, the Function Code P5.0.17 determines what parameters of the function codes are specifically displayed. Its ones, tens, hundreds and thousands respectively correspond to each function code group. Refer to the following table for explanation of specific meaning.

Function Code	Setting scope		Explanation
Function parameter displays the Option of P5.0.17	Ones	0	Only display basic parameter group
		1	Display the menus at all levels
	Tens	0	Don't display Group P7
		1	Display Group P7
	Hundreds	0	Don't display verification group
		1	Display verification group
	Thousands	0	Don't display code group
		1	Display code group

● User Mode (P0.0.01=1)

Only display customization parameters of user function and use Function Code of Group P7.0 to determine what parameters of the function codes are specifically displayed by the frequency inverter (Refer to the description for Group P7.0 for more details). In user mode, the function code has the prefix with 'U'.

Function Code	Setting scope		Explanation
Function parameter displays the Option of Group P7.0	P7.0.00	U0.0.01	When the parameter of function code is set, it is deemed that this function code is selected as user customization function code. 30 parameters of function codes can be selected and set at most.
	.....	U0.0.00~UX.X.XX (except for group P7 and P8)	
	P7.0.29	U0.0.00~UX.X.XX (except for group P7 and P8)	

● Verification Mode (P0.0.01=2)

Only display the modified parameters (in case of any difference of function code between reference value and factory value, it is deemed that the parameters are changed), the function code has the prefix with 'C' in verification mode.

## Chapter 5 Tables of Function Parameters

### Description for Tables of Function Parameters

1. Function parameters of E Series Frequency inverter are divided into 9 groups as per the functions. Each group includes several sub-groups and each sub-group includes several function codes, which can be set with different values.

2. P××.×× in function sheet or other section of the manual denotes “××” function code of sort “××”; For example, “P0.0.01” denotes function code 01 of sort P0.0.

3. Content explanation of function sheet:

Column 1 “Function Code”: serial number of function code parameter; Column 2 “Function Name”: full name of function parameter; Column 3 “Setting Scope”: scope of valid set value of function parameters; Column 4 “Factory Setting”: original set value of function parameters when delivered out of the factory; Column 5 “Change Limit”: change property of function parameters (that is, whether change and changing conditions are allowed); Column 6 “Reference Page”: page referred to of function parameters.

Modification limit of parameter is explained as below:

“☆”: Denote that the set value of the parameter is modifiable under stop or running state of the frequency inverter;

“★”: Denote that the set value of the parameter is not modifiable under running state of the frequency inverter;

“●”: Denote that the value of the parameter is actual testing value and not modifiable;

“○”: Denote that this parameter is allowed to be modified only at P5.0.18=2

“▲”: Denote that this function in E Series is invalid and not allowed to be modified

### Explanation:

Please read the manual carefully while modifying parameter of frequency inverter. And contact our Company for any problem occurs during operation. No data submits to customer modification, violation of it maybe causes serious fault, or significant property loss, of which consequences should be born by User!

## 5.1 P0 Group - Basic Function

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P0.0 Basic Group					
P0.0.00	Type of Frequency inverter	1. G Type (constant torque load type) 2. P Type (fans and water pump load type)	Machine type	○	72
P0.0.01	Display Mode0: Basic Mode (Prefix with 'P')	1: User Mode (Prefix with 'U') 2: Verification Mode (Prefix with 'C')	0	☆	
P0.0.02	Control Mode0: V/F Control	1: Open-loop Vector Control (SVC) 2: Closed-loop Vector Control (Invalid E100)	1	★	73
P0.0.03	Option of operation control mode	0: Keyboard Control 1: Terminal Control 2: Communication Control	0	☆	
P0.0.04	Option of A Frequency Source	0: Keyboard Reference (No Power-off Memory) 1: Keyboard Reference (Power-off Memory) 2: Keyboard Potentiometer Reference 3: External Terminal VF1 Reference 4: External Terminal Vf2 Reference 5: PULS Reference (DI6) 6: Multiplex Directive Reference 7: Simple PLC Reference 8: PID Control Reference 9: Communication Reference 10: Operation Result 1 11: Operation Result 2 12: Operation Result 3 13: Operation Result 4	02	★	74
P0.0.05	Keyboard Frequency Reference	000.00~ maximum frequency	050.00	☆	75
P0.0.06	Running Direction	0: Default Direction 1: Negation of Direction	0	☆	76
P0.0.07	Maximum frequency	050.00Hz~320.00Hz	050.00	★	
P0.0.08	Upper frequency	Lower frequency ~ highest frequency	050.00	★	
P0.0.09	Lower frequency	000.00~ Upper frequency	000.00	☆	
P0.0.10	Lower frequency operation mode	0: Running at lower limit frequency 1: Stop 2: Zero-speed Running	0	☆	77
P0.0.11	Acceleration Time	0000.0~6500.0s	Machine type	☆	
P0.0.12	Deceleration Time	0000.0~6500.0s	Machine type	☆	
P0.0.13	Type of Motor	0: Common Motor 1: Variable Frequency Motor 2: Synchronous Motor (Valid E100)	0	★	78



Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P0.0.14	Motor rated power	0000.1kW~1000.0kW	Machine type	★	78
P0.0.15	Motor rated frequency	000.01Hz ~Highest frequency	050.00	★	
P0.0.16	Motor rated voltage	0001V~2000V	Machine type	★	
P0.0.17	Motor rated current	000.01~655.35	Machine type	★	
P0.0.18	Motor Rated Rotating Speed	00001~65535	Machine type	★	
P0.0.19	Stator resistance	00.001~65.535	Machine type	★	
P0.0.20	Rotor resistance	00.001~65.535	Machine type	★	
P0.0.21	Motor leakage inductance	000.01~655.35	Machine type	★	
P0.0.22	Motor common inductance	0000.1~6553.5	Machine type	★	
P0.0.23	Non-load current	000.01~Motor rated current	Machine type	★	
P0.0.24	Parameter Identification Control	00: No action 01: Static identification 02: Complete identification 11: Synchronous machine on-load identification (Invalid E100) 12: Synchronous machine non-load identification (Invalid E100)	00	★	
<b>P0.1 Group: Expansion Group</b>					
P0.1.00	Option of Frequency Source	0: Frequency Source A 1: Frequency Source B 2: Frequency Source A+B 3: Frequency Source A-B 4: Max. Value of A & B 5: Min. Value of A & B 6: Standby Frequency Source 1 7: Standby Frequency Source 2 8: Switch of Terminal among the above 8 kinds	0	☆	79
P0.1.01	Option of Frequency Source B	0: Keyboard Reference (No Power-off Memory) 1: Keyboard Reference (Power-off Memory) 2: Keyboard Potentiometer Reference 3: External Terminal VF1 Reference 4: External Terminal VF2 Reference 5: PULS Reference (DI6) 6: Multiplex Directive Reference 7: Simple PLC Reference 8: PID Control Reference 9: Communication Reference 10: Operation Result 1 11: Operation Result 2 12: Operation Result 3 13: Operation Result 4	00	★	80
P0.1.02	Adjustment Volume of: Frequency Source B at superposition	000%~150%	100%	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P0.1.03	Upper Limit Frequency Source	0: Digital Reference (P0.0.08) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Reference 4: PULS Reference (DI6) 5: Communication Reference 6: Operation Result 1 7: Operation Result 2 8: Operation Result 3 9: Operation Result 4	0	★	81
P0.1.04	Upper Limit Frequency Offset	000.00~Highest Frequency	000.00	☆	82
P0.1.05	Keyboard Reference frequency Shut-down Memory Selection	0: No Memory 1: Memory	0	☆	
P0.1.06	Keyboard Reference frequency Action Benchmark at running	0: Running Frequency 1: Reference frequency	0	★	
P0.1.07	Benchmark frequency of accelerating and Deceleration time	0: Highest Frequency 1: Reference frequency 2: 100Hz	0	★	83
P0.1.08	Jogging running frequency	000.00~Highest Frequency	002.00	☆	
P0.1.09	Jogging Acceleration time	0000.0s~6500.0s	0020.0	☆	
P0.1.10J	Jogging Deceleration time	0000.0s~6500.0s	0020.0	☆	
P0.1.11	Acceleration time 2	0000.0s~6500.0s	Machine type	☆	
P0.1.12	Deceleration time 2	0000.0s~6500.0s	Machine type	☆	
P0.1.13	Acceleration time 3	0000.0s~6500.0s	Machine type	☆	
P0.1.14	Deceleration time 3	0000.0s~6500.0s	Machine type	☆	
P0.1.15	Acceleration time 4	0000.0s~6500.0s	Machine type	☆	
P0.1.16	Deceleration time 4	0000.0s~6500.0s	Machine type	☆	
P0.1.17	Frequency Switch Point between Acceleration time 1 and Acceleration time 2	000.00Hz~Highest Frequency	000.00	☆	84
P0.1.18	Frequency Switch Point between Deceleration time 1 and Deceleration time 2	000.00Hz~Highest Frequency	000.00	☆	
P0.1.19	Acceleration and Deceleration Mode	0: Straight Line 1: Curve S 1 2: Curve S 2	0	★	
P0.1.20	Percentage of Starting Phase of Curve S	000.0%~100.0%	030.0	★	85
P0.1.21	Percentage of Ending Phase of Curve S	000.0%~100.0%	030.0	★	
P0.1.22	Hopping Frequency 1	000.00Hz~Highest Frequency	000.00	☆	
P0.1.23	Hopping Frequency 2	000.00Hz~Highest Frequency	000.00	☆	
P0.1.24	Hopping Frequency scope	000.00Hz~Highest Frequency	000.00	☆	
P0.1.25	Jogging Priority	0: Invalid 1: Valid	0	☆	86

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P0.1.26	Type of Encoder	0: ABZ Incremental Encoder 1: UVW Incremental Encoder (Invalid E100) 2: Rotary Transformer (Invalid E100) 3~9: Reservation 10: Distance Control (Open Collector)	00	★	86
P0.1.27	Line Number of Encoder	00001~65535	01024	★	
P0.1.28	Phase Sequence of Encoder	0: Forward Direction 1: Reverse Direction	0	★	
P0.1.29	Encoder Disconnection Testing Time	00: No action 00.1s~10.0s	00.0	★	
P0.1.30	Stator Resistance of Synchronous Machine	00.001~65.535	Machine type	▲/★	
P0.1.31	Back EMF of Synchronous Machine	0000.0~6553.5	Machine type	▲/★	87
P0.1.32	UVW Phase Sequence	0: Forward Direction 1: Reverse Direction	Machine type	▲/★	
P0.1.33	UVW Encoder Angle	000.0~359.9	Machine type	▲/★	
P0.1.34	Pole-pairs of Rotary Transformer	00001~65535	Machine type	▲/★	

### 5.2 Group P1 - Motor Control Parameter

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Sort P1.0: Basic Group					
P1.0.00	V/F Curve Mode	0: Straight Line 1: Multi-point Broken Line 2: Square V/F Curve 1 3: Square V/F Curve 2 4: Square V/F Curve 3	0	★	88
P1.0.01	Torque Boost	00.0% (Automatic Torque Boost) 00.1%~30.0%	04.0	☆	
P1.0.02	Cutoff Frequency of Torque Boost	000.00Hz~Highest Frequency	050.00		
P1.0.03	V/F Slip Compensation Gain	000.0%~200.0%	000.0	☆	
P1.0.04	Velocity Loop Proportional Gain 1	001~100	030	☆	
P1.0.05	Velocity Circulation Integral Time 1	00.01~10.00	00.50	☆	
P1.0.06	Switching Frequency 1	000.00Hz~P1.0.09	005.00	☆	89
P1.0.07	Velocity Loop Proportional Gain 2	001~100	020	☆	
P1.0.08	Velocity Circulation Integral Time 2	00.01~10.00	01.00	☆	
P1.0.09	Switching Frequency 2	P1.0.06~Highest Frequency	010.00	☆	
P1.0.10	Start Mode	0: Direct Start 1: Speed Tracking Mode 2: Brake and Restart	0	☆	
P1.0.11	Speed Tracking Mode	0: Start from Shutdown Frequency 1: Start from Zero Speed 2: Start from Highest Frequency	0	★	90
P1.0.12	Start Frequency	00.00Hz~10.00Hz	00.00	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P1.0.13	Hold Time of Start Frequency	000.0s~100.0s	000.0	★	90
P1.0.14	Starting DC Brake Current	000%~100%	000	★	91
P1.0.15	Starting DC Brake Time	000.0s~100.0s	000.0	★	
P1.0.16	Stop Mode	0: Stop by Deceleration 1: Free Stop	0	☆	
P1.0.17	Stop DC Braking Initial Frequency	000.00Hz~Highest Frequency	000.00	☆	
P1.0.18	Stop DC Braking Hold Time	000.0s~100.0s	000.0	☆	
P1.0.19	Stop DC Braking Current	000%~100%	000	☆	
P1.0.20	Stop DC Braking Time	000.0s~100.0s	000.0	☆	
P1.0.21	Braking Use Rate	000%~100%	100	☆	92
P1.0.22	Carrier Frequency	00.5kHz~16.0kHz	06.0	☆	
P1.0.23	Fan Control	0: Rotate at running 1: Continuous Running 2: Control based on Temperature	0	★	
P1.0.24	Motor Overload Protection	0: Prohibition 1: Curve 1 2: Curve 2 3: Curve 3	1	☆	93
P1.0.25	Motor Overload Protection Level	00.20~10.00	01.00	☆	
P1.0.26	Motor Overload Alarm System	050%~100%	080	☆	
Group P1.1: Extension Group					
P1.1.00	Broken Line V/F Point 1 Frequency	000.00Hz~P1.1.02	000.00	★	94
P1.1.01	Broken Line V/F Point 1 Voltage	000.0%~100.0%	000.0	★	
P1.1.02	Broken Line V/F Point 2 Frequency	P1.1.00~P1.1.04	000.00	★	
P1.1.03	Broken Line V/F Point 2 Voltage	000.0%~100.0%	000.0	★	
P1.1.04	Broken Line V/F Point 3 Frequency	P1.1.02~Motor rated frequency	000.00	★	
P1.1.05	Broken Line V/F Point 3 Voltage	000.0%~100.0%	000.0	★	
P1.1.06	V/F Overexcited Gain	000~200	064	☆	
P1.1.07	Vector Control Torque Upper Frequency	0: Digital Reference (P1.1.08) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Terminal Reference 4: PULS Reference (DI6) 5: Communication Reference 6: MIN (VF1, VF2) 7: MAX (VF1, VF2) 8: Operation Result 3 9: Operation Result 4 10: Standby Torque Source 1 11: Standby Torque Source 2	00	☆	95
P1.1.08	Torque Upper Limit Reference	000.0%~200.0%	150.0	☆	96
P1.1.09	Inversion Control Enable	0: Allow 1: Prohibit	0	☆	
P1.1.10	Forward and Reverse Dead Time	0000.0s~3000.0s	0000.0	☆	
P1.1.11	Power-on Running Selection	0: Running 1: Not Running	0	☆	97

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P1.1.12	Droop Control	00.00Hz~10.00Hz	00.00	☆	97
P1.1.13	Speed/Torque Control Mode Selection	0: Speed Control 1: Torque Control	0	★	
P1.1.14	Torque Reference Source	0: Digital Reference (P1.1.15) 1: External Terminal Vf1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Terminal Reference 4: PULS Reference (DI6) 5: Communication Reference 6: MIN (VF1, VF2) 7: MAX (VF1, VF2) 8: Operation Result 1 9: Operation Result 2 10: Operation Result 3 11: Operation Result 4 12: Standby Torque Source 1 13: Standby Torque Source 2	00	★	
P1.1.15	Torque Digital Reference	-200.0%~200.0%	150.0	☆	
P1.1.16	Torque Control FWD Frequency Limit	000.00Hz~Highest Frequency	050.00	☆	99
P1.1.17	Torque Control REV Frequency Limit	000.00Hz~Highest Frequency	050.00	☆	
P1.1.18	Torque Acceleration Time	0000.0s~6500.0s	0000.0	☆	
P1.1.19	Torque Deceleration Time	0000.0s~6500.0s	0000.0	☆	

### 5.3 Group P2 - Input/Output Terminal Function

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P2.0: Basic Group					
P2.0.00	DI1 Terminal Function	0: No Function	01	★	100
P2.0.01	DI2 Terminal Function	1: Forward (FWD)	04	★	
P2.0.02	DI3 Terminal Function	2: Reverse (REV)	09	★	
P2.0.03	DI4 Terminal Function	3: Three-wire Running Control	12	★	
P2.0.04	DI5 Terminal Function	4: Forward Jogging	13	★	
P2.0.05	DI6 Terminal Function	5: Reverse Jogging	00	★	
P2.0.06	DI7 Terminal Function	6: Terminal UP	00	▲/★	
P2.0.07	DI8 Terminal Function	7: Terminal DOWN	00	▲/★	
P2.0.08	DI9 Terminal Function	8: Free Stop	00	▲/★	
P2.0.09	DI10 Terminal Function	9: Multiplex Directive Terminal 1	00	▲/★	
		10: Multiplex Directive Terminal 2			
		11: Multiplex Directive Terminal 3			
		12: Multiplex Directive Terminal 4			
		13: Fault Reset (RESET)			
		14: Running Pause			
		15: External Fault Input			

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
		16: Acceleration & Deceleration Time Selection Terminal 1 17: Acceleration & Deceleration Time Selection Terminal 2 18: Frequency Source Selection Terminal 1 19: Frequency Source Selection Terminal 2 20: Frequency Source Selection Terminal 3 21: Running Command Selection Terminal 1 22: Running Command Selection Terminal 2 23: UP/DOWN Reference Reset 24: Prohibition of Acceleration & Deceleration 25: PID Pause 26: PLC State Reset 27: Wobbling Pause 28: Counter Input 29: Counter Reset 30: Length Counting Input 31: Length Reset 32: Torque Control Prohibition 33: PULS Impulse Input 34: Immediate DC Brake 35: External Fault Normally-closed Input 36: Frequency Modification Enable 37: PID Action Direction Negation 38: External Stop Terminal 1 39: External Stop Terminal 2 40: PID Integral Stop 41: PID Parameter Switch 42: Speed Control/Torque Control Switch 43: Emergency Stop 44: Deceleration DC Brake 45: User-Defined Fault 1 46: User-Defined Fault 2 47: Running Time Reset 48: Timer Input Terminal 1 49: Timer Input Terminal 2 50: Timer Reset Terminal 1 51: Timer Reset Terminal 2 52: Encoder Phase A Input 53: Encoder Phase B Input 54: Distance Reset 55: Integral Computation Reset 56: User Function 1 57: User Function 2 58: User Function 3 59: User Function 4			101

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P2.0.10	DI Filtering time	0.000s~1.000s	0.010	☆	105
P2.0.11	External Terminal Running Control Mode	0: Two-line Type 1 1: Two-line Type 2 2: Three-line Type 1 3: Three-line Type 2	0	★	
P2.0.12	UP/DOWN Terminal Change Rate	00.001Hz/s~65.535Hz/s	01.000	☆	
P2.0.13	Minimum Input of Curve 1	00.00V~P2.0.15	00.00	☆	106
P2.0.14	Corresponding reference for Minimum Input of Curve 1	-100.0%~100.0%	000.0	☆	
P2.0.15	Maximum Input of Curve 1	P2.0.13~10.00V	10.00	☆	
P2.0.16	Corresponding reference for Maximum Input of Curve 1	-100.0%~100.0%	100.0	☆	
P2.0.17	VF1 Filtering time	00.00s~10.00s	00.10	☆	
P2.0.18	Minimum Input of Curve 2	00.00V~P2.0.20	00.00	☆	
P2.0.19	Corresponding reference for Minimum Input of Curve 2	-100.0%~100.0%	000.0	☆	
P2.0.20	Maximum Input of Curve 2	P2.0.18~10.00V	10.00	☆	
P2.0.21	Corresponding reference for Maximum Input of Curve 2	-100.0%~100.0%	100.0	☆	
P2.0.22	VF2 Filtering time	0.00s~10.00s	00.10	☆	
P2.0.23	Minimum Input of PULS	0.00kHz~ P2.0.25	000.00	☆	
P2.0.24	Corresponding reference for Minimum Input of PULS	-100.0%~100.0%	000.0	☆	107
P2.0.25	Maximum Input of PULS	P2.0.23~100.00kHz	050.00	☆	
P2.0.26	Corresponding reference for Maximum Input of PULS	-100.0%~100.0%	100.0	☆	
P2.0.27	PULS Filtering time	00.00s~10.00s	00.10	☆	
P2.0.28	Expansion Card YO1 Function Selection	0: No Function 1: Frequency inverter under Running 2: Fault Stop Output 3: Frequency Level Testing FDT1 Output	00	▲/☆	
P2.0.29	T1 Relay Function Selection	4: Frequency Arrival 5: Zero-speed Running (no output when shut down)	01	☆	
P2.0.30	T2 Relay Function Selection	6: Motor Overload Pre-alarm 7: Frequency inverter Overload Pre-alarm 8: Reference Count Value Arrival 9: Designated Count Value Arrival	02	☆	
P2.0.31	Expansion Card YO2 Function Selection	10: Length Arrival 11: PLC circulation cycle completed 12: Accumulative Running Time Arrival	00	▲/☆	
P2.0.32	YO Function Selection (Use Terminal YO/FMP as YO,i.e.P2.1.20=1)	13: Frequency Limit 14: Torque Limit 15: Ready for Running 16: VF1>VF2 17: Upper Frequency Arrival	00	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
		18: Lower Frequency Arrival (no output when shut down) 19: Undervoltage state output 20: Communication Reference 21: VF1 Output less than Lower Limit 22: VF1 Output more Upper Limit 23: Zero-speed Running 2 (also output when shut down) 24: Accumulative Power-on Time Arrival 25: Frequency Level Testing FDT2 Output 26: Frequency 1 Arrival Output 27: Frequency 2 Arrival Output 28: Current 1 Arrival Output 29: Current 2 Arrival Output 30: Timing Arrival Output 31: VF1 Input Overlimit 32: In Off-load 33: In Reverse Running 34: Zero-current State 35: Module Temperature Arrival 36: Output Current Overlimit 37: Lower Frequency Arrival (also output when shut down) 38: Alarm Output 39: PLC Phase Completed 40: Current Running Time Arrival 41: Fault Output (Not Output for Undervoltage) 42: Timer 1 Timing Arrival 43: Timer 2 Timing Arrival 44: Timer 1 Timing Arrival but Timer 2 Timing Not Arrival 45: User Function 1 46: User Function 2 47: User Function 3 48: User Function 4 49: User Function 5 50: Synchronization Intermediate Relay M1 51: Synchronization Intermediate Relay M2 52: Synchronization Intermediate Relay M3 53: Synchronization Intermediate Relay M4 54: Synchronization Intermediate Relay M5 55: Distance over Zero 56: Distance Set value 1 Arrival 57: Distance Set value 2 Arrival 58: Operation Result 2 greater than 2 59: Operation Result 4 greater than 2			108



Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P2.0.33	Analog Output FM1 Reference	0: Running Frequency 1: Reference frequency 2: Output Current 3: Output Torque (Absolute Value of Torque) 4: Output Power 5: Output Voltage 6: Impulse Input	00	☆	111
P2.0.34	Analog Output FM2 Reference	7: VF1 Voltage 8: VF1 Voltage 9: Keyboard Potentiometer Voltage 10: Actual Length Value 11: Actual Counting Value 12: Communication Reference 13: Motor Speed	01	☆	
P2.0.35	FMP Output Reference (Use Terminal YO/FMP as FMP, i.e.P2.1.20=0)	14: Output Current 15: Bus Voltage 16: Output Torque 17: Operation Result 1 18: Operation Result 2 19: Operation Result 3 20: Operation Result 4	00	☆	
P2.0.36	Analog FM1 Output Offset	-100.0%~100.0%	000.0	☆	112
P2.0.37	Analog FM1 Output Gains	-10.00~10.00	01.00	☆	
P2.0.38	Analog FM2 Output Offset	-100.0%~100.0%	000.0	☆	
P2.0.39	Analog FM2 Output Gains	-10.00~10.00	01.00	☆	
Group P2.1: Extension Group					
P2.1.00	Valid Model Selection 1 of Terminal DI	0: Active High Level 1: Active Low Level Ones: DI1 Tens: DI2 Hundreds: DI3 Thousands: DI4 Ten Thousands: DI5	00000	★	112
P2.1.01	Valid Model Selection 2 of Terminal DI	0: Active High Level 1: Active Low Level Ones: DI6 Tens: DI7 (Invalid E100) Hundreds: DI8 (Invalid E100) Thousands: DI9 (Invalid E100) Ten Thousands: DI10 (Invalid E100)	00000	★	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P2.1.02	Analog Input Curve Selection	1: Curve 1 2: Curve 2 3: Curve 3 3: Curve 4 Ones: Curve Selected for VF1 Tens: Curve Selected for VF2	H.21	☆	113
P2.1.03	Selection for Curve less than Min. Reference	0: Corresponding Min. Input Reference 1: 0.0% Ones: VF1 less than Min. Input Tens: VF2 less than Min. Input	H.00	☆	
P2.1.04	Min. Input of Curve 3	00.00V~P2.1.06	00.00	☆	
P2.1.05	Corresponding reference for Min. Input of Curve 3	-100.0%~100.0%	000.0	☆	
P2.1.06	Curve 3 Inflection Point 1 Input	P2.1.04~P2.1.08	03.00	☆	
P2.1.07	Corresponding reference for Curve 3 Inflection Point 1 Input	-100.0%~100.0%	030.0	☆	
P2.1.08	Curve 3 Inflection Point 2 Input	P2.1.06~P2.1.10	06.00	☆	
P2.1.09	Corresponding reference for Curve 3 Inflection Point 2 Input	-100.0%~100.0%	060.0	☆	
P2.1.10	Max. input of Curve 3	P2.1.08~10.00V	10.00	☆	
P2.1.11	Corresponding reference for Max. input of Curve 3	-100.0%~100.0%	100.0	☆	
P2.1.12	Min. Input of Curve 4	00.00V~P2.1.14	00.00	☆	
P2.1.13	Corresponding reference for Min. Input of Curve 4	-100.0%~100.0%	-100.0	☆	
P2.1.14	Curve 4 Inflection Point 1 Input	P2.1.12~P2.1.16	03.00	☆	
P2.1.15	Corresponding reference for Curve 4 Inflection Point 1 Input	-100.0%~100.0%	-030.0	☆	
P2.1.16	Curve 4 Inflection Point 2 Input	P2.1.14~P2.1.18	06.00	☆	
P2.1.17	Corresponding reference for Curve 4 Inflection Point 2 Input	-100.0%~100.0%	030.0	☆	114
P2.1.18	Max. input of Curve 4	P2.1.16~10.00V	10.00	☆	
P2.1.19	Corresponding reference for Max. input of Curve 4	-100.0%~100.0%	100.0	☆	
P2.1.20	YO/FMP Terminal Function	0: Impulse output (FMP) 1: Open Collector Output (YO)	1	☆	
P2.1.21	Highest Frequency of FMP Output	000.01KHz~100.00KHz	050.00	☆	
P2.1.22	Valid State of Multi-functional Output Terminal	0: Positive Logic 1: Negative Logic Ones: YO 十位: T1 Tens: T1 Hundreds: T2 Thousands: Expansion Card YO1 (Invalid E100) Ten Thousands: Expansion Card YO2 (Invalid E100)	00000	☆	115
P2.1.23	VF1 Terminal Function as Digital Input	00: Use as Normal Analog 01 ~ 59: Digital Input Terminal Function	00	★	
P2.1.24	VF2 Terminal Function as Digital Input	00: Use as Normal Analog 01 ~ 59: Digital Input Terminal Function	00	★	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P2.1.25	Valid State Option of VF	0: Active High Level 1: Active Low Level Ones: VF1 Tens: VF2	00	★	115
P2.1.26	DI1 Delay	0.0s~3600.0s	0000.0	☆	116
P2.1.27	DI2 Delay	0.0s~3600.0s	0000.0	☆	
P2.1.28	DI3 Delay	0.0s~3600.0s	0000.0	☆	
P2.1.29	YO Delay	0.0s~3600.0s	0000.0	☆	
P2.1.30	T1 Delay	0.0s~3600.0s	0000.0	☆	
P2.1.31	T2 Delay	0.0s~3600.0s	0000.0	☆	
Group P2.2 Auxiliary Group					
P2.2.00	Accumulative Power-on Arrival Time Reference	00000h~65000h	00000	☆	116
P2.2.01	Accumulative Running Arrival Time Reference	00000h~65000h	00000	☆	
P2.2.02	Detected Reference frequency Width upon Arrival	000.0%~100.0%	000.0	☆	117
P2.2.03	Frequency Detection FDT1	000.00Hz~Highest Frequency	050.00	☆	
P2.2.04	FDT1 Lagged Value	000.0%~100.0%	005.0	☆	
P2.2.05	Frequency Detection FDT2	000.00Hz~Highest Frequency	050.00	☆	118
P2.2.06	FDT2 Lagged Value	000.0%~100.0%	005.0	☆	
P2.2.07	Detected Frequency Value 1 upon Arbitrary Arrival	000.00Hz~Highest Frequency	050.00	☆	
P2.2.08	Detected Frequency 1 Width upon Arbitrary Arrival	000.0%~100.0%	000.0	☆	
P2.2.09	Detected Frequency Value 2 upon Arbitrary Arrival	000.00Hz~Highest Frequency	050.00	☆	
P2.2.10	Detected Frequency 2 Width upon Arbitrary Arrival	000.0%~100.0%	000.0	☆	
P2.2.11	Zero Current Detection Level	000.0%~300.0% (100.0% correspond to rated current of motor)	005.0	☆	119
P2.2.12	Delay Time for Zero Current Detection	000.01s~600.00s	000.10	☆	
P2.2.13	Output Current Overlimit Value	00.0: No Detection 000.1%~300.0%	200.0	☆	
P2.2.14	Delay Time for Current Overlimit Detection	000.00s~600.00s	000.00	☆	
P2.2.15	Current Level Detection 1	000.0%~300.0%	100.0	☆	120
P2.2.16	Detection Width of Current Level 1	000.0%~300.0%	000.0	☆	
P2.2.17	Current Level Detection 2	000.0%~300.0%	100.0	☆	121
P2.2.18	Detection Width of Current Level 2	000.0%~300.0%	000.0	☆	
P2.2.19	VF1 Input Lower Limit	00.00V~P2.2.20	03.10	☆	
P2.2.21	Model Temperature Arrival Reference	000℃~100℃	075	☆	
P2.2.22	Current Running Arrival Time Reference	0000.0min~6500.0min	0000.0	★	

**5.4 Group P3 - Programmable Function**

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P3.0: Basic Group					
P3.0.00	Simple PLC Running Mode	0: End of Single Running and Stop 1: End of Single Running and Save Final Value 2: Continuous Running 3: Cycle N Times	0	☆	122
P3.0.01	Cycle Times N	00000~65000	00000	☆	
P3.0.02	Option of PLC Power-off Memory	Ones: Option of Power-off Memory 0: No Power-off Memory 1: Power-off Memory Tens: Stop Memory Selection 0: No Stop Memory 1: Stop Memory	00	☆	
P3.0.03	Phase Directive 0	-100.0%~100.0%	000.0	☆	123
P3.0.04	Phase 0 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.05	Phase Directive 1	-100.0%~100.0%	000.0	☆	
P3.0.06	Phase 1 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.07	Phase Directive 2	-100.0%~100.0%	000.0	☆	
P3.0.08	Phase 2 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.09	Phase Directive 3	-100.0%~100.0%	000.0	☆	
P3.0.10	Phase 3 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.11	Phase Directive 4	-100.0%~100.0%	000.0	☆	
P3.0.12	Phase 4 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.13	Phase Directive 5	-100.0%~100.0%	000.0	☆	
P3.0.14	Phase 5 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.15	Phase Directive 6	-100.0%~100.0%	000.0	☆	
P3.0.16	Phase 6 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.17	Phase Directive 7	-100.0%~100.0%	000.0	☆	
P3.0.18	Phase 7 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.19	Phase Directive 8	-100.0%~100.0%	000.0	☆	
P3.0.20	Phase 8 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.21	Phase Directive 9	-100.0%~100.0%	000.0	☆	
P3.0.22	Phase 9 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.23	Phase Directive 10	-100.0%~100.0%	000.0	☆	
P3.0.24	Phase 10 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.25	Phase Directive 11	-100.0%~100.0%	000.0	☆	
P3.0.26	Phase 11 Running Time	0000.0s~6500.0s	0000.0	☆	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P3.0.27	Phase Directive 12	-100.0%~100.0%	000.0	☆	123
P3.0.28	Phase 12 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.29	Phase Directive 13	-100.0%~100.0%	000.0	☆	
P3.0.30	Phase 13 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.31	Phase Directive 14	-100.0%~100.0%	000.0	☆	
P3.0.32	Phase 14 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.33	Phase Directive 15	-100.0%~100.0%	000.0	☆	
P3.0.34	Phase 16 Running Time	0000.0s~6500.0s	0000.0	☆	
P3.0.35	Phase 0 attribution	Ones: Acceleration & Deceleration Time Selection (Invalid Multiplex Directive)	H.00	☆	124
P3.0.36	Phase 1 attribution		H.00	☆	
P3.0.37	Phase 2 attribution	0: Acceleration & Deceleration Time 1	H.00	☆	
P3.0.38	Phase 3 attribution		H.00	☆	
P3.0.39	Phase 4 attribution	2: Acceleration & Deceleration Time 2	H.00	☆	
P3.0.40	Phase 5 attribution		H.00	☆	
P3.0.41	Phase 6 attribution	3: Acceleration & Deceleration Time 3	H.00	☆	
P3.0.42	Phase 7 attribution		H.00	☆	
P3.0.43	Phase 8 attribution	Tens: Frequency Source Selection (Valid Multiplex Directive)	H.00	☆	
P3.0.44	Phase 9 attribution		H.00	☆	
P3.0.45	Phase 10 attribution	0: Current Phase Directive	H.00	☆	
P3.0.46	Phase 11 attribution		H.00	☆	
P3.0.47	Phase 12 attribution	1: Keyboard Potentiometer	H.00	☆	
P3.0.48	Phase 13 attribution		H.00	☆	
P3.0.49	Phase 14 attribution	2: Keyboard Frequency Reference	H.00	☆	
P3.0.50	Phase 15 attribution		H.00	☆	
P3.0.51	Simple PLC Running Time Unit	0: Second 1: Hour	0	☆	
Group P3.1: Expansion Group					
P3.1.00	Timing Function Selection	0: Invalid 1: Valid	0	★	124
P3.1.01	Fixed Running Time Selection	0: Digital Reference (P3.1.02) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference (Analog input range corresponds to P3.1.02)	0	★	
P3.1.02	Fixed Running Time	0000.0min~6500.0min	0000.0		
P3.1.03	Wobulating Reference Mode	0: Relative to Reference frequency 1: Relative to Highest Frequency	0	☆	125
P3.1.04	Wobulating Range	000.0%~100.0%	000.0	☆	
P3.1.05	Kicking Range	00.0%~50.0%	00.0	☆	
P3.1.06	Wobulating Cycle	0000.1s~3000.0s	0010.0	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P3.1.07	Rise Time of Wobbling Triangular Wave	000.1%~100.0%	050.0	☆	125
P3.1.08	Reference Length	00000m~65535m	01000	☆	
P3.1.09	Actual Length	00000m~65535m	00000	☆	
P3.1.10	Impulse Count per meter	0000.1~6553.5	0100.0	☆	
P3.1.11	Reference Count Value	00001~65535	01000	☆	
P3.1.12	Designated Count Value	00001~65535	01000	☆	
P3.1.13	Distance Set value 1	-3200.0~3200.0	0000.0	☆	
P3.1.14	Distance Set value 2	-3200.0~3200.0	0000.0	☆	
P3.1.15	Impulse Count per Distance	000.00~600.00	000.00	☆	
<b>Group P3.2: Built-in Logic PLC Function Group</b>					
P3.2.00	Intermediate Delay Relay Control	0: the input of this relay is determined by this Relay Control Word A 1: the input of this relay is determined by this Relay Control Word B 2: the input of this relay is determined by this Relay Control Word C Ones: Relay 1 (M1) Tens: Relay 2 (M2) Hundreds: Relay 3 (M3) Thousands: Relay 4 (M4) Ten Thousands: Relay 5(M5)	00000	★	126
P3.2.01	Intermediate Relay Control Word A	0: Reference 0 1: Reference 1 Ones: M1 Tens: M2 Hundreds: M3 Thousands: M4 Ten Thousands: M5	00000	☆	
P3.2.02	Intermediate Delay Relay M1 Control Word B	Ones: Control Logic 0: Input 1 1: Input 1 and NOT 2: Input 1 and Input 2 AND 3: Input 1 and Input 2 OR 4: Input 1 and Input 2 XOR 5: the valid reference of Input 1 is valid	00000	★	127
P3.2.03	Intermediate Delay Relay M2 Control Word B	the valid Reference of Input 2 is invalid	00000	★	
P3.2.04	Intermediate Delay Relay M3 Control Word B	6. Valid reference of Input 1 Rise Edge is valid Valid reference of Input 2 Rise Edge is invalid	00000	★	
P3.2.05	Intermediate Delay Relay M4 Control Word B	7: Reverse valid signal of Input 1 Rising Edge	00000	★	
P3.2.06	Intermediate Delay Relay M5 Control Word B	8: Input 1 Rise Edge is valid and output a impulse signal with width of 200ms 9: Input 1 Rise Edge and Input 2 AND	00000	★	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
		Hundreds and Tens: Input 1 Selection 0~9: DI1~DI10 10~14: M1~M5 15~16: VF1, VF2 17~19: Standby 20~79: Output Function 00~59 Corresponding to Multi-functional Output Terminal Ten Thousands: Input 2 Selection 0~9: DI1~DI10 10~14: M1~M5 15~16: VF1, VF2 17~19: Standby 20~59: Output Function 00~39 Corresponding to Multi-functional Output Terminal			127
P3.2.07	Intermediate Delay Relay M1 Control Word C	Tens Ones:00~59	0000	★	128
P3.2.08	Intermediate Delay Relay M2 Control Word C	Output Function 00~59 Corresponding to Digital Input Terminal	0000	★	
P3.2.09	Intermediate Delay Relay M3 Control Word C	Thousands Hundreds	0000	★	
P3.2.10	Intermediate Delay Relay M4 Control Word C	Output Function 00~59 Corresponding to Multi-functional Output Terminal	0000	★	
P3.2.11	Intermediate Delay Relay M5 Control Word C		0000	★	
P3.2.12	M1 Connection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.13	M2 Connection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.14	M3 Connection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.15	M4 Connection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.16	M5 Connection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.17	M1 Disconnection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.18	M2 Disconnection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.19	M3 Disconnection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.20	M4 Disconnection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.21	M5 Disconnection Delay Time	0.0s~3600.0s	0000.0	☆	
P3.2.22	Valid State Option of Intermediate Relay	0: Not Negation 1: Negation Ones: M1 Tens: M2 Hundreds: M3 Thousands: M4 Ten Thousands: M5	00000	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P3.2.23	Internal Timer Control Word	Ones: Timing Control 1 of Timer Tens: Timing Control 2 of Timer 0: Timer Running 1: Controlled by Timer Input Terminal 1 2: Negation Control of Timer Input Terminal 1 3: Controlled by Timer Input Terminal 2 4: Negation Control of Timer Input Terminal 2 Hundreds: Timer 1 Reset Control Thousands: Timer 2 Reset Control 0: Controlled by Timer Reset Terminal 1 1: Controlled by Timer Reset Terminal 2 Ten Thousands: Timing Unit 0: Second 1: Minute	00000	☆	129
P3.2.24	Timing Time of Timer 1	0.0s~3600.0s	0000.0	☆	
P3.2.25	Timing Time of Timer 2	0.0s~3600.0s	0000.0	☆	
P3.2.26	Operation Module	0: No Operation 1: Add Operation 2: Subtraction Operation 3: Multiply Operation 4: Division Operation 5: Greater than Judgment 6: Equal to Judgment 7: Equal to or Greater than Judgment 8: Integration 9~F: Reservation Ones: Operation 1 Tens: Operation 2 Hundreds: Operation 3 Thousands: Operation 4	H.0000	☆	130
P3.2.27	Operation Coefficient Property Setting	0: Operate the Setting Coefficient by multiplication without decimal 1: Operate the Setting Coefficient by multiplication with one decimal 2: Operate the Setting Coefficient by multiplication with two decimals 3: Operate the Setting Coefficient by multiplication with three decimals 4: Operate the Setting Coefficient by multiplication with four decimals 5: Operate the Setting Coefficient by division without decimal 6: Operate the Setting Coefficient by division with one decimal 7: Operate the Setting Coefficient by division with two decimals 8: Operate the Setting Coefficient by division with three decimals 9: Operate the Setting Coefficient by division with four decimals Ones: Operation 1 Tens: Operation 2 Hundreds: Operation 3 Thousands: Operation 4	0000	☆	



Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P3.2.28	Input A of Operation 1	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	131
P3.2.29	Input B of Operation 1	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	
P3.2.30	Setting Coefficient of Operation 1	00000~65535	00001	☆	
P3.2.31	Input A of Operation 2	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 2 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	
P3.2.32	Input B of Operation 2	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	
P3.2.33	Setting Coefficient of Operation 2	00000~65535	00001	☆	
P3.2.34	Input A of Operation 3	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 3 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	132
P3.2.35	Input B of Operation 3	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 3 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	
P3.2.36	Setting Coefficient of Operation 3	00000~65535	00001	☆	
P3.2.37	Input A of Operation 4	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 4 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P3.2.38	Input B of Operation 4	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 4 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000	☆	132
P3.2.39	Setting Coefficient of Operation 4	00000~65535	00001	☆	

### 5.5 Group P4 - PID Control And Communication Control

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P4.0: PID Control Group					
P4.0.00	PID Reference Source	0: Digital Reference (P4.0.01) 1: Keyboard Potentiometer Reference 2: External Terminal VF1 Reference 3: External Terminal VF2 Reference 4: PULS Reference (DI6) 5: Communication Reference 6: Multiplex Directive Terminal Reference 7: Simple PLC Reference 8: Operation Result 1 9: Operation Result 2 10: Operation Result 3 11: Operation Result 4	00	☆	133
P4.0.01	PID Value Reference	000.0%~100.0%	050.0	☆	
P4.0.02	PID Feedback Source	0: External Terminal VF1 Reference 1: External Terminal VF1 Reference 2: VF1-VF2 3: VF1+VF2 4: PULS Reference (DI6) 5: Communication Reference 6: MAX[VF1, VF2] 7: MIN[VF1, VF2] 8: Switch of Multiplex Directive Terminal on the above conditions 9: Operation Result 1 10: Operation Result 2 11: Operation Result 3 12: Operation Result 4	00	☆	134
P4.0.03	PID Action Direction	0: Direct Action 1: Reverse Action	0	☆	136
P4.0.04	PID Reference Feedback Range	00000~65535	01000	☆	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P4.0.05	Proportional Gains KP1	000.0~100.0	020.0	☆	136
P4.0.06	Integral Time TI1	00.01s~10.00s	02.00	☆	
P4.0.07	Derivative Time Td1	00.000s~10.000s	00.000	☆	
P4.0.08	PID Deviation Limit	000.0%~100.0%	000.0	☆	137
P4.0.09	PID Feedback Filtering time	00.00s~60.00s	00.00	☆	
P4.0.10	Proportional Gains KP2	000.0~100.0	020.0	☆	
P4.0.11	Integral Time TI2	00.01s~10.00s	02.00	☆	
P4.0.12	Derivative Time Td2	00.000s~10.000s	00.000	☆	
P4.0.13	PID Switch Conditions	0: No Switch 1: Switch through Terminals 2: Switch through Deviation	0	☆	138
P4.0.14	PID Switch Deviation 1	000.0%~P4.0.15	020.0	☆	
P4.0.15	PID Switch Deviation 2	P4.0.14~100.0%	080.0	☆	
P4.0.16	PID Initial Value	000.0%~100.0%	000.0	☆	
P4.0.17	PID Initial Value Hold Time	000.00~650.00s	000.00	☆	
P4.0.18	PID Feedback Loss Detection	000.0%: No Judgment on Feedback Loss 000.1%~100.0%	000.0	☆	
P4.0.19	PID Feedback Loss Detection Time	00.0s~20.0s	00.0	☆	139
P4.0.20	PID Stop Operation	0: No Operation 1: Operation	0		
<b>Group P4.1: Communication Group</b>					
P4.1.00	Baud Rate	0: 1200 1: 2400 2: 4800 3: 9600 4: 19200 5: 38400 6: 57600	3	☆	139
P4.1.01	Data Format	0: No Verification (8-N-2) 1: Even Parity Verification (8-E-1) 2: Odd Parity Verification (8-O-1) 3: No Verification (8-N-1)	0	☆	
P4.1.02	Local Machine Address	000: Broadcast Address 001~249	001	☆	
P4.1.03	Response Delay	00~20ms	02	☆	
P4.1.04	Communication Timeout	00.0 (Invalid) 00.1s~60.0s	00.0	☆	
P4.1.05	Data Transmission Format	0: ASCII Mode (Reservation) 1: RTU Mode	1	☆	

## 5.6 Group P5 - Keyboard Display

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P5.0: Basic Group					
P5.0.00	Keyboard JOG Key Function Reference	0: Invalid 1: Forward Jogging 2: Reverse Jogging 3: Forward and Reverse Switch	1	★	140
P5.0.01	Keyboard STOP Key Stop Function	0: Only valid in Keyboard Operation Mode 1: Valid for any Mode	1	☆	
P5.0.02	LED Running Display Parameter 1	H.0001~H.FFFF Bit00: Running Frequency (Hz) Bit01: Reference frequency (Hz) Bit02: Output Current (A) Bit03: Output Voltage (V) Bit04: Bus Voltage (V) Bit05: Output Torque (%) Bit06: Output Power (kW) Bit07: Input Terminal State Bit08: Output Terminal State Bit09: VF1 Voltage (V) Bit10: VF2 Voltage (V) Bit11: Customized Display Value Bit12: Actual Count Value Bit13: Actual Length Value Bit14: PID Reference Bit15: PID Feedback	H.001F	☆	
P5.0.03	LED Running Display Parameter 2	H.0000~H.FFFF Bit00: Impulse frequency (0.01kHz) Bit01: Feedback Speed (Hz) Bit02: PLC Phase Bit03: VF1 Voltage before Correction(V) Bit04: VF2 Voltage before Correction (V) Bit05: Line Speed Bit06: Current Power-on Time (min) Bit07: Current Running Time (min) Bit08: Residual Running Time (min) Bit09: Frequency of Frequency Source A(Hz) Bit10: Frequency of Frequency Source B(Hz) Bit11: Communication Set value (Hz) Bit12: Impulse frequency (Hz) Bit13: Encoder Feedback Speed (r/min) Bit14: Actual Distance Value Bit15: User Standby Monitoring Value 1	H.0000	☆	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P5.0.04	Automatic Time Switch of LED Running Display Parameter	000.0: No Switch 000.1s~100.0s	000.0	☆	140
P5.0.05	LED Stop Display Parameter	H.0001~H.FFFF Bit00: Reference frequency (Hz) Bit01: Bus Voltage (V) Bit02: Input Terminal State Bit03: Output Terminal State Bit04: VF1 Voltage (V) Bit05: VF2 Voltage (V) Bit06: Actual Count Value Bit07: Actual Length Value Bit08: PLC Phase Bit09: Customized Display Value Bit10: PID Reference Bit11: PID Feedback Bit12: Impulse frequency (Hz) Bit13: User Standby Monitoring Value 1 Bit14: Reservation Bit15: Reservation	H.0033	☆	142
P5.0.06	LCD Line 1 Display at Running	0000~9399	9001	☆	143
P5.0.07	LCD Line 2 Display at Running	0000~9399	9000	☆	
P5.0.08	LCD Line 3 Display at Running	0000~9399	9002	☆	
P5.0.09	LCD Line 4 Display at Running	0000~9399	9003	☆	
P5.0.10	LCD Line 1 Display at Stop	0000~9399	9001	☆	
P5.0.11	LCD Line 2 Display at Stop	0000~9399	9000	☆	
P5.0.12	LCD Line 3 Display at Stop	0000~9399	9004	☆	
P5.0.13	LCD Line 4 Display at Stop	0000~9399	0000	☆	
P5.0.14	LCD Chinese/English Display Switch	0: Chinese 1: English	0	☆	
P5.0.15	Customized Display of Coefficient	0.0001~6.5000	1.0000	☆	
P5.0.16	Customized Display of Decimal Point	0: 0-digit Decimal Point 1: 1-digit Decimal Point 2: 2-digit Decimal Point 3: 3-digit Decimal Point	1	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P5.0.17	Selection Display of Function Parameter Group	Ones: 0: Only display basic group 1: Display the menus at all levels Tens 0: Don't display Group P7 1: Display Group P7 2: Reservation Hundreds: 0: Don't display correction parameter group 1: Display correction parameter group Thousands: 0: Don't display code group 1: Display code group Ten Thousands: Reservation	00011	☆	144
P5.0.18	Function Password Protection	0: Modifiable 1: Non-modifiable 2: Allowable Modification to GP Type	0	☆	
P5.0.19	Parameter Initialization	00: No Operation 01: Clearance of Record Information 09: Reset to Factory Parameter, excluding motor parameter, correction group, password group 19: Reset to Factory Parameter, excluding motor parameter, password group 30: Users Current Parameter Backup 60: Reset to User Backup Parameters 100~999: Reset to User Factory Parameters	000	☆	
P5.0.20	User Password	00000~65535	00000	☆	145
Group P.5.1 Expansion Group					
P5.1.00	Accumulative Running Time	00000h~65000h		●	145
P5.1.01	Accumulative Power On Time	00000h~65000h		●	
P5.1.02	Accumulative Power Consumption	00000 Kilowatt~65000 Kilowatt		●	
P5.1.03	Module Temperature	000℃~100℃		●	
P5.1.04	Hardware Version No.	180.00		●	
P5.1.05	Software Version No.	001.00		●	
P5.1.06	Program Nonstandard Label	0000~9999		●	

## 5.7 Group P6 - Fault Display and Protection

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P6.0: Fault Display Group					
P6.0.00	Fault Record 1 (Last Time)	0: No Fault 1: Constant Overcurrent 2: Accelerated Overcurrent 3: Decelerated Overcurrent 4: Constant Overvoltage 5: Accelerated Overvoltage 6: Decelerated Overvoltage 7: Module Fault 8: Undervoltage 9: Frequency inverter Overload 10: Motor Overload 11: Input Default Phase 12: Output Default Phase		●	146
P6.0.01	Fault Record 2	13: External Fault 14: Communication Abnormity 15: Frequency inverter Overheat 16: Frequency inverter Hardware Fault 17: Motor-to-ground Short Circuit 18: Motor Identification Error 19: Motor Off-load 20: PID Feedback Loss 21: User Customized Fault 1 22: User Customized Fault 2 23: Power-on Time Arrival 24: Running Time Arrival 25: Encoder Fault		●	
P6.0.02	Fault Record 3	26: Parameter Read-Write Abnormity 27: Motor Overheat 28: Larger Speed Deviation 29: Motor Overspeed 30: Initial Position Error 31: Current Detection Fault 32: Contactor 33: Abnormity of Current Detection 34: Fast Current-limiting Timeout 35: Motor Switch at Running 36: 24V Power Fault 37~39: Reservation 40: Buffer Resistance Fault			

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P6.0.03	Fault Frequency 1			●	146
P6.0.04	Fault Current 1			●	
P6.0.05	Bus Voltage 1 when at Fault			●	
P6.0.06	Input Terminal State 1 when at fault			●	
P6.0.07	Output Terminal State 1 when at fault			●	
P6.0.08	Frequency inverter State 1 when at fault			●	
P6.0.09	Power-on Time 1 when at fault			●	
P6.0.10	Running Time 1 when at fault			●	
P6.0.11	Fault Frequency 2			●	
P6.0.12	Fault Current 2			●	
P6.0.13	Bus Voltage 2 when at Fault			●	147
P6.0.14	Input Terminal State 2 when at fault			●	
P6.0.15	Output Terminal State 2 when at fault			●	
P6.0.16	Frequency inverter State 2 when at fault			●	
P6.0.17	Power-on Time 2 when at fault			●	
P6.0.18	Running Time 2 when at fault			●	
P6.0.19	Fault Frequency 3			●	
P6.0.20	Fault Current 3			●	
P6.0.21	Bus Voltage 3 when at Fault			●	
P6.0.22	Input Terminal State 3 when at fault			●	
P6.0.23	Output Terminal State 3 when at fault			●	
P6.0.24	Frequency inverter State 3 when at fault			●	
P6.0.25	Power-on Time 3 when at fault			●	
P6.0.26	Running Time 3 when at fault			●	
<b>Group 6.1: Protection Control Group</b>					
P6.1.00	Input Default Phase Protection	0: Prohibited 1: Allowed	1	☆	147
P6.1.01	Output Default Phase Protection	0: Prohibited 1: Allowed	1	☆	
P6.1.02	Overvoltage Stall Protection Sensitivity	0~100	000	☆	148
P6.1.03	Overvoltage Stall Protection Voltage Point	120%~150%	130	☆	
P6.1.04	Overcurrent Stall Protection Sensitivity	0~100	020	☆	
P6.1.05	Overcurrent Protection current	100%~200%	150	☆	
P6.1.06	Fault Auto Reset Number	0~20	00	☆	
P6.1.07	Waiting Interval Time of Fault Auto Reset	0.1s~100.0s	001.0	☆	



Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P6.1.08	Fault Protective Action Selection 1	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Motor Overload Tens: Input Default Phase Hundreds: Output Default Phase Thousands: External Default Ten Thousands: Communication Abnormality	00000	☆	149
P6.1.09	Fault Protective Action Selection 2	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Motor Overload Tens: Feedback Loss Hundreds: User Customized Fault 1 Thousands: User Customized Fault 2 Ten Thousands: Power-on Time Arrival	00000	★	
P6.1.10	Fault Protective Action Selection 3	Ones: Running Time Arrival 0: Free Stop 1: Stop by its Mode 2: Continuous Running Tens: Encoder Abnormality 0: Free Stop Hundreds: Parameter Read-Write Abnormity 0: Free Stop 1: Stop by its Mode Thousands: Motor Overhear 0: Free Stop 1: Stop by its Mode 2: Continuous Running Ten Thousands: Fault of 24V Power Supply 0: Free Stop 1: Stop by its Mode	00000	☆	
P6.1.11	Fault Protective Action Selection 4	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Larger Speed Deviation Tens: Motor Overspeed Hundreds: Initial Position Error Thousands: Reservation Ten Thousands: Reservation	00000	☆	

Chapter 5 Tables of Function Parameters

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
P6.1.12	Continuous Running Frequency Selection when at Fault	0: Running at Current Frequency 1: Running at Reference frequency 2: Running at Upper Frequency 3: Running at Lower Frequency 4: Running at Back Frequency for Abnormality	0	☆	150
P6.1.13	Backup Frequency for Abnormality	000.0%~100.0%	100.0	☆	
P6.1.14	Action Selection for Momentary Interruption	0: Invalid 1: Deceleration 2: Stop by Deceleration	0	☆	151
P6.1.15	Judgment Time of Momentary Interruption Voltage Recovery	000.00s~100.00s	000.50	☆	
P6.1.16	Voltage Judgment for Momentary Interruption Action	60.0%~100.0% (Standard Bus Voltage)	080.0	☆	
P6.1.17	Voltage Judgment for Suspension of Momentary Action	80.0%~100.0% (Standard Bus Voltage)	090.0	☆	
P6.1.18	Off-load Protection Selection	0: Valid 1: Invalid	0	☆	152
P6.1.19	Off-load Detection Level	000.0%~100.0%	010.0	☆	
P6.1.20	Off-load Detection Time	00.0s~60.0s	01.0	☆	
P6.1.21	Overspeed Detection	00.0%~50.0%	20.0	☆	
P6.1.22	Overspeed Detection Time	00.0: No Detection 00.1s~60.0s	01.0	☆	
P6.1.23	Speed Deviation greater than Detection Value	00.0%~50.0%	20.0	☆	
P6.1.24	Speed Deviation greater than Detection Time	00.0: No Detection 00.1s~60.0s	05.0	☆	
P6.1.25	Fault Output Terminal Action Selection during Fault Auto Reset Period	0: No Action 1: Action	0	☆	
P6.1.26	Input Default Phase Protection Sensitivity	01~10 (The smaller it is, the more sensitivity it is)	04	☆	147

## 5.8 Group P7 - User Function Customization

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P7.0: Basic Group					
P7.0.00	User Function 0	U0.0.01	U0.001	●	153
P7.0.01	User Function 1	U0.0.00~UX.X.XX (exclude P7, P8)	U0.002	☆	
P7.0.02	User Function 2	U0.0.00~UX.X.XX (exclude P7, P8)	U0.003	☆	
P7.0.03	User Function 3	U0.0.00~UX.X.XX (exclude P7, P8)	U0.007	☆	
P7.0.04	User Function 4	U0.0.00~UX.X.XX (exclude P7, P8)	U0.008	☆	
P7.0.05	User Function 5	U0.0.00~UX.X.XX (exclude P7, P8)	U0.017	☆	
P7.0.06	User Function 6	U0.0.00~UX.X.XX (exclude P7, P8)	U0.018	☆	
P7.0.07	User Function 7	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.08	User Function 8	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.09	User Function 9	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.10	User Function 10	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.11	User Function 11	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.12	User Function 12	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.13	User Function 13	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.14	User Function 14	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.15	User Function 15	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.16	User Function 16	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.17	User Function 17	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.18	User Function 18	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.19	User Function 19	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.20	User Function 20	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.21	User Function 21	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.22	User Function 22	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.23	User Function 23	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.24	User Function 24	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.25	User Function 25	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.26	User Function 26	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.27	User Function 27	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.28	User Function 28	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	
P7.0.29	User Function 29	U0.0.00~UX.X.XX (exclude P7, P8)	U0.000	☆	

**5.9 Group P8 - Manufacturer Function**

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Group P8.0: Manufacturer Function Group					
P8.0.00	Manufacturer Code	00000~65535	00000	☆	154
Sort P8.1: Parameter Correction Sort					
P8.1.00	Voltage Input of Potentiometer Correction Point 1	00.00V~P8.1.02	00.00	☆	154
P8.1.01	Corresponding reference of Potentiometer Correction Point 1	-100.0%~100.0%	000.0	☆	
P8.1.02	Voltage Input of Potentiometer Correction Point 2	P8.1.00~10.00V	10.00	☆	
P8.1.03	Corresponding reference of Potentiometer Correction Point 2	-100.0%~100.0%	100.0	☆	
P8.1.04	Filtering time of potentiometer	00.00s~10.00s	00.10	☆	
P8.1.05	VF1 actual voltage 1	0.500V~4.000V	2.000	☆	
P8.1.06	VF1 indicated voltage 1	0.500V~4.000V	2.000	☆	
P8.1.07	VF1 actual voltage 2	6.000V~9.999V	8.000	☆	
P8.1.08	VF1 indicated voltage 2	6.000V~9.999V	8.000	☆	
P8.1.09	VF2 actual voltage 1	0.500V~4.000V	2.000	☆	
P8.1.10	VF2 indicated voltage 1	0.500V~4.000V	2.000	☆	
P8.1.11	VF2 actual voltage 2	6.000V~9.999V	8.000	☆	
P8.1.12	VF2 indicated voltage 2	6.000V~9.999V	8.000	☆	
P8.1.13	FM1 target voltage 1	0.500V~4.000V	2.000	☆	
P8.1.14	FM1 actual voltage 1	0.500V~4.000V	2.000	☆	
P8.1.15	FM1 target voltage 2	6.000V~9.999V	8.000	☆	
P8.1.16	FM1 target voltage 2	6.000V~9.999V	8.000	☆	
P8.1.17	FM2 target voltage 1	0.500V~4.000V	2.000	☆	
P8.1.18	FM2 target voltage 1	0.500V~4.000V	2.000	☆	
P8.1.19	FM2 target voltage 2	6.000V~9.999V	8.000	☆	
P8.1.20	FM2 target voltage 2	6.000V~9.999V	8.000	☆	

**5.10 Group P9 - Monitoring Parameter**

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page
Sort P9.0: Basic Monitoring Parameter					
P9.0.00	Running Frequency			●	156
P9.0.01	Reference frequency			●	
P9.0.02	Output Current			●	
P9.0.03	Output Voltage			●	
P9.0.04	Bus Voltage			●	
P9.0.05	Output Torque			●	

Function code	Function name	Setting scope	Factory Value	Modification limit	Reference page	
P9.0.06	Output Power			●	156	
P9.0.07	Input Terminal Status			●		
P9.0.08	Output Terminal Status			●		
P9.0.09	VF1 Voltage			●		
P9.0.10	VF2 Voltage			●		
P9.0.11	Custom Display Value			●		
P9.0.12	Actual Counting Value			●		
P9.0.13	Actual Length Value			●		
P9.0.14	PID Reference			●		
P9.0.15	PID Feedback			●		
P9.0.16	PULS Impulse frequency			●		
P9.0.17	Feedback Speed			●		
P9.0.18	PLC Phase			●		
P9.0.19	Voltage before Vf1 Correction			●		
P9.0.20	Voltage before VF2 Correction			●		
P9.0.21	Line Speed			●		
P9.0.22	Current Power-on Time			●		
P9.0.23	Current Running Time			●		
P9.0.24	Residual Running Time			●		
P9.0.25	Frequency of Frequency Source A			●		
P9.0.26	Frequency of Frequency Source B			●		157
P9.0.27	Communication Set value			●		
P9.0.28	Impulse frequency			●		
P9.0.29	Encoder Feedback Speed			●		
P9.0.30	Actual Distance Value			●		
P9.0.31~ P9.0.45	Reservation			●		
P9.0.46	Operation Result 1			●		
P9.0.47	Operation Result 2			●		
P9.0.48	Operation Result 3			●		
P9.0.49	Operation Result 4			●		
P9.0.50	User Standby Monitoring Value 1			●		
P9.0.51	User Standby Monitoring Value 2			●		
P9.0.52	User Standby Monitoring Value 3			●		
P9.0.53	User Standby Monitoring Value 4			●		
P9.0.54	User Standby Monitoring Value 5			●		

## Chapter 6. Description of Parameters

### 6.1 Group 0 - Basic Function

#### P0.0 Group Basic Group

Function code	Function Name	Setting scope	Factory Value
P0.0.00	Type of Frequency inverter	1:G Type (constant torque load type) 2:P Type (fans and water pump load type)	Type

This function code is only for the users to check the factory type of the frequency inverter and is generally not allowed to be modified by the users. If modification is required, the function code P5.0.18 must be first changed to 2.

- 1: G Type applicable for constant torque load 80
- 2: P Type applicable for fans and water pump load

Function code	Function Name	Setting scope	Factory Value
P0.0.01	Display Mode	0:Basic Mode (Prefix with 'P') 1:User Mode (Prefix with 'U') 2:Verification Mode (Prefix with 'C')	0

This function code is used for confirming what a kind of display modes is selected for inventor  
0: Basic Mode (Prefix with 'P')

The frequency inverter specifically displays what parameters of the function codes are determined by Function Code P5.0.17 (Refer to the description for Function Code P5.0.17 for more details)

- 1: User Mode (Prefix with 'U')

Only display customization parameters of user function and use Function Code of Group P7.0 to determine what parameters of the function codes are specifically displayed by the frequency inverter (Refer to the description for Group P7.0 for more details). In user mode, the function code has the prefix with 'U'.

- 2: Verification Mode (Prefix with 'C')

Only display the modified parameters (in case of any difference of function code between reference value and factory value, it is deemed that the parameters are changed), the function code has the prefix with 'C' at this time.

**Note: no matter what the prefix is, 'P' or 'U' or 'C', the meaning of their relative parameters is the same and the prefix is only for distinguishing the display mode.**

Function code	Function Name	Setting scope	Factory Value
P0.0.02	Control Mode	0:V/F Control 1: Open-loop Vector Control (SVC) 2: Closed-loop Vector Control (Invalid E100)	1

0:V/FC control

Be applicable for the occasions without high requirements to load or where one set of frequency inverter drives more than one set of motor.

1. SVC

Don't need to externally connect the encoder as speed feedback and be applicable for general and high-powered occasions, one set of frequency inverter only drives one set of motor.

2. VC

Need to externally connect the encoder as speed feedback and be applicable for occasions with high-precision speed control or torque control, one set of frequency inverter only drives one set of motor. CDI-E180 Series hasn't had this function and doesn't need to have external expansion card of the encoder.

If the load motor is permanent magnet synchronous motor, the VC shall be selected.

**Note: if the vector control mode is selected, it is better to identify the parameters of the motor, only precise parameters of the motor can give play to the advantages of VC Mode.**

Function code	Function Name	Setting scope	Factory Value
P0.0.03	Option of operation control mode	0: Keyboard Control 1: Terminal Control 2: Communication Control	0

0: Keyboard Control

Key RUN, STOP and JOG on operating panel control start, stop and FWD& REV switch of the frequency inverter

1: Terminal Input

Use the digital input terminal to control FWD, REV and stop of the frequency inverter

2: Communication Control

Use the principal computer to control FWD, REV, stop, jog and reset (Refer to Chapter VIII for more details)

Detailed methods for the above three kinds of control methods refer to 7.1.1

Function code	Function Name	Setting scope	Factory Value
P0.0.04	Option of A Frequency Source	0:Keyboard Reference (No Power-off Memory) 1:Keyboard Reference (Power-off Memory) 2: Keyboard Potentiometer Reference 3: External Terminal VF1 Reference 4:External Terminal VF2 Reference 5:PULS Reference (DI6) 6: Multiplex Directive Reference 7:Simple PLC Reference 8:PID Control Reference 9:Communication Reference 10:Operation Result 1 11:Operation Result 2 12:Operation Result 3 13:Operation Result 4	02

0: Keyboard Reference (No Power-off Memory)

The initial value of the reference frequency is the value set by Function Code P0.0.05, and it can be changed through Key▲&▼ on the keyboard or Terminal UP/DOWN. After the frequency inverter powers on again after power off, the reference frequency is set to value set by P0.0.05.

1: Keyboard Reference (Power-off Memory)

The initial value of the reference frequency is the value set by Function Code P0.0.05, and it can be changed through Key▲ & ▼ on the keyboard or Terminal UP/DOWN. After the frequency inverter powers on again after power off, the reference frequency is the frequency at the time of power off, and it can be saved through Key▲ & ▼ on the keyboard or Terminal UP/DOWN.

2: Keyboard Potentiometer Reference

The reference frequency is given by the potentiometer on operation panel. The impact of zero-offset or voltage attenuation caused by overlong keyboard lines can be adjusted through Function Code P8.1.00~P8.1.04.

3: External Terminal VF1 Reference

4: External Terminal VF2 Reference

The reference frequency is given by the analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2) . VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve between the input of Vf1 and VF2 and the reference frequency , the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. The deviation between actual voltage and sampling voltage of the analog input terminal can be adjusted through Function Code P8.1.05~P8.1.12.



5: PULS Reference (Di6)

The frequency reference is given by high-speed impulse frequency of digital input terminal D16 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and torque upper limit value can be set through Function Code P2.0.23~P2.0.26, that is, line relationship.

6: Multiplex Directive Terminal Reference

The reference frequency is given by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals (Terminal Function 9~12, refer to the Description for Multiplex Directive Terminal Function of P2.0.00~P2.0.09 for more details)

7: Simple PLC Reference

The reference frequency is given by Simple PLC Function, the running frequency of the frequency inverter can be switched among 1~16 arbitrary frequency directives, the sources, hold time and acceleration & deceleration time of each frequency directive can be set through Function Code 3.0.03~P3.0.50.

8: PID Control Reference

The reference frequency is given by the frequency calculated from PID Control. When setting the frequency calculated from PID Control, it is required to setting related parameters of “PID Control Group” (P4.0.00~P4.0.20).

9: Communication Reference

The reference frequency is given by the principal computer through communication mode (Refer to Chapter VIII for more details)

10: Operation Result 1

11: Operation Result 2

12: Operation Result 3

13: Operation Result 4

The reference frequency is determined by the operation results after setting calculation of the internal operation module. Refer to the Description of Function Code P3.2.26~P3.2.39 for more details of the operation module. The operation results can be viewed through Function Code 9.0.46~P9.0.49.

Function code	Function Name	Setting scope	Factory Value
P0.0.05	Keyboard Frequency Reference	000.00~ maximum frequency	050.00

When the Function Code P0.0.04 or P0.1.01 is set to 0 or 1, the initial value of the reference frequency is given by this function code.

Chapter 6. Description of Parameters

Function code	Function Name	Setting scope	Factory Value
P0.0.06	Running Direction	0:Default Direction 1:Negation of Direction	0

The modification on this function code can realize the purpose of changing the motor steering without changing the connection of the motor and its role is equivalent to adjust any two lines of Motor U, V and W to realize the conversion of the steering direction of the motors. This function code is valid in any running control mode.

**Note: Reset to factory parameters, the running direction of the motor can restore to original state. It should be used with caution for occasions that forbid from changing the motor steering after completing the debugging of the system.**

Function code	Function Name	Setting scope	Factory Value
P0.0.07	Maximum frequency	050.00Hz~320.00Hz	050.00

The highest frequency refers to the maximum frequency that the frequency inverter allows to output.

When the analog input, PULS Impulse Input, multiplex directive input and simple PLC in E Series Frequency inverter are adopted as frequency source, each percentage is set based on the value given by corresponding function code.


**Note: the modification to this set value can change the data which takes the set value of this function code as calibration.**

Function code	Function Name	Setting scope	Factory Value
P0.0.08	Upper frequency	Lower frequency ~ highest frequency	050.00
P0.0.09	Lower frequency	000.00~ Upper frequency	000.00

The upper limit frequency is the Highest Frequency allowed to run set by the users. At P0.1.03=0, the set value of Function Code P0.0.08 determines the Highest Frequency that the frequency inverter allows to run.

The lower limit frequency is the minimum frequency allowed to run set by the users.

The relationship among Highest Frequency, Upper Limit Frequency and Lower Limit Frequency are shown in the figure below:



HF: Highest Frequency UF:Upper Frequency LF:Lower Frequency

Function code	Function Name	Setting scope	Factory Value
P0.0.10	Lower frequency operation mode	0:Running at lower limit frequency 1: Stop 2: Zero-speed Running	0

0: Run at lower limit frequency

When the reference frequency is less than the lower limit frequency (value set by P0.0.09), the frequency inverter runs at lower limit frequency

1: Stop

When the reference frequency is less than the lower limit frequency, the frequency inverter stops

2: Zero-speed Running

When the reference frequency is less than the lower limit frequency, the frequency inverter runs at 0Hz


**Note: when running at 0Hz, the frequency inverter can output a certain voltage, so special attention shall be paid when in use.**

Function code	Function Name	Setting scope	Factory Value
P0.0.11	Acceleration Time	0000.1s~6500.0s	Machine type
P0.0.12	Deceleration Time	0000.1s~6500.0s	Machine type

The acceleration time refers to time required to raise the frequency inverter from zero frequency to reference frequency of the acceleration and deceleration time (set by Function Code P0.1.07).

The deceleration time refers to time required to reduce the frequency inverter reference frequency of the acceleration and deceleration time to zero frequency.

See the Description of the Figure below:



## Chapter 6. Description of Parameters

Function code	Function Name	Setting scope	Factory Value
P0.0.13	Type of Motor0:Common motor	1:Variable frequency motor 2: Synchronous Motor (Invalid E100)	0

This function code is used to set the type of the load motor equipped with the frequency inverter.

0: Common motor

Because heat radiation effect of the common motor becomes worse when running at low speed, relative electronic thermal protection value should be adjusted properly; low speed compensating performance of motor protection mode is to lower protection threshold of motor overload when running frequency is less than 30Hz.

1: Variable frequency motor

Variable frequency motor uses forced air cooling, so that radiating effect is not affected by the rotating speed. Hence, it is not required to lower protection threshold when running at low speed.

2: Synchronous Motor

If it is synchronous motor, the control mode is set to closed-loop vector control (i.e. P0.0.02=2).

CDI-E100 Series can't support synchronous motor.

Function code	Function Name	Setting scope	Factory Value
P0.0.14	Motor rated power	0000.1kW~1000.0kW	Machine type
P0.0.15	Motor rated frequency	000.01Hz ~Highest frequency	050.00
P0.0.16	Motor rated voltage	0001V~2000V	Machine type
P0.0.17	Motor rated current	000.01~655.35	Machine type
P0.0.18	Motor Rated Rotating Speed	00001~65535	Machine type
P0.0.19	Stator resistance	00.001~65.535	Machine type
P0.0.20	Rotor resistance	00.001~65.535	Machine type
P0.0.21	Motor leakage inductance	000.01~655.35	Machine type
P0.0.22	Motor common inductance	0000.1~6553.5	Machine type
P0.0.23	Non-load current	000.01~Motor rated current	Machine type

The above parameters are intrinsic parameters of AC asynchronous motor, no matter what is adopted, V/F control or vector control, all have certain requirements to the parameters of the motor, especially for vector control, it requires that value of P0.0.19~P0.0.23 must be very close to the intrinsic parameters of the motor, the more the precision of the value is, the better the performance of the vector control is, therefore, when using the vector control, it is better to identify the motor through Function Code P0.0.24. If the identification cannot be made on site, according to the parameters provided by the motor manufacturer, it is to input them into the above corresponding function code.

Function code	Function Name	Setting scope	Factory Value
P0.0.24	Parameter Identification Control	00: No action 01: Static identification 02: Complete identification 11: Synchronous machine on-load identification (Invalid E100) 12: Synchronous machine non-load identification (Invalid E100)	00

Refer to 7.1.17 for more details (Parameter Identification)

### P0.1: Expansion Group

Function code	Function Name	Setting scope	Factory Value
P0.1.00	Option of Frequency Source	0:Frequency Source A 1:Frequency Source B 2:Frequency Source A+B 3:Frequency Source A-B 4: Max. Value of A & B 5:Min. Value of A & B 6:Standby Frequency Source 1 7:Standby Frequency Source 2 8: Switch of Terminal among the above 8 kinds	0

#### 0: Frequency Source A

The reference frequency is given by Frequency Source A (P0.0.04).

#### 1: Frequency Source B

The reference frequency is given by Frequency Source B (P0.1.01).

#### 2: Frequency Source A+B

The reference frequency is given by Frequency Source A+B.

#### 3: Frequency Source A-B

The reference frequency is given by A-B Frequency, if A-B Frequency is negative value; the frequency inverter runs in opposite direction

#### 4: Max. Value of A & B

The reference frequency is determined by the maximum value between Frequency Source A and B.

#### 5: Min. Value of A & B

The reference frequency is determined by the minimum value between Frequency Source A and B.

## Chapter 6. Description of Parameters

6: Standby Frequency Source 1

7: Standby Frequency Source 2

Standby Frequency Source 1 and Standby Frequency Source 2 are reserved by the manufacturer as frequency sources used for special occasions in future, so the users may ignore them as usual.

8: Switch of Terminal among the above 8 kinds

The reference frequency is switched among the above 8 kinds of frequency sources by selecting different composite state of the terminals. E Series Frequency inverter can set 3 kinds of frequency sources to choose the terminals (Terminal Function 18~20, refer to the instruction for Terminal Selection Function of Frequency Source P2.0.00~P2.0.09 for more details)

Function code	Function Name	Setting scope	Factory Value
P0.1.01	Option of Frequency Source B	0: Keyboard Reference (No Power-off Memory) 1: Keyboard Reference (Power-off Memory) 2: Keyboard Potentiometer Reference 3: External Terminal VF1 Reference 4: External Terminal VF2 Reference 5: PULS Reference (DI6) 6: Multiplex Directive Reference 7: Simple PLC Reference 8: PID Control Reference 9: Communication Reference 10: Operation Result 1 11: Operation Result 2 12: Operation Result 3 13: Operation Result 4	00

This function case has the same function with “Option of Frequency Source A” (P0.0.04), if it is needed to use, please refer to the setting method for Function Code P0.0.04 to set.

Function code	Function Name	Setting scope	Factory Value
P0.1.02	Adjustment Volume of: Frequency Source B at superposition	000%~150%	100

When the reference frequency of frequency inverter is given by Frequency Source A+B and Frequency Source A-B, it defaults A to main reference and B to auxiliary Reference. This function code determines the regulation size of Frequency Source B, which is the percentage relative to the scope of Frequency Source B (set by Function Code P0.2.01)

At P0.2.01=0, the frequency of Frequency Source B is regulated relative to Highest Frequency.

At P0.2.01=1, the frequency of Frequency Source B is regulated relative to frequency of Frequency Source A.

Function code	Function Name	Setting scope	Factory Value
P0.1.03	Upper Limit Frequency Source	0: Digital Reference (P0.0.08) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Reference 4:PULS Reference (DI6) 5: Communication Reference 6: Operation Result 1 7: Operation Result 2 8: Operation Result 3 9: Operation Result 4	0

This function code determines the source of the upper limit frequency.

0: Digital Reference (P0.0.08)

The upper limit frequency is determined by the value set by Function Code P0.0.08.

1: External Terminal VF1 Reference

2: External Terminal VF2 Reference

The upper limit frequency is given by the analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2). VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve of the input of VF1 and VF2 and the upper limit frequency, the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. The deviation between actual voltage and sampling voltage of the analog input terminal can be adjusted through Function Code P8.1.05~P8.1.12.

3: Multiplex Directive Terminal Reference

The upper limit frequency is set by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals (Terminal Function 9~12, refer to the Description for Multiplex Directive Terminal Function of P2.0.00~P2.0.09 for more details)

4: PULS Reference

The upper limit frequency is set by high-speed impulse frequency of digital input terminal DI6 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and upper limit frequency can be set through Function Code P2.0.23~P2.0.26, that is, linear relationship.

5: Communication Reference

The upper limit frequency is set by the upper computer through communication mode (refer to Chapter VIII for more details).

- 6: Operation Result 1
- 7: Operation Result 2
- 8: Operation Result 3
- 9: Operation Result 4

The upper limit frequency is determined by data after setting calculation of the internal operation module. Refer to the Description of Function Code P3.2.26~P3.2.39 for more details of the operation module. The operation results can be viewed through Function Code 9.0.46~P9.0.49.

**Note: the upper limit frequency cannot be set to negative value, but if it is the negative value, the upper limit frequency is invalid.**

Function code	Function Name	Setting scope	Factory Value
P0.1.04	Upper Limit Frequency Offset	000.00~Highest Frequency	000.00

The set value of this function code is the offset of the upper frequency, and the superposition of this offset and upper frequency set by Function Code P0.1.03 is adopted as final set value of upper frequency.

Function code	Function Name	Setting scope	Factory Value
P0.1.05	Keyboard Reference frequency Shut-down Memory Selection	0: No Memory 1: Memory	0

0: No Memory

After the frequency inverter stops, the reference frequency is reset to the value given by Function Code P0.0.05, and the frequency allowance, which is conducted through Key ▲ & ▼ on the keyboard or Terminal UP/DOWN, is cleared .

1: Memory

After the frequency inverter stops, the reference frequency is the frequency set before stop, and the frequency allowance, which is conducted through Key ▲ & ▼ on the keyboard or Terminal UP/DOWN, is saved.

**Note: this function code is valid only when the frequency source is set by the keyboard.**

Function code	Function Name	Setting scope	Factory Value
P0.1.06	Keyboard Reference frequency Action Benchmark at running	0: Running Frequency 1: Reference frequency	0

When this function code is adopted to determine the action of Key ▲ & ▼ on the keyboard or Terminal UP/DOWN, it is to confirm what a kind of mode is adopted to correct the frequency and the increase & decrease shall be done on the basis of running frequency or reference frequency .

0: Running Frequency

The regulation shall be made on the basis of running frequency



1: Reference frequency

The regulation shall be made on the basis of reference frequency

The difference between two settings is obvious when the frequency inverter is in the process of acceleration and deceleration, namely, when the running frequency differs from the reference frequency, different Option of parameters leads to great difference.

**Note: this function code is valid only when the frequency source is set by the keyboard.**

Function code	Function Name	Setting scope	Factory Value
P0.1.07	Benchmark frequency of accelerating and Deceleration time	0: Highest Frequency 1: Reference frequency 2: 100Hz	0

0: Highest Frequency

The acceleration and deceleration time refers to the time from frequency 0 to highest frequency, and it can change with the change of the highest frequency at this time.

1: Reference frequency

The acceleration and deceleration time refers to the time from frequency 0 to highest frequency, and it can change with the change of the reference frequency at this time.

2: 100Hz

The acceleration and deceleration time refers to the time from frequency 0 to 100Hz, and it is a fixed value at this time.

**Note: the jogging acceleration and deceleration time is also subject to its control.**

Function code	Function Name	Setting scope	Factory Value
P0.1.08	Jogging running frequency	000.00~Highest Frequency	002.00
P0.1.09	Jogging Acceleration time	0000.0s~6500.0s	0020.0
P0.1.10	Jogging Deceleration time	0000.0s~6500.0s	0020.0

The function codes above define the reference frequency and acceleration and deceleration time when the frequency inverter is at jogging running.

Function code	Function Name	Setting scope	Factory Value
P0.1.11	Acceleration time 2	0000.0s~6500.0s	Machine type
P0.1.12	Deceleration time 2	0000.0s~6500.0s	Machine type
P0.1.13	Acceleration time 3	0000.0s~6500.0s	Machine type
P0.1.14	Deceleration time 3	0000.0s~6500.0s	Machine type
P0.1.15	Acceleration time 4	0000.0s~6500.0s	Machine type
P0.1.16	Deceleration time 4	0000.0s~6500.0s	Machine type

## Chapter 6. Description of Parameters

The function codes above have the same definitions with P0.0.11 and P0.0.12; refer to the Description of P0.0.11 and P0.0.12 for more details

E Series Frequency inverter totally provides 4 groups of acceleration and deceleration time of the straight line, which can switch among 4 groups of acceleration and deceleration time through different composite state of acceleration and deceleration time selection terminals. It can set 2 acceleration and deceleration time selection terminals (terminal function 16~17, refer to the Description of Code P2.0.00~P2.0.09 for Acceleration and Deceleration Time Selection Terminal Function of Function for more details)

Function code	Function Name	Setting scope	Factory Value
P0.1.17	Frequency Switch Point between Acceleration time 1 and Acceleration time 2	000.00Hz~Highest Frequency	000.00
P0.1.18	Frequency Switch Point between Deceleration time 1 and Deceleration time 2	000.00Hz~Highest Frequency	000.00

The function codes above are adopted to set the frequency of the switch point of acceleration and deceleration time 1 and acceleration and deceleration time 2. When the running frequency of the frequency inverter is less than the set value of these two function codes, the acceleration and deceleration time 2 is adopted, otherwise the acceleration and deceleration time 1 is adopted.

**Note: when using this function, the acceleration and deceleration time 1 and acceleration and deceleration time 2 cannot be set to 0s.**

Function code	Function Name	Setting scope	Factory Value
P0.1.19	Acceleration and Deceleration Mode	0: Straight Line 1: Curve S 1 2: Curve S 2	0

### 0: Acceleration and Deceleration of the Straight Line


The output frequency increases or decreases by the straight line. E Series Frequency inverter provides 4 groups of acceleration and deceleration time of the straight line, namely, P0.0.11 and P0.0.12, P0.1.11 and P0.1.12, P0.1.13 and P0.1.14 and P0.1.15 and P0.1.16. The switch can be selected through different composite state of acceleration and deceleration time selection terminals.

#### 1: Curve S 1

The output frequency increases or decreases by Curve S 1. Curve S 1 is used for occasions required for gradual start or stop. Parameter P0.1.20 and P0.1.21 respectively defines the time scale of starting point and ending point of Curve S 1.


#### 2: Curve S 2

In the Curve S 2, the rated frequency of the motor is always the inflection point of Curve S, as shown in the figure below. Generally, it applies for the occasions that the high-speed area above the rated frequency requires to rapidly accelerate and decelerate.



Function code	Function Name	Setting scope	Factory Value
P0.1.20	Percentage of Starting Phase of Curve S	000.0%~100.0%	030.0
P0.1.21	Percentage of Ending Phase of Curve S	000.0%~100.0%	030.0

Parameter P0.1.20 and P0.1.21 respectively defines the time scale of starting point and ending point of Curve S 1. These two parameters need to meet  $P0.1.20 + P0.1.21 \leq 100.0\%$ , refer to the Description for the figure below:




T1 is the value set by Function Code P0.1.20, the slope of the output frequency gradually increases from zero within this period of time.

T2 is the value set by Function Code P0.1.21, the slope of the output frequency gradually decreases to zero within this period of time.

Within the time between T1 and T2, the change on slope of the output frequency keeps constant.

Function code	Function Name	Setting scope	Factory Value
P0.1.22	Hopping Frequency 1	000.00Hz~Highest Frequency	000.00
P0.1.23	Hopping Frequency 2	000.00Hz~Highest Frequency	000.00
P0.1.24	Hopping Frequency scope	000.00Hz~Highest Frequency	000.00

The hopping frequency function is set so that running frequency of the frequency inverter can avoid load resonance band of the driving system. E Series Frequency inverter can set two hopping frequency points, after setting, even the reference frequency is within load resonance band, the output frequency of the frequency inverter will also be automatically adjusted out of load resonance band to avoid running on resonant frequency, refer to the Description for the figure below:



Function code	Function Name	Setting scope	Factory Value
P0.1.25	Jogging Priority	0:Invalid 1:Valid	0

This function code is used to set whether the priority of the jogging function is the highest. The jogging function includes Keyboard Jogging Function and Terminal Jogging Function.

When at P0.1.25=1, if the jogging command occurs in the running process, the switch of frequency inverter is the jogging running state. The target frequency is the jogging frequency and the acceleration and deceleration time is the jogging acceleration and deceleration time.

Function code	Function Name	Setting scope	Factory Value
P0.1.26	Type of Encoder	0: ABZ Incremental Encoder 1: UVW Incremental Encoder (E100 Invalid) 2: Rotary Transformer (E100Invalid) 3~9: Reservation 10: Distance Control (Open Collector)	0

This function code is used to set the selected type of the Encoder.

CDI-E180 Series Frequency inverter supports various types of the encoders. Different encoder needs to configure different encoder expansion card, when in use, the correct encoder expansion card shall be selected and ordered. The synchronous motor may select any one of three types of the encoders in the table above, while the asynchronous motor generally selects and uses ABZ incremental encoder and rotary transformer.

After completing the installation of the encoder, the value of Function Code P0.1.27 shall be correctly set based on actual conditions, or the frequency inverter may not run normally.

**Note: when the open collector-type encoder is adopted to realize the distance control, the function code must be set to P0.1.26=10.**

Function code	Function Name	Setting scope	Factory Value
P0.1.27	Line Number of Encoder	00001~65535	01024

This function code is used for the number of pulses per revolution to set ABZ or UVW incremental encoder.

In closed-type vector control mode, the line number of the encoder must be correctly set, or the frequency inverter will not run normally.

Function code	Function Name	Setting scope	Factory Value
P0.1.28	Phase sequence of ABZ Incremental Encoder	0: Forward Direction 1: Reverse Direction	0

This function code is only valid for ABZ incremental encoder, namely, it is valid at P0.1.26=0, and used to set the phase sequence of ABZ Incremental Encoder AB Signal. It is valid for synchronous motor and asynchronous motor, when the asynchronous motor is completely tuned or the synchronous motor is tuned, the AB Phase Sequence is acquired for ABZ Encoder.

Function code	Function Name	Setting scope	Factory Value
P0.1.29	Encoder Disconnection Testing Time	00: No action 00.1s~10.0s	00.0

When the detection time of the encoder disconnection fault is set to 00.0, the frequency inverter can't detect the disconnection fault of encoder. When the frequency inverter has detected the disconnection fault and the duration is over the time set by Function Code P0.1.29, the frequency inverter gives an alarm of Fault Err25.

Function code	Function Name	Setting scope	Factory Value
P0.1.30	Stator Resistance of Synchronous Machine	00.001~65.535	Machine type
P0.1.31	Back EMF of Synchronous Machine	0000.0~6553.5	Machine type

The above parameters are intrinsic parameters of synchronous motor, the load motor equipped with the frequency inverter refers to synchronous motor, it requires that value of P0.1.30~P0.1.31 must be very close to the intrinsic parameters of the motor, the more the precision of the value is, the better the performance of the vector control is. The motor parameters are identified through Function Code P0.0.24. If the identification cannot be made on site, according to the parameters provided by the motor manufacturer, it is to input them into the above corresponding function code.

Function code	Function Name	Setting scope	Factory Value
P0.1.32	UVW Phase Sequence	0: Forward Direction 1: Reverse Direction	Machine type
P0.1.33	UVW Encoder Angle	000.0~359.9	Machine type

The above function codes are only valid when the synchronous motor adopts UVW incremental encoder.

These two parameters are more important for the running of the synchronous motor, so it is better to acquire these two parameters of the synchronous motor through identification by Function Code P0.0.24 after completing initial installation.

Function code	Function Name	Setting scope	Factory Value
P0.1.34	Pole-pairs of Rotary Transformer	00001~65535	Machine type

When the encoder is rotary transformer (i.e. P0.1.26=2), this function code is used to set its pole-pairs.

## 6.2 Group P1 - Motor Control Parameter

### Group P1.0 - Basic Group

Function code	Function Name	Setting scope	Factory Value
P1.0.00	V/F Curve Mode	0: Straight Line 1: Multi-point Broken Line 2: Square V/F Curve 1 3: Square V/F Curve 2 4: Square V/F Curve 3	0

0: Straight Line V/F

Applicable for common constant torque load

1: Multi-point Broken Line

V/F Relation Curve of any broken lines can be acquired through setting Function Code P1.1.00~P1.1.05.

2: Square V/F


Applicable for centrifugal loads of fans, water pumps, etc.

3: Square V/F Curve 2

4: Square V/F Curve 3

Refer to relation curve between straight line V/F and square V/F

Each curve is shown in the figure below:



Function code	Function Name	Setting scope	Factory Value
P1.0.01	Torque Boost	00.0% (Automatic Torque Boost) 00.1%~30.0%	04.0
P1.0.02	Cutoff Frequency of Torque Boost	000.00Hz~Highest Frequency	050.00

In order to compensate the property of controlling the lower frequency torque by V/F, the boosting compensation is conducted for output voltage in low-frequency working area. Under normal circumstances, the factory value can meet the requirements, if the compensation is too great, the current fault may occur. When the load is heavier and the low-frequency torque of the motor is not enough, it suggests increasing this parameter. When the load is lighter, this parameter can be reduced.

The frequency inverter is automatic torque boost when the torque boost is set at 00.0%, the frequency inverter can automatically calculate the required torque boost value based on the parameters of the motor as stator, resistance, etc.

Torque Boost Cut-off Frequency: when the output frequency is below this set value, the torque boost is valid, in case of exceeding this set value, the torque boost is invalid

Function code	Function Name	Setting scope	Factory Value
P1.0.03	V/F Slip Compensation Gain	000.0%~200.0%	000.0


This function code is only valid for asynchronous motor and the percentage relative to rated slip of motor. When it is the slip that is compensated by the motor for rated load, the rated slip of the motor can be calculated and acquired based on rated frequency of the motor and rated speed. V/F Slip Compensation can compensate asynchronous motor for the speed deviation of the motor occurred from load increase so as to make the speed able to basically keep stable.

Function code	Function Name	Setting scope	Factory Value
P1.0.04	Velocity Loop Proportional Gain 1	001~100	030
P1.0.05	Velocity Circulation Integral Time 1	00.01~10.00	00.50
P1.0.06	Switching Frequency 1	000.00Hz~P1.0.09	005.00
P1.0.07	Velocity Loop Proportional Gain 2	001~100	020
P1.0.08	Velocity Circulation Integral Time 2	00.01~10.00	01.00
P1.0.09	Switching Frequency 2	P1.0.06~Highest Frequency	010.00

The above parameters can realize that the frequency inverter may select the parameters of different Velocity Loop PI at different running frequency. When the running frequency is less than the switch frequency 1(P1.0.06), the parameters of Velocity Loop PI are adjusted to P1.0.04 and P1.0.05.

When the running frequency is greater that the switch frequency 2 (P1.0.09), the parameters of Velocity Loop are P1.0.07 and P1.0.08.

The parameters of Velocity Loop PI between switch frequency 1 and switch frequency 2 are the linear switch of two groups of PI parameters.



The increase of proportional gain P can speed up the dynamic response of the system, but if P is too great, it may easily vibrate. The decrease of integration time I can speed up the dynamic response of the system, but if I is too small, it may have large overshoot and easily vibrate. Generally, the proportional gain P is first adjusted so as to increase P as possible under the preconditions of ensuring non-vibration of the system, and then it is to adjust the integration time I to make the system not only have rapid response property, but small overshoot.

Function code	Function name	Setting scope	Factory Value
P1.0.10	Start Mode	0: Direct Start 1: Speed Tracking Mode 2: Brake and Restart	0

0: Direct Start

The frequency inverter starts running from start frequency.

1: Rotating Speed before Start

The frequency inverter shall first judge the rotating speed and direction of the motor and then track down the start frequency of motor, the rotating motor smoothly starts without any surge. It is applicable for momentary interruption restart of the high inertia loads. In order to ensure the performance of rotating speed before start, accurate setting of the motor parameters is required.

2: Brake before Start

First conduct DC braking and then start running from start frequency.

Function code	Function name	Setting scope	Factory Value
P1.0.11	Speed Tracking Mode	0: Start from Shutdown Frequency 1: Start from Zero Speed 2: Start from Highest Frequency	0

0: Start from Stop Frequency

Track down from the frequency at the moment of stop and adopt this method as usual.

1: Start from Zero Speed

Track up from zero frequency and adopt this method when start after longer stop time.

2: Start from Highest Frequency

Track down from highest frequency

**Note: this function code is only valid when the start mode is speed tracking start (i.e. P1.0.10=1)**

Function code	Function name	Setting scope	Factory Value
P1.0.12	Start Frequency	00.00Hz~10.00Hz	00.00
P1.0.13	Hold Time of Start Frequency	000.0s~100.0s	000.0

Start Frequency: refer to running frequency when the frequency inverter starts.

In order to ensure that the motor has a certain start torque, proper start frequency shall be given. If the setting is too great, the overcurrent may occur. When the reference frequency is less than start frequency, the frequency inverter cannot start and is at ready mode (when jogging, it is not subject to the impact of start frequency).

Hold Time of Start Frequency: refer to the running time of starting the frequency during the process of start.



Function code	Function name	Setting scope	Factory Value
P1.0.14	Starting DC Brake Current	000%~100%	000
P1.0.15	Starting DC Brake Time	000.0s~100.0s	000.0

Starting DC Brake Current: refer to the output current in the process of starting DC brake, which is the percentage relative to rated current of the motor, the larger the starting DC brake current, the greater the braking force is.

Starting DC Brake Time: refer to duration time of outputting the start DC brake current in the process of starting the frequency inverter.

Function code	Function name	Setting scope	Factory Value
P1.0.16	Shutdown mode	0: Reducing speed to shut down 1: Shut down freely	0

0: Stop by Speed Deceleration

After the stop command is effective, the frequency inverter reduces the output frequency based on deceleration time and stops after the frequency is reduced to 0.

1: Free Stop

After the stop command is effective, the frequency inverter immediately stops outputting and the motor stops freely based on mechanical inertia at this time.

Function code	Function name	Setting scope	Factory Value
P1.0.17	Stop DC Braking Initial Frequency	000.00Hz~Highest Frequency	000.00
P1.0.18	Stop DC Braking Hold Time	000.0s~100.0s	000.0
P1.0.19	Stop DC Braking Current	000%~100%	000
P1.0.20	Stop DC Braking Time	000.0s~100.0s	000.0

Start Frequency of Stop DC Brake: when the output frequency is reduced to this frequency in the stopping process by reducing the speed, after waiting for the time set by P1.0.18, it is to start stop DC brake process.

Hold Time of Stop DC Brake: when the output frequency is reduced to the start frequency of stop DC brake, the frequency inverter first stops outputting for a period and then restarts DC brake process so as to prevent the faults as overcurrent arising from start DC brake at higher speed.

Stop DC Brake Current: refer to the output current in the process of stop DC brake, which is the percentage relative to rated current of the motor. The higher the stop DC brake current is, the larger the brake force is.

Stop DC Brake Time: refer to the duration of outputting the stop DC brake value in the stop process of the frequency inverter. When the stop DC brake time is set at 000.0, the stop DC brake function is valid.

## Chapter 6 Description of Parameters

Function code	Function name	Setting scope	Factory Value
P1.0.21	Braking Use Rate	000%~100%	100

This function code is only valid for the frequency inverter of the built-in brake unit. CDI-E100 Series has complete built-in brake units, but CDI-E180 Series 15Kw and below has built-in brake units.

As for duty ratio of adjusting the brake units, the higher the brake usage rate is, the higher the duty ratio of the brake unit action is and the stronger the brake effect is, but the bus voltage fluctuation of the frequency inverter is greater in the brake process.

Function code	Function name	Setting scope	Factory Value
P1.0.22	Carrier Frequency	0.50kHz~16.0kHz	06.0

This function code is used to regulate the carrier frequency of the frequency inverter. The regulation of the carrier frequency can lower the noise of the motor and reduce the line-to-ground leakage current and the interference arising from the frequency inverter. When the carrier frequency is lower, the high-order harmonic components of output current increase, the losses of motor increase and the temperature of the motor rises. When the carrier frequency is higher, the losses of motor are reduced and the temperature rise of the motor decreases, but the losses of the frequency inverter increase and the temperature of the frequency inverter rise, so the interference is enhanced.

The regulation of the carrier frequency can influence the following performance:

Carrier Frequency	Low → High
Noise of Motor	Large → Small
Output Current Waveform	Bad → Good
Temperature Rise of Motor	High → Low
Temperature Rise of Frequency inverter	Low → High
Current Leakage	Small → Large
External Radiation Interference	Small → Large

Function code	Function name	Setting scope	Factory Value
P1.0.23	Fan Control	0: Rotate at running 1: Continuous Running 2: Control based on Temperature	0

Refer to action mode used for selecting the cooling fan.

When at P1.0.23=0, the fans of the frequency inverter run at running state and can't run at stop state.

When at P1.0.23=1, the fans keep running after power on.

When at P1.0.23=2, the fans run when the temperature of the radiator is higher than 35°C, but can't run when lower than 35°C.

Function code	Function name	Setting scope	Factory Value
P1.0.24	Motor Overload Protection	0: Prohibition 1 :Curve 1 2 :Curve 2 3 :Curve 3	1
P1.0.25	Motor Overload Protection Level	00.20~10.00	01.00
P1.0.26	Motor Overload Alarm System	050%~100%	080


When at P1.0.24=0, the frequency inverter hasn't had overload protection function to the motor, it suggests heating the relay between frequency inverter and motor.

When at P1.0.24=1,2 or 3, the frequency inverter shall judge whether the motor is overload or not based on inverse-time characteristic curve of the overload protection of the motor.

The users need to correctly set the value of P1.0.25 based on actual overload capability and load conditions of the motor, if the set value is too small, it is easy to report the motor overload fault (Err10) , while the set value is too large, the motor may have the risk of being burnt, especially for the conditions that the rated current of the frequency inverter is larger than the rated current of the motor. When at P1.0.25=01.00, it means that the motor overload protection level is 100% rated current of the motor.

Function Code P1.0.26 is used to define when the early alarm is given before overload fault protection of the motor. The larger the value is, the smaller the early alarm lead is. When the accumulative output current of the frequency inverter is larger than product of multiplying overload inverse time curve by P1.0.26, the multi-functional output terminal of the frequency inverter outputs Signal ON, and the corresponding multi-functional output terminal is overload pre-alarm of the motor(6).

The overload inverse-time characteristic curve of E Series Frequency inverter is shown in the figure below:




Overload inverse-time characteristic curve

**Group P1.1 - Expansion Group**

Function code	Function name	Setting scope	Factory Value
P1.1.00	Broken Line V/F Point 1 Frequency	000.00Hz~P1.1.02	000.00
P1.1.01	Broken Line V/F Point 1 Voltage	000.0%~100.0%	000.0
P1.1.02	Broken Line V/F Point 2 Frequency	P1.1.00~P1.1.04	000.00
P1.1.03	Broken Line V/F Point 2 Voltage	000.0%~100.0%	000.0
P1.1.04	Broken Line V/F Point 3 Frequency	P1.1.02~Motor rated frequency	000.00
P1.1.05	Broken Line V/F Point 3 Voltage	000.0%~100.0%	000.0

The above functions define V/F Curve with multi-point broken line, and the voltage of the above broken points is the percentage relative to the rated voltage of the motor. V/F Curve with multi-point broken line is given based on the load characteristics of the motor, but attention shall be paid that the relationship between three voltage points and frequency points must meet:  $P1.1.00 < P1.1.02 < P1.1.04$ ,  $P1.1.01 < P1.1.03 < P1.1.05$ , refer to the Description in the figure below:



**Note: the voltage cannot be set too large when at low frequency, or the frequency inverter may have overcurrent fault or its motor may be burnt.**

Function code	Function name	Setting scope	Factory Value
P1.1.06	V/F Overexcited Gain	000~200	064

In the deceleration process of the frequency inverter, the pumping voltage can make DC bus voltage rise, the overexcited control can restrain the rise of DC bus voltage to avoid occurrence of overvoltage fault. The larger the overexcited gain is, the stronger the restraint effect is, but if the overexcited gain is too large, it is easy to lead to increase of the output current, even overcurrent fault. As for the occasions where the rise of DC bus voltage is not great or have brake resistance, it suggests setting the overexcited gain at 0.

**Note: this function code is only valid when the control mode is V/F Control (i.e. P0.0.02=0).**

Function code	Function name	Setting scope	Factory Value
P1.1.07	Vector Control Torque Upper Frequency	0: Digital Reference (P1.1.08) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Terminal Reference 4: PULS Reference (DI6) 5: Communication Reference 6: MIN (VF1, VF2) 7: MAX (VF1, VF2) 8: Operation Result 1 9: Operation Result 2 10: Standby Torque Source 3 11: Standby Torque Source 4	0

#### 0: Digital Reference (P1.1.08)

The upper limit of the vector control torque is given by the value at based on Function Code P1.1.08.

#### 1: External Terminal VF1 Reference

#### 2: External Terminal VF2 Reference

The vector control torque is given by the analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2). VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve between the input of VF1 and VF2 and the upper limit of torque, the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. The deviation between actual voltage and sampling voltage of the analog input terminal can be adjusted through Function Code P8.1.05~P8.1.12.

#### 3: Multiplex Directive Terminal Reference

The vector control is given by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals (Terminal Function 9~12, refer to the Description for Multiplex Directive Terminal Function of P2.0.00~P2.0.09 for more details)

#### 4: PULS Reference (DI6)

The vector control is set by high-speed impulse frequency of digital input terminal DI6 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and torque upper limit value can be set through Function Code P2.0.23~P2.0.26, that is, linear relationship.

#### 5: Communication Reference

The upper limit of vector control torque is set by the upper computer through communication mode (refer to Chapter VIII for more details).

6: MIN (VF1, VF2)

The upper limit of vector control torque is set by the input value of VF1 and VF2, whichever is lower.

7: MAX (VF1, VF2)

The upper limit of vector control torque is set by the input value of VF1 and VF2, whichever is larger.

8: Operation Result 1

9: Operation Result 2

10: Operation Result 3

11: Operation Result 4

**Note: when the upper limit of the vector control torque is set by VF1 &VF2, multiplex directive, PULSE, communication and operation results, the corresponding range is the value set by P1.1.08.**

Function code	Function name	Setting scope	Factory Value
P1.1.08	Torque Upper Limit Reference	000.0%~200%	150.0

When at P1.1.07=0, the setting value of this function code determines the upper limit of the vector control torque, which is the percentage relative to the rated torque of the motor.

Function code	Function name	Setting scope	Factory Value
P1.1.09	Inversion Control Enable	0: Allow 1: Prohibit	0

This function code is used to set whether the frequency inverter is allowed to run at reverse state.

When at P1.1.09=0, the frequency inverter is allowed to run at reversal state.

When at P1.1.09=1, the frequency inverter is prohibited to run at reversal state, which is mainly used for the occasions that the load is unable to reverse.

**Note: the director of this function code is defined by the set value relative to running direction (P0.0.06)**

Function code	Function name	Setting scope	Factory Value
P1.1.10	Forward and Reverse Dead Time	0000.0s~3000.0s	0000.0

This function code is used to set the duration time of outputting OHZ when the frequency inverter is in the process of forward and reverse switch

Function code	Function name	Setting scope	Factory Value
P1.1.11	Power-on Running Selection	0: Running 1: Not Running	0

This function code is used to set when the frequency inverter runs in response to valid running command at the moment of power-on.

When at P1.1.11=0, the frequency inverter directly responds to the running

When at P1.1.11=1, frequency inverter can't respond to the running. It cannot run until the running command is valid again after it is cancelled.

Function code	Function name	Setting scope	Factory Value
P1.1.12	Droop Control	00.00Hz~10.00Hz	00.00

When more than one motor drive the same load, the uneven distribution of the load may occur. The droop control decreases the output frequency along the increase of the load so as to realize even load of more than one motor. The set value of this function code is the frequency value declined at rated load.

Function code	Function name	Setting scope	Factory Value
P1.1.13	Speed/Torque Control Mode Selection	0: Speed Control 1: Torque Control	0

This function code is used to set what kind of running mode of the frequency inverter is adopted, speed control mode or torque control mode.

When at P1.1.13=0, the speed control mode is adopted

When at P1.1.13=1, the torque control mode is adopted

Function code	Function name	Setting scope	Factory Value
P1.1.14	Torque Reference Source	0: Digital Reference (P1.1.15) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference 3: Multiplex Directive Terminal Reference 4: PULS Reference (DI6) 5: Communication Reference 6: MIN (VF1,VF2) 7: MAX (VF1,VF2) 8: Operation Result 1 9: Operation Result 2 10: Operation Result 3 11: Operation Result 4 12: Standby Torque Source 1 13: Standby Torque Source 2	00

0: Digital Reference (P1.1.15)

The upper limit of the vector control torque is given by the value at based on Function Code P1.1.15.

1: External Terminal VF1 Reference

2: External Terminal VF2 Reference

The torque Reference is given by the analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2). VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve between the input of VF1 and VF2 and the torque set value, the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. The deviation between actual voltage and sampling voltage of the analog input terminal can be adjusted through Function Code P8.1.05~P8.1.12.

3: Multiplex Directive Terminal Reference

The torque reference is given by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals (Terminal Function 9~12, refer to the Description for Multiplex Directive Terminal Function of P2.0.00~P2.0.09 for more details)

4: PULS Reference (DI6)

The torque reference is given by high-speed impulse frequency of digital input terminal DI6 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and torque upper limit value can be set through Function Code P2.0.23~P2.0.26, that is, line relationship.

5: Communication Reference

The torque reference is given by the upper computer through communication mode (refer to Chapter VIII for more details).

6: MIN (VF1, VF2)

The torque reference is given by the input value of VF1 and VF2, whichever is lower.

7: MAX (VF1, VF2)

The torque reference is given by the input value of VF1 and VF2, whichever is larger.

8: Operation Result 1

9: Operation Result 2

10: Operation Result 3

11: Operation Result 4

The torque reference is determined by the operation results after setting calculation of the internal operation module. Refer to the Description for Function Code P3.2.26~P3.2.39 for more details of the operation module. The operation results can be viewed through Function Code 9.0.46~P9.0.49.



12: Standby Torque Source 1

13: Standby Torque Source 2

Standby Torque Source 1 and Standby Torque Source 2 are reserved by the manufacturer as frequency sources used for special occasions in future, so the users may ignore them as usual.

**Note: when the torque is set by VF1 & VF2, multiplex directive, PULSE, communication and operation results, the corresponding range is the value set by P1.1.15.**

Function code	Function name	Setting scope	Factory Value
P1.1.15	Torque Digital Reference	-200.0%~200.0%	150.0

When at P1.1.14=0, the setting value of this function code determines the torque reference, which is the percentage relative to the rated torque of the motor.

Function code	Function name	Setting scope	Factory Value
P1.1.16	Torque Control FWD Frequency Limit	000.00Hz~Highest Frequency	050.00
P1.1.17	Torque Control REV Frequency Limit	000.00Hz~Highest Frequency	050.00

This function code is used to set the highest frequency in forward and reverse running when the frequency inverter runs in torque control mode (i.e. P1.1.13=1).

Function code	Function name	Setting scope	Factory Value
P1.1.18	Torque Acceleration Time	0000.0s~6500.0s	0000.0
P1.1.19	Torque Deceleration Time	0000.0s~6500.0s	0000.0

These two function codes are used to set the acceleration time of the torque rise and the deceleration time of the torque decline when running in torque control mode (i.e. P1.1.13=1). They may be set to 0 for the occasions requiring rapid response.

### 6.3 Group P2 - Input/Output Terminal Function

#### Group P2.0 - Basic Group

The input and output terminals of CDI-E100 Series and E180 Series are configured as below:

CDI-E100 Series	CDI-E180 Series
6-way digital input terminal (DI1~DI6), in which DI6 can connect high-speed Impulse Input	6-way digital input terminal (DI1~DI6), in which DI6 can connect high-speed Impulse Input. Additional 4-way digital input terminal (DI7~DI10) is added through externally connected I/O expansion card
2-way Analog Input (VF1 & VF2)	2-way Analog Input (VF1 & VF2)
2-way Analog Input (FM1 & FM2)	2-way Analog Input (FM1 & FM2)
One-way Collector Output (YO) (Use Terminal YO/FMP as YO)	One-way Collector Output (YO) (Use Terminal YO/FMP as YO) can add additional 2-way (YO1 and YO2) through externally connected I/O expansion card
Two-way Relay Output (T1 & T2)	Two-way Relay Output (T1 & T2)
One-way Impulse Output Terminal(FMP) (Use Terminal YO/FMPas FMP)	One-way Impulse Output Terminal (FMP) (Use Terminal YO/FMPas FMP)
<b>Note: YO/FMP Terminal is common terminal of YO and FMP, but only one can be used at the same time (select through function code P2.1.20).</b>	

Function code	Function Name	Setting scope	Factory Value
P2.0.00	DI1 Terminal Function	0~59	01 ( FWD Running)
P2.0.01	DI2 Terminal Function	0~59	04 (REV Jogging)
P2.0.02	DI3 Terminal Function	0~59	09 (Multiplex Directive Terminal 1)
P2.0.03	DI4 Terminal Function	0~59	12 (Multiplex Directive Terminal 4)
P2.0.04	DI5 Terminal Function	0~59	13 (Fault Reset)
P2.0.05	DI6 Terminal Function	0~59	00
P2.0.06	DI7 Terminal Function	0~59	00
P2.0.07	DI8 Terminal Function	0~59	00
P2.0.08	DI9 Terminal Function	0~59	00
P2.0.09	DI10 Terminal Function	0~59	00

The above function codes are used to set the functions of digital input terminals and the functions for option are shown in the table below:

Setting value	Function	Description
0	No Function	Define the not in-service terminals as “Unused” to prevent malfunctions.
1	Forward Running (FWD)	Control FWD and REV of the frequency inverter through these two terminals.
2	Reverse Running (REV)	
3	3-line Running	Control Confirm that the running mode of the frequency inverter is three-line control mode through this terminal. Refer to the Description for Terminal Control in 7.1.1.
4	Forward Jogging	Control FWD Jogging and REV Jogging through of the frequency inverter through these two terminals and be valid for any running control mode. The running frequency and acceleration & deceleration time of the inching refer to the description for P0.1.08, P0.1.09 and P0.1.10 .
5	Reverse Jogging	
6	Terminal UP	When the reference frequency is given by the keyboard, increase or decreases the reference frequency through these two terminals.
7	Terminal DOWN	
8	Free Stop	When the terminal state is valid, the frequency inverter is blocked to output, the shut-down of the motor is not subject to the control of the frequency inverter at this moment. This mode has same meaning of free stop described in P1.0.16.
9	Multiplex Directive Terminal 1	Realize the references of 16 kinds of the directive through 16 kinds of states of these four terminals.
10	Multiplex Directive Terminal 2	
11	Multiplex Directive Terminal 3	
12	Multiplex Directive Terminal 4	
13	Fault Reset (RESET)	Realize remote fault reset through this terminal and have same function with RESET Key on Keyboard.
14	Running Pause	When this terminal state is valid, the terminal slows down and stops, but all running parameter are memorized. When this terminal state is invalid, the frequency inverter is resets to running state before stop.
15	External Fault Input	When this terminal state is valid, the frequency inverter gives an alarm of Err13, and then the fault is handled based on fault protection action mode.
16	Acceleration & Deceleration Time Selection Terminal 1	Realize the switch among four groups of straight acceleration and deceleration time, refer to Appendix 3 for more details.
17	Acceleration & Deceleration Time Selection Terminal 2	
18	Frequency Source Selection Terminal 1	When at P0.1.00=8, the functions of these terminals are valid. Realize the switch among 8 kinds of frequency sources through 8 kinds of state of these three terminals.
19	Frequency Source Selection Terminal 2	
20	Frequency Source Selection Terminal 3	
21	Running Command Selection Terminal 1	Realize the switch among running control modes through close/open state of these two terminals
22	Running Command Selection Terminal 2	

Setting value	Function	Description
23	UP/DOWN Reference Reset	When the reference frequency is given by the keyboard, this terminal can remove the frequency allowance adjusted by Terminal UP/DOWN or Key▲ & ▼ on Keyboard to reset the reference frequency to the value given by P0.0.05.
24	Prohibition of Acceleration & Deceleration	When this terminal state is valid, the output frequency of the frequency inverter is not impacted by the signal (except for stop command)
25	PID Pause	PID Control fails temporarily, the frequency inverter maintains the running of current output frequency and can't conduct PID Regulation of the frequency source.
26	PLC State Reset	During executing process of PLC, the frequency inverter is reset the frequency inverter to initial state of Simple PLC through this terminal
27	Wobblulating Pause	The frequency inverter outputs in central frequency and the wobblulating function suspends.
28	Counter Input	Be used for defining the output terminal of count impulse. If it is high-speed pulse, connect Terminal DI6.
29	Counter Reset	Conduct reset handling to counter.
30	Length Counting Input	Be used for defining the output terminal of length count impulse. If it is high-speed pulse, connect Terminal DI6.
31	Length Reset	Conduct reset handling to length.
32	Torque Control Prohibition	Prohibit the frequency inverter from running in torque control mode, and the frequency inverter only can run in speed control mode.
33	PULS Impulse Input	Define PULS Impulse Input Terminal and connect Terminal DI6.
34	Immediate DC Brake	When this terminal state is valid, the frequency inverter is directly switched to DC Switch State.
35	External Fault Normally-closed Input	When this terminal state is invalid, the frequency inverter gives an alarm of Err13, and then the fault is handled based on fault protection action mode.
36	Frequency Modification Enable	When this terminal state is invalid, the frequency inverter cannot respond the modification to frequency. When this terminal state is valid, the frequency inverter responds the modification to frequency.
37	PID Action Direction Negation	When this terminal state is valid, the direction of PID Action is opposite to the direction given by P4.0.03.
38	External Stop Terminal 1	When the running control mode is keyboard control (P0.0.03=0), the terminal can stop through this terminal.
39	External Stop Terminal 2	In any of running control modes, the frequency inverter can slow down and stop at deceleration time 4 through this terminal.
40	PID Integral Stop	When the units digit of P4.2.08 is 1 (i.e. the integral separation is valid and this terminal is valid, the functions of integral regulation of PID stops temporarily, but the functions of proportional regulation and integral regulation of PID are still valid.

Setting value	Function	Description
41	PID Parameter Switch	When the switch conditions of PID parameters are the terminal (P4.0.13=1), this terminal state is invalid, adopt PID Parameter 1. When this terminal state is valid, adopt PID Parameter 2.
42	Speed Control/Torque Control Switch	Realize the switch of the frequency inverter between torque control mode and speed control mode. This terminal state is invalid, the frequency inverter runs in setting mode of P1.1.13 (Speed/Torque Control Mode), when this terminal state is valid, it is switched to another mode.
43	Emergency Stop	When this terminal is valid, the frequency inverter outputs the voltage in enclosed mode and freely stops by inertia.
44	Deceleration DC Brake	When the terminal state is valid, the frequency inverter slows down to Start Frequency of Stop DC Brake and then is switched to Stop DC Brake State.
45	User-Defined Fault 1	When: User-Defined Fault 1 and 2 are valid, the frequency inverter respectively give an alarm of Err21 and Err22 and then the faults are handled based on fault protection action mode.
46	User-Defined Fault 2	
47	Running Time Reset	During the running process, it is to conduct reset handling for current running time, current running time can be viewed through Function Code P9.0.23.
48	Timer Input Terminal 1	When internal timer is controlled by this terminal, this terminal controls the start or stop of the timer, refer to the Description of Function Code P3.2.23.
49	Timer Input Terminal 2	When internal timer is controlled by this terminal, this terminal controls the start or stop of the timer, refer to the Description of Function Code P3.2.23.
50	Timer Reset Terminal 1	When internal timer reset is controlled by this terminal, this terminal state is valid, the timer resets, refer to the Description of Function Code P3.2.23.
51	Timer Reset Terminal 2	When internal timer reset is controlled by this terminal, this terminal state is valid, the timer resets, refer to the Description of Function Code P3.2.23.
52	Encoder Phase A Input	Define the signal input terminal of Encoder A and B. Terminal D15 and D16 of CDI-E100 Series can connect high-speed impulse of the encoder, the impulse frequency of the encoder of other terminals is not greater than 200Hz. The impulse frequency of CDI-E180 Series encoder must be less than 200Hz.
53	Encoder Phase B Input	
54	Distance Reset	Conduct reset handling to the distance
55	Integral Computation Reset	Reset the integral computation in operation module
56~59	User Function 1~4	Reservation

Appendix 1 Description for Functions of Multiplex Directive Terminals

Terminal 4	Terminal 3	Terminal 2	Terminal 1	Multiplex Directive Reference	Corresponding parameter
OFF	OFF	OFF	OFF	Multiplex Directive 0	P3.0.03
OFF	OFF	OFF	ON	Multiplex Directive 1	P3.0.05
OFF	OFF	OFF	OFF	Multiplex Directive 2	P3.0.07
OFF	OFF	OFF	ON	Multiplex Directive 3	P3.0.09
OFF	ON	ON	OFF	Multiplex Directive 4	P3.0.11
OFF	ON	ON	ON	Multiplex Directive 5	P3.0.13
OFF	ON	ON	OFF	Multiplex Directive 6	P3.0.15
OFF	ON	ON	ON	Multiplex Directive 7	P3.0.17
ON	OFF	OFF	OFF	Multiplex Directive 8	P3.0.19
ON	OFF	OFF	ON	Multiplex Directive 9	P3.0.21
ON	OFF	OFF	OFF	Multiplex Directive 10	P3.0.23
ON	OFF	OFF	ON	Multiplex Directive 11	P3.0.25
ON	ON	ON	OFF	Multiplex Directive 12	P3.0.27
ON	ON	ON	ON	Multiplex Directive 13	P3.0.29
ON	ON	ON	OFF	Multiplex Directive 14	P3.0.31
ON	ON	ON	ON	Multiplex Directive 15	P3.0.33

**Explanation:** when the multiplex directive corresponds to frequency, the corresponding parameter is the percentage relative to highest frequency.

**When the multiplex directive corresponds to torque, the corresponding parameter is the percentage relative to digital reference torque.**

**When the multiplex directive corresponds PID, the corresponding parameter is the percentage relative to PID Reference Feedback range.**

Appendix 2 Description for Functions of Frequency Source Selection Terminals

Terminal 3	Terminal 2	Terminal 1	Option of frequency source
OFF	OFF	OFF	Frequency source A (correspond to P0.1.00=0)
OFF	OFF	ON	Frequency source B (correspond to P0.1.00=1)
OFF	ON	OFF	Frequency source A+B (correspond to P0.1.00=2)
OFF	ON	ON	Frequency source A-B (correspond to P0.1.00=3)
ON	OFF	OFF	Max. value of A & B (correspond to P0.1.00=4)
ON	OFF	ON	Min. value of A & B (correspond to P0.1.00=5)
ON	ON	OFF	Backup frequency source 1 (correspond to P0.1.00=6)
ON	ON	ON	Backup frequency source 2 (correspond to P0.1.00=7)

## Appendix 3 Description for Functions of Acceleration and Deceleration Time Selection Terminals

Terminal 2	Terminal 1	Option of acceleration/ deceleration time	Corresponding parameters
OFF	OFF	Acceleration/ deceleration time 1	P0.0.11, P0.0.12
OFF	ON	Acceleration/ deceleration time 2	P0.0.11, P0.0.12
ON	OFF	Acceleration/ deceleration time 3	P0.1.13, P0.1.14
ON	ON	Acceleration/ deceleration time 4	P0.1.15, P0.1.16

## Appendix 4 Description for Functions of Running Command Selection Terminals

Current Running Control Mode	Terminal 1	Terminal 2	Running Control Mode
Keyboard Control (P0.0.03=0)	OFF	ON	Terminal Control
	ON	OFF	Communication Control
	ON	ON	Communication Control
Terminal Control (P0.0.03=1)	OFF	ON	Keyboard Control
	ON	OFF	Communication Control
	ON	ON	Keyboard Control
Communication Control (P0.0.03=2)	OFF	ON	Keyboard Control
	ON	OFF	Terminal Control
	ON	ON	Keyboard Control

**Note: when Terminal 1 and Terminal 2 are OFF, it is the running control mode set by Function Code P0.0.03**

Function code	Function name	Setting scope	Factory Value
P2.0.10	DI Filtering time	0.000s~1.000s	0.010

This function code is used to set the software filtering time of terminal DI input state. If the occasions, which use Terminal DI Input, are easily to lead to false operation by interference, this parameter can be increased to enhance the anti-interference ability, but the increase of the filtering time may cause slow response of Terminal DI.

Function code	Function name	Setting scope	Factory Value
P2.0.11	External Terminal Running Control Mode	0: Two-line Type 1 1: Two-line Type 2 2: Three-line Type 1 3: Three-line Type 2	0

This function code defines that when the control running mode is terminal control (i.e. P0.0.03=1), there are four different modes to control the running of the frequency inverter. Refer to Terminal Control in 7.1.1 for more details.

Function code	Function name	Setting scope	Factory Value
P2.0.12	UP/DOWN Terminal Change Rate	00.001Hz/s~65.535Hz/s	01.000

The function code defines that when Terminal UP/DOWN is used to regulate the reference frequency, set the rate of frequency variation.

When P0.2.04 (Decimal Point of Frequency) is 2, the value range is 00.001Hz/s~65.535Hz/s.

When P0.2.04 (Decimal Point of Frequency) is 1, the value range is 000.01Hz/s~655.35Hz/s.

Function code	Function name	Setting scope	Factory Value
P2.0.13	Minimum Input of Curve 1	00.00V~P2.0.15	00.00
P2.0.14	Corresponding reference for Minimum Input of Curve 1	-100.0%~100.0%	000.0
P2.0.15	Maximum Input of Curve 1	P2.0.13~10.00V	10.00
P2.0.16	Corresponding reference for Maximum Input of Curve 1	-100.0%~100.0%	100.0
P2.0.17	VF1 Filtering time	00.00s~10.00s	00.10

The above function codes are used to set the relation between analog input and corresponding reference value, that is, straight line relationship.

When the voltage of analog input is greater than the given “Max. Input of Curve 1” (P2.0.15), the analog is calculated at “Max. Input of Curve 1”; similarly when the voltage of analog input is lower than the given “Min. Input of Curve 1” (P2.0.13), the calculation shall be at min. input or 0.0% according to the setting of “Curve below Mix. Input Reference Selection”.

VF1 Input Filtering time is used to set the software filtering time of VF1, when the on-site analog is easily to be interrupted, the filtering time shall be increased to make the detected analog tend to be stable, but the greater filtering time makes the response speed of the analog detection become slow, how to set needs to balance based on actual situations of the applications.

**Explanation: when the analog inputs corresponding frequency, the corresponding given value is the percentage relative to highest frequency.**

**When the analog inputs corresponding torque, the corresponding given value is the percentage relative to digital reference torque.**

**When the analog inputs corresponding PID, the corresponding reference value is the percentage relative to PID Reference Feedback range.**

**When the analog inputs corresponding time, the corresponding given value is the percentage relative to running time (P3.1.02).**

Function code	Function name	Setting scope	Factory Value
P2.0.18	Minimum Input of Curve 2	00.00V~P2.0.20	00.00
P2.0.19	Corresponding reference for Minimum Input of Curve 2	-100.0%~100.0%	000.0
P2.0.20	Maximum Input of Curve 2	P2.0.18~10.00V	10.00
P2.0.21	Corresponding reference for Maximum Input of Curve 2	-100.0%~100.0%	100.0
P2.0.22	VF2 Filtering time	00.00s~10.00s	00.10

The functions and use methods of Curve 2 refer to the Description of Curve 1.



Function code	Function name	Setting scope	Factory Value
P2.0.23	Minimum Input of PULS	0.00kHz~ P2.0.25	000.00
P2.0.24	Corresponding reference for Minimum Input of PULS	-100.0%~100.0%	000.0
P2.0.25	Maximum Input of PULS	P2.0.23~100.00kHz	050.00
P2.0.26	Corresponding reference for Maximum Input of PULS	-100.0%~100.0%	100.0
P2.0.27	PULS Filtering time	00.00s~10.00s	00.10

The above function codes are used to set the relation between PULS Impulse Frequency and corresponding reference value, that is, straight line relationship.

When the input impulse frequency is greater than the given “Max. PULS Input” (P2.0.25), the impulse frequency is calculated at “Max. PULS Input”; similarly, when the input impulse frequency is lower than the given “Min. PULS Input” (P2.0.23), the impulse frequency is calculated at “Min. PULS Input”.

PULS Input Filtering time is used to set the software filtering time of PULS Impulse Frequency, when the on-site impulse is easily to be interrupted, the filtering time shall be increased to make the detected impulse frequency tend to be stable, but the greater filtering time makes the response speed of detecting the impulse frequency become slow, how to set needs to balance based on actual situations of the applications.

**Note: when the PULS Impulse Frequency inputs corresponding frequency, the corresponding given value is the percentage relative to highest frequency.**

**When the PULS Impulse Frequency inputs corresponding torque, the corresponding given value is the percentage relative to digital reference torque.**

**When the PULS Impulse Frequency inputs corresponding PID, the corresponding given value is the percentage relative to PID Reference feedback range.**

Function code	Function name	Setting scope	Factory Value
P2.0.28	Expansion Card YO1 Function Selection (Invalid E100)	0~59	00
P2.0.29	T1 Relay Function Selection		01
P2.0.30	T2 Relay Function Selection		02
P2.0.31	Expansion Card YO2 Function Selection (Invalid E100)		00
P2.0.32	YO Function Selection (Use Terminal YO/FMP as YO,i.e.P2.1.20=1)		00

The above five function codes are used to select the functions of five multi-functional output terminals, in which YO & T1 Relay and T2 Relay are configured on control panel, YO1 & YO2 are on I/O Expansion Card of CDI-E180 Series, but invalid for CDI-E100 Series.

The Descriptions of multi-functional output terminals are as below:

Setting value	Function	Description
0	No Function	Multi-functional output terminals have no any functions.
1	Frequency inverter under Running	When the frequency inverter is at running state, have output frequency (able to be zero) and output Signal ON.
2	Fault Stop Output	When the frequency inverter breaks down and shuts down, output Signal ON.
3	Frequency Level Testing FDT1 Output	Refer to the Description for Function Code P2.2.03 and P2.2.04.

Setting value	Function	Description
4	Frequency Arrival	Refer to the Description for Function Code P2.2.02.
5	Zero-speed Running (no output when shut down)	When the frequency inverter is at running state and the output frequency is 0Hz, output Signal ON.
6	Motor Overload Pre-alarm	Before overload protection action of the motor, the judgment can be made according to the threshold value of early alarm to overload, after exceeding the threshold value of early alarm, output Signal ON. Refer to the Description for Function Code P1.0.25 and P1.0.26.
7	Frequency inverter Overload Pre-alarm	The frequency inverter outputs Signal ON 10s prior to occurrence of overload protection.
8	Reference Count Value Arrival	When actual accounting value reaches the set value of Function Code P3.1.11, output Signal ON.
9	Designated Count Value Arrival	When actual accounting value reaches the set value of Function Code P3.1.12, output Signal ON.
10	Length Arrival	When actual length (P9.0.13) reaches the length set by Function Code P3.1.08, output Signal ON.
11	PLC circulation cycle completed	When simple PLC running completes a cycle, output the impulse signal with the width of 250ms.
12	Accumulative Running Time Arrival	When the accumulative running time of the frequency inverter reaches the time set by Function Code P2.2.01, output Signal ON.
13	Frequency Limit	When the output frequency of the frequency inverter reaches upper frequency or lower frequency, output Signal ON.
14	Torque Limit	When the output torque of frequency inverter reaches limit value of the torque in speed control mode, output Signal ON.
15	Ready for Running	When main circuits and control circuit power of the frequency inverter have been stable and the inventor hasn't defected out any fault information, and the frequency inverter is in running state, output Signal ON.
16	VF1>VF2	When the input value of VF1 is greater than the input value of VF2, output Signal ON.
17	Upper Frequency Arrival	When the output frequency reaches upper frequency, output Signal ON.
18	Lower Frequency Arrival (no output when shut down)	When the output frequency reaches lower frequency and the frequency inverter is in running state, output Signal ON.
19	Undervoltage state output	When the frequency inverter is in undervoltage state, output Signal ON.
20	Communication Reference	Refer to the Description of Chapter 8.
21	VF1 Output less than Lower Limit	When the value of the Analog VF1 Input is less than the value set by Function Code P2.2.19 (Lower Limit of VF1 Input), output Signal ON.
22	VF1 Output more Upper Limit	When the value of the Analog VF1 Input is greater than the value set by Function Code P2.2.20 (Upper Limit of VF1 Input), output Signal ON.

Setting value	Function	Description
23	Zero-speed Running 2 (also output when shut down)	When the output frequency of the frequency inverter is 0Hz, output Signal ON. In Stop Mode, this signal is ON.
24	Accumulative Power-on Time Arrival	When the accumulative power-on time of the frequency inverter reaches the time set by Function Code P2.2.00, output Signal ON.
25	Frequency Level Testing FDT2 Output	Refer to the Description of Function Code P2.2.05 and P2.2.06.
26	Frequency 1 Arrival Output	Refer to the Description of Function Code P2.2.07 and P2.2.08
27	Frequency 2 Arrival Output	Refer to the Description of Function Code P2.2.09 and P2.2.10.
28	Current 1 Arrival Output	Refer to the Description of Function Code P2.2.15 and P2.2.16.
29	Current 2 Arrival Output	Refer to the Description of Function Code P2.2.17 and P2.2.18.
30	Timing Arrival Output	When the timing function selection (P3.1.00=1) is valid, this running time reaches the given timing time, the frequency inverter automatically shuts down, output Signal ON in the process of shutdown and stop.
31	VF1 Input Overlimit	When the value of the analog input is greater than the value (Upper Limit of VF1 Input)set by Function Code P2.2.20 or less than the value (Lower Limit of VF1 Input)set by Function Code P2.2.19, output Signal ON
32	In Off-load	In off-load state, the frequency inverter outputs Signal ON.
33	In Reverse Running	In reverse running state, the frequency inverter outputs Signal ON.
34	Zero-current State	Refer to the Description of Function Code P2.2.11 and P2.2.12.
35	Module Temperature Arrival	When the radiator temperature of the module of the frequency inverter reaches the temperature set by Function Code P2.2.21, output Signal ON.
36	Output Current Overlimit	Refer to the Description of Function Code P2.2.13 and P2.2.14.
37	Lower Frequency Arrival (also output when shut down)	When the output frequency reaches lower frequency or the reference frequency is less than the lower frequency in stop state, output Signal ON.
38	Alarm Output	When the frequency inverter fails, if the fault handling mode is continuous running, output Signal ON. If the fault handling mode is shutdown by speed reduction, output Signal ON in the process of shutdown by speed reduction.
39	PLC Phase Completed	When each phase of simple PLC is completed, output an impulse signal with the width of 200ms.

Setting value	Function	Description
40	Current Running Time Arrival	When current running time of the frequency inverter exceeds the value set by Function Code P2.2.22, output Signal ON and the frequency inverter cannot shut down.
41	Fault Output (Not Output for Undervoltage)	When the frequency inverter fails and shuts down, output Signal ON. Output Signal OFF in undervoltage state.
42	Timer 1 Timing Arrival	When the time of Timer 1 reaches the time set by Function Code P3.2.24, output Signal ON.
43	Timer 2 Timing Arrival	When the time of Timer 2 reaches the time set by Function Code P3.2.25, output Signal ON.
44	Timer 1 Timing Arrival but Timer 2 Timing Not Arrival	When the time of Timer 1 reaches the time set by Function Code P3.2.24 and the time of Timer 2 fails to reach the time set by Function Code P3.2.25, output Signal ON.
45	User Function 1	Reservation
46	User Function 2	Reservation
47	User Function 3	Reservation
48	User Function 4	Reservation
49	User Function 5	Reservation
50	Synchronization Intermediate Relay M1	Have the same action with M1
51	Synchronization Intermediate Relay M2	Have the same action with M2
52	Synchronization Intermediate Relay M3	Have the same action with M3
53	Synchronization Intermediate Relay M4	Have the same action with M4
54	Synchronization Intermediate Relay M5	Have the same action with M5
55	Distance over Zero	When actual distance (P9.0.30) is greater than 0, output Signal ON.
56	Distance Set value 1 Arrival	When actual distance (P9.0.30) reaches the distance set by Function Code P3.1.13, output Signal ON.
57	Distance Set value 2 Arrival	When actual distance (P9.0.30) reaches the distance set by Function Code P3.1.14, output Signal ON.
58	Operation Result 2 greater than 2	When the result 2 of the operation module is greater than 0, output Signal ON.
59	Operation Result 4 greater than 2	When the result 4 of the operation module is greater than 0, output Signal ON.

Function code	Function Name	Setting scope	Factory Value
P2.0.33	Analog Output FM1 Reference	0~20	00
P2.0.34	Analog Output FM2 Reference		01
P2.0.35	FMP Output Reference (Use Terminal YO/FMP as FMP, i.e. P2.1.20=0)		00

Function Code P2.0.33 and P2.0.34 respectively define the functions of Analog Output FM1 and FM2. Function Code P2.0.35 defines FMP Impulse Output Function.

The output range of Analog Output FM1 and FM2 is 0V~10V voltage signal or 0/4mA~20mA current signal. The deviation between actual output voltage and target output voltage of the analog output terminal can be adjusted through Function Code P8.1.13~P8.1.20.

The range of FMP Output Impulse Frequency is 0.01kHz~P2.1.21 (Highest Frequency of FMP Output ), P2.1.21 can be set among 0.01kHz~100.00kHz.

The calibration relation between range of impulse output or analog output and corresponding functions are shown in the table below:

Set value	Function	Corresponding Function of Impulse or Analog Output 0.0%~100.0%
0	Running Frequency	0~Max. Output Frequency
1	Output Current	0~Max. Output Frequency
2	Output Torque (Absolute Value of Torque)	0~2 Times of Rated Current of the Motor
3	Output Torque	0~2 Times of Rated Torque of the Motor
4	Output Power	0~2 Times of Rated Power
5	Output Voltage	0~2 Times of Rated Voltage of the Frequency inverter
6	PULSE Impulse Input	0.01kHz~100.00kHz
7	VF1 Voltage	0V~10V (or 0/4mA~20mA)
8	VF2 Voltage	0V~10V (or 0/4mA~20mA)
9	Keyboard Potentiometer Voltage	0V~10V
10	Actual Length Value	0~Reference Length Value (Set value of Function Code P3.1.08)
11	Actual Counting Value	0~Designated Count Value (Set value of Function Code P3.1.12)
12	Communication Reference	Refer to the Description of Chapter VIII.
13	Motor Speed	0~Corresponding Speed of Max. Output Frequency
14	Output Current	0.0A~1000.0A
15	Bus Voltage	0.0V~1000.0V
16	Output Torque	-2 Times of Rated Torque of the Motor ~ 2 Times of Rated Torque of the Motor
17	Operation Result 1	-1000~1000
18	Operation Result 2	0~1000
19	Operation Result 3	-1000~1000
20	Operation Result 4	0~1000

Function code	Function Name	Setting scope	Factory Value
P2.0.36	Analog FM1 Output Offset	-100.0%~100.0%	000.0
P2.0.37	Analog FM1 Output Gains	-10.00~10.00	01.00
P2.0.38	Analog FM2 Output Offset	-100.0%~100.0%	000.0
P2.0.39	Analog FM2 Output Gains	-10.00~10.00	01.00

The above function codes are generally used for correcting zero drift of analog output and deviation of output amplitude, but also can be used to customize the required analog output curve.

Actual Analog Output= Standard Analog Output × Analog Output Gain+ Analog Output Offset  
Standard Analog Output refers to the output analog value without offset and gain correction.

### Group P2.1 Expansion Group

Function code	Function Name	Setting scope	Factory Value
P2.1.00	Valid Model Selection 1 of Terminal DI	0: Active High Level 1: Active Low Level Ones: DI1 Tens: DI2 Hundreds: DI3 Thousands: DI4 Ten Thousands: DI5	00000
P2.1.01	Valid Model Selection 2 of Terminal DI	0: Active High Level 1: Active Low Level Ones: DI6 Tens: DI7 (Invalid E100) Hundreds: DI8 (Invalid E100) Thousands: DI9 (Invalid E100) Ten Thousands: DI10 (Invalid E100)	00000

Be used for setting valid state mode of digital input terminal.

When selecting active high level, it is not valid until corresponding Terminal DI is connected, and the disconnection is invalid.

When selecting active low level, it is not valid until corresponding Terminal DI is connected, and the disconnection is invalid.

**Note: DI7~DI10 are the terminals of CDI-E180 Series on Expansion Card I/0, but invalid for CDI-E100 Series.**

Function code	Function Name	Setting scope	Factory Value
P2.1.02	Analog Input Curve Selection	Ones: Curve Selected for VF1 Tens: Curve Selected for VF2 1: Curve 1 2: Curve 2 3: Curve 3 4: Curve 4	H.21

The ones and tens of this function code are respectively used to select corresponding given curve of analog. Two analog inputs can respectively select any one of four kinds of the curves. Curve 1 and Curve 2 are linear relationship, refer to the setting of P2.0.13~P2.0.22 for more details, while Curve 3 and Curve 4 are broken line relationship with two inflection points, refer to the setting of P2.1.04~P2.1.19 for more details.


Function code	Function Name	Setting scope	Factory Value
P2.1.03	Selection for Curve less than Min. Reference	Ones: VF1 less than Min. Input Tens: VF2 less than Min. Input 0: Corresponding Min. Input Reference 1: 0.0%	H.00

This function code is used to set how to determine the corresponding reference of the analog when the analog input is less than the given “Min. Input”.

The ones and tens of this function code respectively correspond to VF1 and VF2. If it is 0, when VF input is lower than “Min. Input”, this corresponding reference of this analog is “Corresponding reference of Min. Input” (P2.0.14, P2.0.19, P2.1.05, P2.1.13) of the selected curve. If it is 1, when VF input is lower than “Min. Input”, this corresponding reference of this analog is 0.0%.

Function code	Function Name	Setting scope	Factory Value
P2.1.04	Min. Input of Curve 3	00.00V~P2.1.06	00.00
P2.1.05	Corresponding reference for Min. Input of Curve 3	-100.0%~100.0%	000.0
P2.1.06	Curve 3 Inflection Point 1 Input	P2.1.04~ P2.1.08	03.00
P2.1.07	Corresponding reference for Curve 3 Inflection Point 1 Input	-100.0%~100.0%	030.0
P2.1.08	Curve 3 Inflection Point 2 Input	P2.1.06~ P2.1.10	06.00
P2.1.09	Corresponding reference for Curve 3 Inflection Point 2 Input	-100.0%~100.0%	060.0
P2.1.10	Max. Input of Curve 3	P2.1.08~10.00V	10.00
P2.1.11	Corresponding reference for Max. Input of Curve 3	-100.0%~100.0%	100.0

The functions and use methods of Curve 3 is roughly the same with Curve 1 and Curve 2 (refer to the Description of Curve 1), the difference is that Curve 1 and Curve 2 are linear relationship without inflection point, but curve 3 is broken line relationship with two inflection point in the middle, refer to the Description in the figure below:



Function code	Function Name	Setting scope	Factory Value
P2.1.12	Min. Input of Curve 4	00.00V~P2.1.14	00.00
P2.1.13	Corresponding reference for Min. Input of Curve 4	-100.0%~100.0%	-100.0
P2.1.14	Curve 4 Inflection Point 1 Input	P2.1.12~P2.1.16	03.00
P2.1.15	Corresponding reference for Curve 4 Inflection Point 1 Input	-100.0%~100.0%	-030.0
P2.1.16	Curve 4 Inflection Point 2 Input	P2.1.14~P2.1.18	06.00
P2.1.17	Corresponding reference for Curve 4 Inflection Point 2 Input	-100.0%~100.0%	030.0
P2.1.18	Max. Input of Curve 4	P2.1.16~10.00V	10.00
P2.1.19	Corresponding reference for Max. Input of Curve 4	-100.0%~100.0%	100.0

As for the functions and use methods of Curve 4, refer to the Description of Curve 3.

Function code	Function name	Setting scope	Factory Value
P2.1.20	YO/FMP Terminal Function	0: Impulse output (FMP) 1: Open Collector Output (YO)	1

This function code is used to define that the Terminal YO/FMP is used as impulse output function or open collector function.

If it is used as impulse output (i.e.P2.1.20=0), specific function refers to the Description for Function Code P2.0.35, and the high frequency of the output impulse is determined by the set value of Function Code P2.1.21 at the moment.

If it is used as open collector function (i.e.P2.1.20=1), specific function refers to the Description for Function Code P2.0.32.

Function code	Function name	Setting scope	Factory Value
P2.1.21	Highest Frequency of FMP Output	000.01kHz~100.00kHz	050.00

This function code is used to set the highest frequency of output impulse when Terminal YO/FMP is used as impulse output (i.e.P2.1.20=0)



Function code	Function Name	Setting scope	Factory Value
P2.1.22	Valid State of Multi-functional Output Terminal	0: Positive Logic 1: Negative Logic Ones: YO Tens: T1 Hundreds: T2 Thousands: Expansion Card Yo1 (Invalid E100) Ten Thousands: Expansion Card Yo2 (Invalid E100)	00000

The ones, tens, hundreds, thousands and ten thousands of this function code respectively define the output logic of Output Terminal YO, T1, T2, Expansion Card YO1 and YO2.

0: Positive Logic

When the output signal is valid, the multi-functional output terminal is connected. But When the output signal is invalid, the multi-functional output terminal is disconnected.

1: Negative Logic

When the output signal is invalid, the multi-functional output terminal is connected. But when the output signal is valid, the multi-functional output terminal is disconnected.

Function code	Function name	Setting scope	Factory Value
P2.1.23	VF1 Terminal Function as Digital Input	00: Use as Normal Analog 01~59: Digital Input Terminal Function	00
P2.1.24	VF2 Terminal Function as Digital Input	00: Use as Normal Analog 01~59: Digital Input Terminal Function	00

This group of function codes is used to set the functions when the analog input terminal VF is used as digital input terminal DI. When VF is used as DI, VF and 10V are connected, VF Terminal State is high level, when VF and 10V are disconnected, and VF Terminal State is low level. the setting refers to the use and Description of the functions refer to Function Code P2.0.00~P2.0.09.

Function code	Function name	Setting scope	Factory Value
P2.1.25	Valid State Option of VF	0: Active High Level 1: Active Low Level Ones: VF1 Tens: VF2	00

This function code is used to confirm that the analog input terminal VF is used as digital input terminal DI , VF Terminal State is active high level or active low level. Ones and Tens respectively represent VF1 and VF2.

Active High Level: the connection of VF and 10V is valid, but disconnection is invalid.

Active Low Level: the connection of VF and 10V is valid, but disconnection is invalid.

Function code	Function Name	Setting scope	Factory Value
P2.1.26	DI1 Delay	0.0s~3600.0s	0000.0
P2.1.27	DI2 Delay	0.0s~3600.0s	0000.0
P2.1.28	DI3 Delay	0.0s~3600.0s	0000.0

The above functions are used to set the delayed time arising from the impact of the signal on frequency inverter when changes occur in signal DI1, DI2 and Di3.

Function code	Function Name	Setting scope	Factory Value
P2.1.29	YO Delay	0.0s~3600.0s	0000.0
P2.1.30	T1 Delay	0.0s~3600.0s	0000.0
P2.1.31	T2 Delay	0.0s~3600.0s	0000.0

The above function codes are used to set the delayed time of the frequency inverter from generating signal YO, T1 and T2 to output signal YO, T1 and T2.

### Group P2.2 - Auxiliary Group

Function code	Function Name	Setting scope	Factory Value
P2.2.00	Accumulative Power-on Arrival Time Reference	0h~65000h	00000

This function code is used to set accumulative power-on time of the frequency inverter from the date of leaving the factory. When actually accumulative power-on time reaches the value set by Function Code P2.2.00, the multi-functional output terminals of the frequency inverter output Signal ON. The corresponding function of multi-functional output terminals is accumulative power-on time arrival (24). The frequency inverter gives an alarm of Fault Err23. If the setting is 0, the accumulative power-on time is not limited. Actually accumulative power-on time can be viewed through Function Code P5.1.01.

**Note: Only when actually accumulative power-on time (P5.1.01) is less than the value set by Function Code P2.2.00, the frequency inverter can enter into normal running, if the setting is 0, the accumulative power-on time is not limited.**


Function code	Function Name	Setting scope	Factory Value
P2.2.01	Accumulative Running Arrival Time Reference	0h~65000h	00000

This function code is used to set accumulative running time of the frequency inverter. When actually accumulative running time reaches the value set by Function Code P2.2.01, the multi-functional output terminals of the frequency inverter output Signal ON and the frequency inverter shuts down automatically. The corresponding function of multi-functional output terminals is accumulative running time arrival (12). The frequency inverter gives an alarm of Fault Err24. Actually accumulative running time can be viewed through Function Code P5.1.00.

**Note: Only when actually accumulative running time (P5.1.00) is less than the value set by Function Code P2.2.01, the frequency inverter can enter into normal running, if the setting is 0, the accumulative running time is not limited.**

Function code	Function name	Setting scope	Factory Value
P2.2.02	Detected Reference frequency Width upon Arrival	000.0%~100.0%	000.0


When the running frequency of frequency inverter is within positive and negative frequency with detected width of the reference frequency, the multi-functional output terminals of the frequency inverter output Signal ON. The reference value of this function code is the percentage relative to the high reference frequency. Corresponding function of multi-functional output terminals is frequency arrival (4), refer to the Description of the figure below:



Detected Width Frequency= Detected Reference frequency Width upon Arrival (P2.2.02) × Highest Frequency (P0.0.07)

Function code	Function name	Setting scope	Factory Value
P2.2.03	Frequency Detection FDT1	000.00Hz~Highest Frequency	050.00
P2.2.04	FDT1 Lagged Value	000.0%~100.0%	005.0

When the output frequency of the frequency inverter exceeds one value, the multi-functional output terminals of the frequency inverter output Signal ON, this value is called as Detected Frequency FDT1. When the output frequency of the frequency inverter is lower than a certain value of Detected Frequency FDT1, the multi-functional output terminals of the frequency inverter output Signal OFF, this value is called as Lagged FDT1 Frequency Value. Corresponding function of multi-functional output terminals is Detected FDT1 Output of Frequency Level (3), refer to the Description of the figure below:




Lagged FDT1 Frequency Value= Detected Frequency FDT1 (P2.2.03) × Lagged Value of FDT1

Function code	Function name	Setting scope	Factory Value
P2.2.05	Frequency Detection FDT2	000.00Hz~Highest Frequency	050.00
P2.2.06	FDT2 Lagged Value	000.0%~100.0%	005.0

FDT2 has the same function with FDT1, refer to the Description for FDT1 (P2.2.03 and P2.2.04) for more details. Corresponding function of multi-functional output terminals is Frequency Level Detection FDT2 (25).

Function code	Function name	Setting scope	Factory Value
P2.2.07	Detected Frequency Value 1 upon Arbitrary Arrival	000.00Hz~Highest Frequency	050.00
P2.2.08	Detected Frequency 1 Width upon Arbitrary Arrival	000.0%~100.0%	000.0

When the running frequency of the frequency inverter is within any positive and negative frequency with detected width of the reference frequency that arrives at Detected Frequency Value 1, the multi-functional output terminals of the frequency inverter output Signal ON. When the running frequency of the frequency inverter is beyond any positive and negative frequency with detected width of the reference frequency that arrives at Detected Frequency Value 1, the multi-functional output terminals of the frequency inverter output Signal OFF. Corresponding function of the multi-functional output terminals is Frequency 1 Arrival Output (26), refer to the Description of the figure below:




Detected Width Frequency = Any Detected Width upon Arrival at Frequency 1 (P2.2.08) × Highest Frequency (P0.0.07)

Function code	Function name	Setting scope	Factory Value
P2.2.09	Detected Frequency Value 2 upon Arbitrary Arrival	000.00Hz~Highest Frequency	050.00
P2.2.10	Detected Frequency 2 Width upon Arbitrary Arrival	000.0%~100.0%	000.0

The above function codes have the same function with Function Code P2.2.07 and P2.2.08, refer to the Description of P2.2.07 and P2.2.08 for more details. Corresponding function of the multi-functional output terminals is Frequency 2 Arrival Output (27).

Function code	Function name	Setting scope	Factory Value
P2.2.11	Zero Current Detection Level	000.0%~300.0% (100.0% correspond to rated current of motor)	005.0
P2.2.12	Delay Time for Zero Current Detection	000.01s~600.00s	000.10


When the running current of the frequency inverter is less than or equal to zero-current detection level and the duration exceeds the delay time of zero-current detection, the multi-functional output terminals of the frequency inverter output Signal ON, once the running current resets to the current detection level larger than zero, the multi-functional output terminals of the frequency inverter output Signal OFF. Corresponding function of the multi-functional output terminals is zero-current state (34), refer to the Description of the figure below:



Current Detection Delay Time when T at O

Function code	Function name	Setting scope	Factory Value
P2.2.13	Output Current Overlimit Value	00.0: No Detection 000.1%~300.0%	200.0
P2.2.14	Delay Time for Current Overlimit Detection	000.00s~600.00s	000.00


When the running current of the frequency inverter is greater than the value set by Function Code P2.2.13 and the duration exceeds the value set by Function Code P2.2.14, the multi-functional output terminals of the frequency inverter output Signal ON, once the running current resets to the value less than and equal to overlimit of output current, the multi-functional output terminals of the frequency inverter output Signal OFF. Corresponding function of the multi-functional output terminals is output current overlimit (36), refer to the Description of the figure below:



The output current overlimit is the percentage of rated current of the motor. T refers to the delay time of detecting out current overlimit.

Function code	Function name	Setting scope	Factory Value
P2.2.15	Current Level Detection 1	000.0%~300.0%	100.0
P2.2.16	Detection Width of Current Level 1	000.0%~300.0%	000.0

When the running current of the frequency inverter is within positive and negative frequency with detected width of the current level detection 1, the multi-functional output terminals of the frequency inverter output Signal ON. When the running current of the frequency inverter is beyond positive and negative detected width of current level detection 1, the multi-functional output terminals of the frequency inverter output Signal OFF. Corresponding function of the multi-functional output terminals is Current 1 Arrival Output (28), refer to the Description of the figure below:



Current Level Detection 1 and Detection Width of Current Level 1 are the percentage of the rated current of the motor.

Function code	Function name	Setting scope	Factory Value
P2.2.17	Current Level Detection 2	000.0%~300.0%	100.0
P2.2.18	Detection Width of Current Level	2000.0%~300.0%	000.0

The above function codes have the same functions with Function Code P2.2.15 and P2.2.16, refer to the Description of Function Code P2.2.15 and P2.2.16 for more details. Corresponding function of the multi-functional output terminals is Current 2 Arrival Output (29).

Function code	Function name	Setting scope	Factory Value
P2.2.19	VF1 Input Lower Limit	00.00V~P2.220	03.10
P2.2.20	VF1 Input Upper Limit	P2.219~11.00V	06.80

When the input value of Analog VF1 is less than the value set by Function Code P2.2.19, the multi-functional output terminals of the frequency inverter output Signal ON. Corresponding function of the multi-functional output terminals is VF Input less than lower limit (21) or above limit (31).

When the input value of Analog VF1 is less than the value set by Function Code P2.2.20, the multi-functional output terminals of the frequency inverter output Signal ON. Corresponding function of the multi-functional output terminals is VF Input less than lower limit (22) or above limit (31).

Function code	Function name	Setting scope	Factory Value
P2.2.21	Model Temperature Arrival Reference	000℃~100℃	075

The module temperature of the frequency inverter reaches the value set by Function Code P2.2.21, the multi-functional output terminals of the frequency inverter output Signal ON. Corresponding function of the multi-functional output terminals is Module Temperature Arrival (35). Actual module temperature can be viewed through Function Code P5.1.03.

Function code	Function name	Setting scope	Factory Value
P2.2.22	Current Running Arrival Time Reference	0000.0~6500.0min	0000.0

The frequency inverter needs to restart timing for every start, when reaching the value set by Function Code P2.2.22, the frequency inverter continues to run and the multi-functional output terminals of the frequency inverter output Signal ON. Corresponding function of multi-functional output terminals is Current Running Time Arrival (40). If the set is 0, current running time is not limited. Actual time of current running can be viewed through Function Code P9.0.23 (when the frequency inverter shuts down, the display value of P9.0.23 automatically resets to 0).

## 6.4 Group P3 - Programmable Function

### Group P3.0 - Basic Group

Function code	Function name	Setting scope	Factory Value
P3.0.00	Simple PLC Running Mode	0: End of Single Running and Stop 1: End of Single Running and Save Final Value 2: Continuous Running 3: Cycle N Times	0

0: Stop after End of Single Cycle

The frequency inverter stops automatically after completing one cycle.

1: Keep Final Value after End of Single Running

The frequency inverter runs at reference frequency of final phase after completing one cycle.

2: Continuous Cycle

The frequency inverter continues to run until the stop command is given.

3: N Times of Cycle

The frequency inverter stops automatically after cycling N times. N is set by reference value of Function Code P3.0.01.

Function Code	Function name	Setting Scope	Factory Value
P3.0.01	Cycle Times N	00000~65000	00000

This function code is used to set the times of cycle running at Function Code P3.0.00=3.

Function Code	Function name	Setting Scope	Factory Value
P3.0.02	Option of PLC Power-off Memory	Ones: Option of Power-off Memory 0: No Power-off Memory 1: Power-off Memory Tens: Stop Memory Selection 0: No Stop Memory 1: Stop Memory	00

PLC Power-off Memory means running phase and running frequency of PLC before memory power-off, when powering on next time, the frequency inverter continues to run from memory phase. If it is selected not to memory, every power-on needs to restart the process of PLC.

PLC Stop Memory means running phase and running frequency of PLC before memory shutdown, when running next time, the frequency inverter continues to run from memory phase. If it is selected not to memory, every start needs to restart the process of PLC.



Function code	Function name	Setting scope	Factory Value
P3.0.03	Phase Directive 0	-100.0%~100.0%	000.0
P3.0.04	Phase 0 Running Time	0000.0s~6553.5s	0000.0
P3.0.05	Phase Directive 1	-100.0%~100.0%	000.0
P3.0.06	Phase 1 Running Time	0000.0s~6553.5s	0000.0
P3.0.07	Phase Directive 2	-100.0%~100.0%	000.0
P3.0.08	Phase 2 Running Time	0000.0s~6553.5s	0000.0
P3.0.09	Phase Directive 3	-100.0%~100.0%	000.0
P3.0.10	Phase 3 Running Time	0000.0s~6553.5s	0000.0
P3.0.11	Phase Directive 4	-100.0%~100.0%	000.0
P3.0.12	Phase 4 Running Time	0000.0s~6553.5s	0000.0
P3.0.13	Phase Directive 5	-100.0%~100.0%	000.0
P3.0.14	Phase 5 Running Time	0000.0s~6553.5s	0000.0
P3.0.15	Phase Directive 6	-100.0%~100.0%	000.0
P3.0.16	Phase 6 Running Time	0000.0s~6553.5s	0000.0
P3.0.17	Phase Directive 7	-100.0%~100.0%	000.0
P3.0.18	Phase 7 Running Time	0000.0s~6553.5s	0000.0
P3.0.19	Phase Directive 8	-100.0%~100.0%	000.0
P3.0.20	Phase 8 Running Time	0000.0s~6553.5s	0000.0
P3.0.21	Phase Directive 9	-100.0%~100.0%	000.0
P3.0.22	Phase 9 Running Time	0000.0s~6553.5s	0000.0
P3.0.23	Phase Directive 10	-100.0%~100.0%	000.0
P3.0.24	Phase 10 Running Time	0000.0s~6553.5s	0000.0
P3.0.25	Phase Directive 11	-100.0%~100.0%	000.0
P3.0.26	Phase 11 Running Time	0000.0s~6553.5s	0000.0
P3.0.27	Phase Directive 12	-100.0%~100.0%	000.0
P3.0.28	Phase 12 Running Time	0000.0s~6553.5s	0000.0
P3.0.29	Phase Directive 13	-100.0%~100.0%	000.0
P3.0.30	Phase 13 Running Time	0000.0s~6553.5s	0000.0
P3.0.31	Phase Directive 14	-100.0%~100.0%	000.0
P3.0.32	Phase 14 Running Time	0000.0s~6553.5s	0000.0
P3.0.33	Phase Directive 15	-100.0%~100.0%	000.0
P3.0.34	Phase 16 Running Time	0000.0s~6553.5s	0000.0

When the tens for each phase property of the multiplex directive is 0, the corresponding reference value of Simple PLC Running and each phase of the multiplex directive are the percentage relative to the highest frequency.

The phase running time is the duration of PLC running at the frequency of each phase (including acceleration and deceleration time and FWD and REV Dead Time).

Chapter 6 Description of Parameters

Function code	Function Name	Setting scope	Factory Value
P3.0.35	Phase 0 Attribution	Ones: Acceleration & Deceleration Time Selection (Invalid Multiplex Directive)	H.00
P3.0.36	Phase 1 Attribution	0: Acceleration & Deceleration Time 1	H.00
P3.0.37	Phase 2 Attribution	1: Acceleration & Deceleration Time 2	H.00
P3.0.38	Phase 3 Attribution	2: Acceleration & Deceleration Time 3	H.00
P3.0.39	Phase 4 Attribution	3: Acceleration & Deceleration Time 4	H.00
P3.0.40	Phase 5 Attribution	Tens: Frequency Source Selection ( Valid Multiplex Directive)	H.00
P3.0.41	Phase 6 Attribution	0: Current Phase Directive	H.00
P3.0.42	Phase 7 Attribution	1: Keyboard Potentiometer	H.00
P3.0.43	Phase 8 Attribution	2: Keyboard Frequency Reference	H.00
P3.0.44	Phase 9 Attribution	3: VF1 Input	H.00
P3.0.45	Phase 10 Attribution	4: VF2 Input	H.00
P3.0.46	Phase 11 Attribution	5: PULS Reference (DI6)	H.00
P3.0.47	Phase 12 Attribution	6: PID Reference	H.00
P3.0.48	Phase 13 Attribution	7: Operation Result 1	H.00
P3.0.49	Phase 14 Attribution	8: Operation Result 2	H.00
P3.0.49	Phase 14 Attribution	9: Operation Result 3	H.00
P3.0.50	Phase 15 Attribution	A: Operation Result 4	H.00

The ones of the phase property determine the acceleration and deceleration time of Simple PLC running at each phase and the tens of phase property determine the frequency source of Simple PLC Running or Multiplex Directive at each phase.

Function Code	Function name	Setting Scope	Factory Value
P3.0.51	Simple PLC Running Time Unit	0: Second 1: Hour	0

Refer to the unit of phase running time when the frequency inverter is at Simple PLC Running.

Function code	Function Name	Setting scope	Factory Value
P3.1.00	Timing Function Selection	0: Invalid 1: Valid	0
P3.1.01	Fixed Running Time Selection	0: Digital Reference (P3.1.02) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference (Analog input range corresponds to P3.1.02)	0
P3.1.02	Fixed Running Time	0000.0min~6500.0min	0000.0

The above function codes are used to complete the timing run function of the frequency inverter. Refer to 7.1.8 for more details (Timing Function).

Function code	Function name	Setting scope	Factory Value
P3.1.03	Wobblating Reference Mode	0: Relative to Reference frequency 1: Relative to Highest Frequency	0
P3.1.04	Wobblating Range	000.0%~100.0%	000.0
P3.1.05	Kicking Range	00.0%~50.0%	00.0
P3.1.06	Wobblating Cycle	0000.1s~3000.0s	0010.0
P3.1.07	Rise Time of Wobblating Triangular Wave	000.1%~100.0%	050.0

The above function codes are used for wobblating function. Refer to 7.1.16 for more details(wobblating function).

Function code	Function name	Setting scope	Factory Value
P3.1.08	Reference Length	00000m~65535m	01000
P3.1.09	Actual Length	00000m~65535m	00000
P3.1.10	Impulse Count per meter	0000.1~6553.5	0100.0

The above function codes are used for fixed-length control. Refer to 7.1.9 for more details (fixed-length function).

Function code	Function name	Setting scope	Factory Value
P3.1.11	Reference Count Value	00001~65535	01000
P3.1.12	Designated Count Value	00001~65535	01000

The above function codes are used for counting control. Refer to 7.1.10 for more details (Counting Function).

Function code	Function name	Setting scope	Factory Value
P3.1.13	Distance Set value 1	-3200.0~3200.0	0000.0
P3.1.14	Distance Set value 2	-3200.0~3200.0	0000.0
P3.1.15	Impulse Count per Distance	000.00~600.00	000.00

The above function codes are used for distance control. Refer to 7.1.11 for more details (Distance Control Function).

**P3.2 Built-in Logic PLC Function**

Function code	Function Name	Setting scope	Factory Value
P3.2.00	Intermediate Delay Relay Control	0: the input of this relay is determined by this Relay Control Word A 1: the input of this relay is determined by this Relay Control Word B 2: the input of this relay is determined by this Relay Control Word C Ones: Relay 1 (M1) Tens: Relay 2 (M2) Hundreds: Relay 3 (M3) Thousands: Relay 4 (M4) Ten Thousands: Relay 5 (M5)	00000

This function is used to set which control word determines the Intermediate Delay Relay.

When at 0, the Intermediate Delay Relay is determined by Control Word A, refer to the Description for Function Code P3.2.01.

When at 1, the Intermediate Delay Relay is determined by Control Word B, refer to the Description for Function Code P3.2.02~P3.2.06.

When at 2, the Intermediate Delay Relay is determined by thousands and hundreds of Control Word C, refer to the Description for Function Code P3.2.07~P3.2.11.

Refer to the explanation for 7.1.12 (Simple Internal Relay Programmable Function).

Function code	Function Name	Setting scope	Factory Value
P3.2.01	Intermediate Relay Control Word A	0: Reference 0 1: Reference 1 Ones: M1 Tens: M2 Hundreds: M3 Thousands: M4 Ten Thousands: M5	00000

When which digit of Function Code P3.2.00 is 0, this function Code is used to compulsorily set corresponding relay of this digit at 0 or 1. Refer to 7.1.12 for more details (Simple Internal Relay Programmable Function).

Function code	Function Name	Setting scope	Factory Value
P3.2.02	Intermediate Delay Relay M1 Control Word B	Ones: Control Logic 0: Input 1 1: Input 1 and NOT 2: Input 1 and Input 2 AND 3: Input 1 and Input 2 OR 4: Input 1 and Input 2 XOR 5: the valid reference of Input 1 is valid the valid Reference of Input 2 is invalid 6: Valid reference of Input 1 Rise Edge is valid Valid reference of Input 2 Rise Edge is invalid 7: Reverse valid signal of Input 1 Rising Edge 8: Input 1 Rise Edge is valid and output a impulse signal with width of 200ms 9: Input 1 Rise Edge and Input 2 AND Hundreds and Tens: Input 1 Selection 0~9: DI1~DI10 10~14: M1~M5 15~16: VF1, VF2 17~19: Standby 20~79: Output Function 00~59 Corresponding to Multi-functional Output Terminal Ten Thousands: Input 2 Selection 0~9: DI1~DI10 10~14: M1~M5 15~16: VF1, VF2 17~19: Standby 20~59: Output Function 00~39 Corresponding to Multi-functional Output Terminal	00000
P3.2.03	Intermediate Delay Relay M2 Control Word B		00000
P3.2.04	Intermediate Delay Relay M3 Control Word B		00000
P3.2.05	Intermediate Delay Relay M4 Control Word B		00000
P3.2.06	Intermediate Delay Relay M5 Control Word B		00000

When which digit of Function Code P3.2.00 is 1, the relay of this digit is controlled by the above corresponding function code. The ones of the above function codes are used to set the logic operation function of Input 1 and Input 2. The hundreds and tens are used to set the option for Input 1. Ten Thousands and Thousands are used to set the option for Input 2. The Intermediate Delay Relay M is the result from simple logic operation of Input 1 and Input 2.

M=Logic Operation (Input 1 and Input 2)

Refer to 7.1.12 for more details (Simple Internal Relay Programmable Function)

Function code	Function Name	Setting scope	Factory Value
P3.2.07	Intermediate Delay Relay M1 Control Word C	Tens Ones: 00~59	0000
P3.2.08	Intermediate Delay Relay M2 Control Word C	Output Function 00~59 Corresponding to Digital Input Terminal	0000
P3.2.09	Intermediate Delay Relay M3 Control Word C	Thousands Hundreds: 00~59	0000
P3.2.10	Intermediate Delay Relay M4 Control Word C	Output Function 00~59 Corresponding to Multi-functional Output Terminal	0000
P3.2.11	Intermediate Delay Relay M5 Control Word C	Terminal	0000

The tens and ones of the above function codes are used to set the action destination of acquiring the Intermediate Delay Relay after logic operation results, that is, action to be performed ( it can correspond to any one kind of digital input functions), and the thousands and hundreds are used to control corresponding relay when which digit of Function Code P3.2.00 is 2(it can correspond to any one kind of multi-functional output terminal functions).Refer to 7.1.12 for more details ( Simple Internal Relay Programmable Function)

Function code	Function Name	Setting scope	Factory Value
P3.2.12	M1 Connection Delay Time	0.0s~3600.0s	0000.0
P3.2.13	M2 Connection Delay Time	0.0s~3600.0s	0000.0
P3.2.14	M3 Connection Delay Time	0.0s~3600.0s	0000.0
P3.2.15	M4 Connection Delay Time	0.0s~3600.0s	0000.0
P3.2.16	M5 Connection Delay Time	0.0s~3600.0s	0000.0
P3.2.17	M1 Disconnection Delay Time	0.0s~3600.0s	0000.0
P3.2.18	M2 Disconnection Delay Time	0.0s~3600.0s	0000.0
P3.2.19	M3 Disconnection Delay Time	0.0s~3600.0s	0000.0
P3.2.20	M4 Disconnection Delay Time	0.0s~3600.0s	0000.0
P3.2.21	M5 Disconnection Delay Time	0.0s~3600.0s	0000.0

The above function codes are used to set the delay time of connecting or disconnecting the Intermediate Delay Relays.

Function code	Function Name	Setting scope	Factory Value
P3.2.22	Valid State Option of Intermediate Relay	0: Not Negation 1: Negation Ones: M1 Tens: M2 Hundreds: M3 Thousands: M4 Ten Thousands: M5	00000

This function code is used to set valid state of the Intermediate Delay Relay.

If which digit is 0, it means that the relay of this digit will output the signal of acquired results.

If which digit is 1, it means that the relay of this digit will invert the signal of acquired results and output it.

Function code	Function Name	Setting scope	Factory Value
P3.2.23	Internal Timer Control Word	Ones: Timing Control 1 of Timer Tens: Timing Control 2 of Timer 0: Timer Running 1: Controlled by Timer Input Terminal 1 2: Negation Control of Timer Input Terminal 1 3: Controlled by Timer Input Terminal 2 4: Negation Control of Timer Input Terminal 2 Hundreds: Timer 1 Reset Control Thousands: Timer 2 Reset Control 0: Controlled by Timer Reset Terminal 1 1: Controlled by Timer Reset Terminal 2 Ten Thousands: Timing Unit 0: Second 1: Minute	00000

The ones and tens of this function code is used to set the timing control of Timer 1 and Timer 2 respectively.

0: Indicate that the timer is uncontrollable and continuously counting.

1: Conduct control by Timer Input Terminal 1, when this terminal state is valid, the timer starts counting, when the terminal state is invalid, the timer stops counting and keeps current value.

2: Conduct inverse control by Timer Input Terminal 1, when this terminal state is invalid, the timer starts counting, when the terminal state is valid, the timer stops counting and keeps current value.

3~4: Refer to Description for 1 and 2.

The hundreds and thousands of this function code are respectively used to set reset control of Timer 1 and Timer 2.

0: Control by Timer Reset Terminal 1, when this terminal state is valid, the timing value of the timer is reset to zero.

1: Control by Timer Reset Terminal 2, when this terminal state is valid, the timing value of the timer is reset to zero.

The ten thousands of this function is used to set the timing unit. 0 indicates and 1 indicates second and minute respectively.

Refer to the explanation of 7.1.13 (Internal Timer Function).

Function code	Function Name	Setting scope	Factory Value
P3.2.24	Timing Time of Timer 1	0.0s~3600.0s	00000
P3.2.25	Timing Time of Timer 2	0.0s~3600.0s	00000

Function Code P3.2.24 and P3.2.25 are respectively used to set the time of Timer 1 and Timer 2.

Function code	Function Name	Setting scope	Factory Value
P3.2.26	Operation Module Operation Module	0: No Operation 1: Add Operation 2: Subtraction Operation 3: Multiply Operation 4: Division Operation 5: Greater than Judgment 6: Equal to Judgment 7: Equal to or Greater than Judgment 8: Integration 9~F: Reservation Ones: Operation 1 Tens: Operation 2 Hundreds: Operation 3 Thousands: Operation 4	0000

The ones, tens, hundreds and thousands of this function code respectively correspond to one-way operation. Each operation can select different operation methods. Refer to the explanation of 7.1.14 for more details (Internal Operation Function).

Function code	Function Name	Setting scope	Factory Value
P3.2.27	Operation Setting Coefficient Property	0: Operate the Setting Coefficient by multiplication without decimal 1: Conduct setting at one decimal fraction to system by multiplication algorithm 2: Conduct setting at two decimal fractions to system by multiplication algorithm 3: Conduct setting at three decimal fractions to system by multiplication algorithm 4: Conduct setting at four decimal fractions to system by multiplication algorithm 5: Conduct setting at no decimal fraction to system by division algorithm 6: Conduct setting at one decimal fractions to system by division algorithm 7: Conduct setting at two decimal fractions to system by division algorithm 8: Conduct setting at three decimal fractions to system by division algorithm Conduct setting at four decimal fractions to system by division algorithm Ones: Operation 1 Tens: Operation 2 Hundreds: Operation 3 Thousands: Operation 4	0000

The scope of the operation results is not certainly equal to the setting scope of the function codes of the frequency inverter, so a setting coefficient is required to set the scope of the operation results to the setting scope of the function codes of the frequency inverter. This function code is used to set the functions of the setting coefficient. The ones, tens, hundreds and thousands of this function code respectively correspond to one-way operation. Refer to the Description of 7.1.14 for more details (Internal Operation Function).



Function code	Function Name	Setting scope	Factory Value
P3.2.28	Input A of Operation 1	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.29	Input B of Operation 1	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.30	Setting Coefficient of Operation 1	00000~65535	00001

The above function codes are used to set input address and setting coefficient of Operation 1. The thousands, hundreds, tens and ones of Function Code P3.2.28 and Function Code P3.2.29 represent the address of Input A of Operation 1 and Input B of Operation 1 respectively. The input address corresponds to all function codes, e.g. Address 0005 corresponds to Function Code P0.0.05. If the input address has no corresponding function code, the default value in the input address is 0. The ten thousands in P3.2.28 and P3.2.29 indicate the operation mode of the digital value in input address. 0 means the operation by unsigned number and 1 means the operation by signed number.

Function Code P3.2.30 is used to set the setting coefficient of Operation 1.

Function code	Function name	Setting scope	Factory Value
P3.2.31	Input A of Operation 2	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 2 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.32	Input B of Operation 2	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 1 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.33	Setting Coefficient of Operation 2	00000~65535	00001

The above function codes are used to set the input address and setting coefficient of Operation 2. Refer to the explanation of Function Code P3.2.28~P3.2.30 for more details.

Function code	Function name	Setting scope	Factory Value
P3.2.34	Input A of Operation 3	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 3 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.35	Input B of Operation 3	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 3 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.36	Setting Coefficient of Operation 3	00000~65535	00001

The above function codes are used to set the input address and setting coefficient of Operation 3. Refer to the explanation of Function Code P3.2.28~P3.2.30 for more details.

Function code	Function name	Setting scope	Factory Value
P3.2.37	Input A of Operation 4	Thousands, Hundreds, Tens and Ones: express address of Input A of Operation 4 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.38	Input B of Operation 4	Thousands, Hundreds, Tens and Ones: express address of Input B of Operation 4 Ten Thousands: express input operation model 0: Input is operation by unsigned number 1: Input is operation by signed number	00000
P3.2.39	Setting Coefficient of Operation 4	00000~65535	00001

The above function codes are used to set the input address and setting coefficient of Operation 4. Refer to the explanation of Function Code P3.2.28~P3.2.30 for more details.

## 6.5 GROUP P4 PID CONTROL AND COMMUNICATION CONTROL

### P4.0 PID Control Group

Function code	Function Name	Setting scope	Factory Value
P4.0.00	PID Reference Source	0: Digital Reference (P4.0.01) 1: Keyboard Potentiometer Reference 2: External Terminal VF1 Reference 3: External Terminal VF2 Reference 4: PULS Reference (DI6) 5: Communication Reference 6: Multiplex Directive Terminal Reference 7: Simple PLC Reference 8: Operation Result 1 9: Operation Result 2 10: Operation Result 3 11: Operation Result 4	00

0: Digital Reference (P4.0.01)

PID Reference Value is determined by the value by Function Code P4.0.01.

1: Keyboard Potentiometer Reference

PID Reference Value is determined by Keyboard Potentiometer

1: External Terminal VF1 Reference

2: External Terminal VF2 Reference

PID Reference Value is set by the analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2). VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve between the input value of VF1 and VF2 and PID value, the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. The deviation between actual voltage and sampling voltage of the analog input terminal can be adjusted through Function Code P8.1.05~P8.1.12.

4: PULS Reference (DI6)

PID Reference Value is set by high-speed impulse frequency of digital input terminal DI6 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and PID value can be set through Function Code P2.0.23~P2.0.26, that is, linear relationship.

5: Communication Reference

PID Reference Value is set by the upper computer through communication mode (refer to Chapter VIII for more details).

6: Multiplex Directive Terminal Reference

PID Reference Value is given by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals (Terminal Function 9~12, refer to the explanation for Multiplex Directive Terminal Function of P2.0.00~P2.0.09 for more details)

7: Simple PLC Reference

PID Reference Value is given by Simple PLC Function, PID Reference of the frequency inverter can be switched among 1~16 arbitrary frequency directives, the sources, hold time and acceleration & deceleration time of each frequency directive can be set through Function Code 3.0.03~P3.0.50.

8: Operation Result 1

9: Operation Result 2

10: Operation Result 3

11: Operation Result 4

PID Reference Value is determined by the operation results after setting calculation of the internal operation module. Refer to the Description of Function Code P3.2.26~P3.2.39 for more details of the operation module. The operation results can be viewed through Function Code 9.0.46~P9.0.49.

Function code	Function Name	Setting scope	Factory Value
P4.0.01	PID Value Reference	000.0%~100.0%	050.0%

When at Function Code P4.0.00=0, PID Reference is determined by the value set by this function code.

Function code	Function Name	Setting scope	Factory Value
P4.0.02	PID Feedback Source	0: External Terminal VF1 Reference 1: External Terminal VF1 Reference 2: VF1-VF2 3: VF1+VF2 4: PULS Reference (DI6) 5: Communication Reference 6: MAX[VF1,VF2] 7: MIN[VF1,VF2] 8: Switch of Multiplex Directive Terminal on the above conditions 9: Operation Result 1 10: Operation Result 2 11: Operation Result 3 12: Operation Result 4	00

0: External Terminal VF1 Reference

1: External Terminal VF2 Reference

PID Feedback Value is set by the analog input terminal.

2: VF1-VF2

PID Feedback Value is set by the analog VF1-VF2 input.

3: VF1+VF2

PID Feedback Value is set by the analog F1+VF2 input.

4: PULS Reference

PID Reference Value is set by high-speed impulse frequency of digital input terminal DI6 (the terminal function is not defined). The corresponding relationship between high-speed impulse frequency and corresponding PID value can be set through Function Code P2.0.23~P2.0.26, that is, linear relationship.

5: Communication Reference

PID Reference Value is set by the upper computer through communication mode (refer to Chapter VIII for more details).

6: MAX[VF1, VF2]

PID Feedback Source is set by maximum value between Analog VF1 and VF2 Input.

7: MIN[VF1, VF2]

PID Feedback Source is set by minimum value between Analog VF1 and VF2 Input.

8: Multiplex directive terminal switches among the above among the above conditions

PID Reference Value switches among the above 8 kinds of conditions by different composite state of Multiplex Directive Terminal. E Series Frequency inverter is able to set four Multiplex Directive Terminals, when in use, it is to take three terminal functions (Terminal Function 9~11), refer to the table below for more details:

Terminal 3	Terminal 2	Terminal 1	Feedback channel
0	0	0	VF1 (correspond to P4.0.02=0)
0	0	1	VF2 (correspond to P4.0.02=1)
0	1	0	VF1-VF2 (correspond to P4.0.02=2)
0	1	1	VF1+VF2 (correspond to P4.0.02=3)
1	0	0	PULS reference (correspond to P4.0.02=4)
1	0	1	Communication Reference (correspond to P4.0.02=5)
1	1	0	MAX[VF1,VF2] (correspond to P4.0.02=6)
1	1	1	MIN[VF1,VF2] (correspond to P4.0.02=7)

- 9: Operation Result 1
- 10: Operation Result 2
- 11: Operation Result 3
- 12: Operation Result 4

PID Reference Value is determined by the operation results after setting calculation of the internal operation module. Refer to the explanation of Function Code P3.2.26~P3.2.39 for more details of the operation module. The operation results can be viewed through Function Code 9.0.46~P9.0.49.

Function code	Function Name	Setting scope	Factory Value
P4.0.03	PID Action Direction	0: Direct Action 1: Reverse Action	0

This function code is used to set the change conditions of the frequency with the feedback quantity.

0: Direct Action

The output frequency of the frequency inverter is in proportion to its feedback quantity, when the feedback quantity is less than the given quantity, the output frequency of the frequency inverter rises to make the feedback quantity rise accordingly and final feedback quantity equal to the given quantity.

1: Reverse Action

The output frequency of the frequency inverter is in inverse proportion to its feedback quantity, when the feedback quantity is greater than the given quantity, the output frequency of the frequency inverter rises to make the feedback quantity decline accordingly and final feedback quantity equal to the given quantity.

Function code	Function Name	Setting scope	Factory Value
P4.0.04	PID Reference Feedback Range	00000~65535	01000

The feedback range of PID Reference is dimensionless unit, which is the range of PID Reference showing P9.0.14 and PID Feedback showing P9.0.15. If P4.0.04 is set at 5000, when the feedback value of PID is 100.0%, PID Feedback showing P9.0.15 is 5000. PID Reference and Feedback are set based on this parameter.

Function code	Function Name	Setting scope	Factory Value
P4.0.05	Proportional Gains KPI	000.0~100.0	020.0
P4.0.06	Integral Time TI1	00.01s~10.00s	02.00
P4.0.07	Derivative Time Td1	00.000s~10.000s	00.000

The greater the value of proportional gain KPI is, the larger the adjustment volume is and the faster the response is, but the too large value can generate the system oscillation, the smaller the value of KPI is, the more stable the system is and the slower the response is.

The greater the value of Integral Time TI1 is, the slower the response is and the more stable the output is, the worse the fluctuation control ability of the feedback quantity is, the smaller the value of TI1 is, the faster the response is and the greater the output fluctuation is, the too small value can generate the oscillation.

The Derivative Time TD1 can set the limit for gain provided by the derivator to ensure that a pure derivative gain can be obtained at low frequency and a constant derivative gain can be obtained at high frequency. The longer the derivative time is, the greater the adjusting strength is.

Function code	Function Name	Setting scope	Factory Value
P4.0.08	PID Deviation Limit	000.0%~100.0%	000.0

This function code is used to determine whether PID is adjusted to prevent unstable output frequency when the deviation between reference and feedback is small.

When the deviation between reference quantity and feedback quantity is less than the value set by P4.0.08, stop the adjustment to PID and the frequency inverter keeps stable output.

When the deviation between reference quantity and feedback quantity is greater than the value set by P4.0.08, adjust PID.

Function code	Function Name	Setting scope	Factory Value
P4.0.09	PID Feedback Filtering time	00.00~60.00s	00.00

VF1 Input Filtering time is used to set the software filtering time of VF1, when the on-site analog is easily to be interrupted, the filtering time shall be increased to make the detected analog tend to be stable, but the greater filtering time makes the response speed of the analog detection become slow, how to set needs to balance based on actual situations of the applications.

Function code	Function Name	Setting scope	Factory Value
P4.0.10	Proportional Gains KP2	000.0~100.0	020.0
P4.0.11	Integral Time TI2	00.01s~10.00s	02.00
P4.0.12	Derivative Time Td2	00.000s~10.000s	00.000

The above function codes have the same functions with Function Code P4.0.05~P4.0.07, refer to the Description for P4.0.05~P4.0.07.

Function code	Function Name	Setting scope	Factory Value
P4.0.13	PID Switch Conditions	0: No Switch 1: Switch through Terminals 2: Switch through Deviation	0

In some occasions of special applications, better PID Parameter is required to be adopted for control under different conditions. This function code is used to set under what condition PID Parameter is required to be switched.

0: No Switch

Adopt PID parameters of P4.0.05~P4.0.07 by default.

1: Switch through Terminal

The switch is made through digital input terminal (set this terminal function at 41: switch of PID parameter). When the terminal signal is valid, adopt PID parameters of P4.0.05~P4.0.07. When the terminal signal is valid, adopt PID parameters of this group of P4.0.10~P4.0.12.


2: Switch based on Deviation

The switch is made based on setting value of Function Code P4.0.14 and P4.0.15, refer to the Description of Function Code P4.0.14 and P4.0.15.

Function code	Function Name	Setting scope	Factory Value
P4.0.14	PID Switch Deviation 1	000.0%~P4.0.15	020.0
P4.0.15	PID Switch Deviation 2	P4.0.14~100.0%	080.0


When at P4.0.13=2, it is to determine whether the switch of PID parameters needs to be done through these two function codes. The setting value of these two function codes is the percentage relative to Function Code P4.0.04 (PID Reference Feedback Range).

When the deviation between reference and feedback is less than PID Switch Deviation 1, adopt PID Parameter of P4.0.05~P4.0.07. When the deviation between reference and feedback is greater than PID Switch Deviation 2, adopt PID Parameter of P4.0.10~P4.0.12. When the deviation between reference and feedback is between PID Switch Deviation 1 and PID Switch Deviation 2, PID Parameter is the linear interpolation value of these two groups of PID Parameters, refer to the description of the figure below:



Function code	Function Name	Setting scope	Factory Value
P4.0.16	PID Initial Value	000.0%~100.0%	000.0
P4.0.17	PID Initial Value HoldTime	000.00~650.00s	000.00

When the frequency inverter starts, first speed it up to initial value of PID at acceleration time and then keep running at initial state of PID, after the duration of time reaches the time given by P4.0.17, conduct regulation to PID. Initial Value of PID is the percentage relative to the highest frequency, refer to the description of the figure below:



Function code	Function Name	Setting scope	Factory Value
P4.0.18	PID Feedback Loss Detection	000.0%: No Judgment on Feedback Loss 000.1%~100.0%	000.0
P4.0.19	PID Feedback Loss Detection Time	00.0s~20.0s	00.0



These two function codes are used to judge whether the feedback signal of PID is missing.

When at P4.0.18=0.0%, no judgment is made for whether the feedback signal of PID is missing.

When at P4.0.18>0.0%, actual PID Feedback Value is less than the value given by P4.0.18 and the duration of time exceeds the time given by P4.0.19, the frequency inverter gives an alarm of Err20 Fault, it is deemed that the feedback signal of PID is missing

Function code	Function Name	Setting scope	Factory Value
P4.0.20	PID Stop Operation	0: No Operation 1: Operation	0

This function code is used to set whether PID operates when the frequency inverter is in shutdown state.

0: No Operation

When the frequency inverter runs, PID operates; when the frequency inverter shuts down, PID can't operate (choose this under general conditions)

1: Operation

No matter what the state of the frequency inverter is, running state or shutdown state, PID operates.

#### P4.1 Communication Group

Function code	Function Name	Setting scope	Factory Value
P4.1.00	Baud Rate	0: 1200 1: 2400 2: 4800 3: 9600 4: 19200 5: 38400 6: 57600	3
P4.1.01	Data Format	0: No Verification (8-N-2) 1: Even Parity Verification (8-E-1) 2: Odd Parity Verification (8-O-1) 3: No Verification (8-N-1)	0
P4.1.02	Local Machine Address	000: Broadcast Address 001~249	001
P4.1.03	Response Delay	00~20ms	02
P4.1.04	Communication Timeout	00.0 (Invalid) 00.1s~60.0s	00.0
P4.1.05	Data Transmission Format	0: ASCII Mode (Reservation) 1: RTU Mode	1

When E Series inverter realizes the communication with other equipments through communication terminal RS-485, it is required to set the above function codes. Refer to Communication RS-485 of E Series Frequency inverter in Chapter VIII for more details.

## 6.6 Group P5 Keyboard Display

### P5.0 Basic Group

Function code	Function Name	Setting scope	Factory Value
P5.0.00	Keyboard JOG Key Function Reference	0: Invalid 1: Forward Jogging 2: Reverse Jogging 3: Forward and Reverse Switch	1

This function code is used to set the function of Multi-functional Key JOG.

When at P5.0.00=0, the function of Key JOG is invalid

When at P5.0.00=1, the function of Key JOG is forward jogging function

When at P5.0.00=2, the function of Key JOG is reverse jogging function

When at P5.0.00=3, the function of Key JOG is forward and reverse switch function

**Note: Forward Jogging Function and Reserve Jogging Function are valid under any running control mode, but the forward and reverse switch function is only valid under keyboard control mode (i.e. P0.0.03=0)**

Function code	Function Name	Setting scope	Factory Value
P5.0.01	Keyboard STOP Key Stop Function	0: Only valid in keyboard operation mode 1: Valid for any mode	1

This function code is used to set shutdown function of Key Stop.

When at P5.0.01=0, the shutdown function is only valid under Keyboard Control Mode (i.e. P0.0.03=0)

When at P5.0.01=1, the shutdown function is valid under any running control modes.


**N: the fault reset function is always valid.**

Function code	Function Name	Setting scope	Factory Value
P5.0.02	LED Running Display Parameter 1	H.0001~H.FFFF	H.001F
P5.0.03	LED Running Display Parameter 2	H.0000~H.FFFF	H.0000
P5.0.04	Automatic Time Switch of LED Running Display Parameter	000.0: No Switch 000.1s~100.0s	000.0


Function Code P5.0.02 and P5.0.03 determine the contents displayed by LED when the frequency inverter is at running state.

Function Code P5.0.04 determines the length of time that displays Parameter 1 and Parameter 2. When setting this to 0, only shown the display parameter given by P5.0.02, or it is to switch between display parameter set by P5.0.02 and display parameter set by P5.0.03 based on the reference time.

The format for specific display contents is as below:



In operation, if it is required to display each parameter above, set corresponding position to 1, after transfer binary system to hexadecimal system, set at P5.0.02.




In operation, if it is required to display each parameter above, set corresponding position to 1, after transfer binary system to hexadecimal system, set at P5.0.03.

Chapter 6 Description of Parameters

Function code	Function name	Setting scope	Factory value
P5.0.05	LED Shutdown Display Parameter	H.0001~H.FFFF	H.0033

This function code determines the contents displayed by LED when the frequency inverter is at shutdown state.

The format for specific display contents is as below:



Function code	Function Name	Setting scope	Factory Value
P5.0.06	LCD Line 1 Display at Running	0000~9399	9001
P5.0.07	LCD Line 2 Display at Running	0000~9399	9000
P5.0.08	LCD Line 3 Display at Running	0000~9399	9002
P5.0.09	LCD Line 4 Display at Running	0000~9399	9003

The above function codes are used to set the contents displayed by each line when the frequency inverter adopts LCD Keyboard at running state. The value given by P5.0.06~P5.0.09 is the parameter address required to display, e.g. if the reference value of Parameter P9.0.00 is needed to display in operation, it is to set one reference value of P5.0.06~P5.0.09 to 9000.

Function code	Function Name	Setting scope	Factory Value
P5.0.10	LCD Line 1 Display at stop	0000~9399	9001
P5.0.11	LCD Line 2 Display at stop	0000~9399	9000
P5.0.12	LCD Line 3 Display at stop	0000~9399	9004
P5.0.13	LCD Line 4 Display at stop	0000~9399	0000

The above function codes are used to set the contents displayed by each line when the frequency inverter adopts LCD Keyboard at shutdown state. The value given by P5.0.10~P5.0.13 is the parameter address required to display, e.g. if the reference value of Parameter P9.0.01 is needed to display when shut down , it is to set one reference value of P5.0.10~P5.0.13 to 9001.

Function code	Function name	Setting scope	Factory Value
P5.0.14	LCD Chinese/English Display Switch	0: Chinese 1: English	0

When the above function codes are used to set either Chinese Display or English Display when the frequency inverter adopts LCD Keyboard.

Function code	Function Name	Setting scope	Factory Value
P5.0.15	Customized Display of Coefficient	0.0001~6.5000	1.0000
P5.0.16	Customized Display of Decimal Point	0: 0-digit Decimal Point 1: 1-digit Decimal Point 2: 2-digit Decimal Point 3: 3-digit Decimal Point	1

In some conditions, the users want to let the frequency inverter not display the frequency, but some values that have linear relationship with frequency. The users can adjust the corresponding relation between display value and frequency of the frequency inverter through modification to Function Code P5.0.15. This display value is called Customized Display Value.

P5.0.16 is used to set the decimal places of customized display value.

e.g. The customized display coefficient of P5.0.15 is 0.5000, the customized display decimal point of P5.0.16 is 3, and the frequency is 20.00Hz, the customized display value shall be  $2000 * 0.5000 = 1.000$  (display three decimal points).

Chapter 6 Description of Parameters

Function code	Function name	Setting scope	Factory Value
P5.0.17	Selection Display of Function Parameter Group	Ones: 0: Only display basic group 1: Display the menus at all levels Tens 0: Don't display Group P7 1: Display Group P7 2: Reservation Hundreds: 0: Don't display correction parameter group 1: Display correction parameter group Thousands: 0: Don't display code group 1: Display code group Ten Thousands: Reservation	00011

When the function code is at P0.0.01=0, its function determine what the parameters of the function code is displayed in detail.

Function code	Function name	Setting scope	Factory Value
P5.0.18	Function Password Protection	0: Modifiable 1: Non-modifiable 2: Allowable Modification to GP Type	0

This function code is used to set whether the parameters of the frequency inverter can be modified.

When at P5.0.18=0, the parameters of all function codes can be modified;

When at P5.0.18=1, the parameters of all function codes can only be viewed but not be modified, such a way can effectively prevent the parameters of the function from incorrect modification.

When at P5.0.18=2, Function Code P0.0.00 is allowed to modify.

Function code	Function name	Setting scope	Factory Value
P5.0.19	Parameter Initialization	00: No Operation 01: Clearance of Record Information 09 Reset to Factory Parameter, excluding motor parameter, correction group, password group 19: Reset to Factory Parameter, excluding motor parameter, password group 30: Users Current Parameter Backup 60: Reset to User Backup Parameters 100~999: Reset to User Factory Parameters	000

0: No Operation

**1: Clearance of Record Information**

Clear fault record information, accumulative running time, accumulative power-on time and accumulative power consumption of the frequency inverter

**9: Reset to factory parameter, excluding motor parameter, correction group, password group**

The frequency inverter resets to factory parameter, excluding motor parameter, correction group, password group.

**19: Reset to Factory Parameter, excluding motor parameter, password group**

The frequency inverter resets to factory parameter, excluding motor parameter, password group.

**30: Users Current Parameter Backup**

Back up all current function parameters of the users to the memory, after the parameters adjustment in disorder, the user can easily reset the disordered parameters to back-up function parameters.

**60: Reset to User Backup Parameters**

Reset to the back-up user parameters last time, i.e. reset to the parameters that are backed up last time when P5.0.19 is set at 30.

**100~999: Reset to User Factory Parameters**

This function is used to reset special tailor-made factory parameter of the users. Generally, the users cannot conduct operation to this reset.

Function code	Function name	Setting scope	Factory Value
P5.0.20	User Password	00000~65535	00000

P5.0.20 is the user password reference, that is, any non-zero five digits, the password protection function becomes effective. When enter into the menu next time, if display “----” , input correct password and then view and modify the function parameters.

If you want to cancel the password protection, only use the password to enter into system and then change P5.0.20 into 00000, the password protection function becomes invalid.

**P5.1 Expansion Group**

Function code	Function name	Description of parameter	Display scope
P5.1.00	Accumulative Running Time	Display accumulated running time of frequency inverter	0h~65000h
P5.1.01	Accumulative Power On Time	Display accumulated electrifying time of frequency inverter since exworks	0h~65000h
P5.1.02	Accumulative Power Consumption	Display accumulated power consumption of frequency inverter up to now	0~65000
P5.1.03	Module Temperature	Display current temperature of the module	000℃~100℃
P5.1.04	Hardware Version No.	Hardware version number	180.00
P5.1.05	Software Version No.	Software version number	001.00
P5.1.06	Program Nonstandard Label	Version number of dedicated program	0000~9999

## 6.7 Fault Display and Protection Control Group P6

### P6.0 Fault Display Group

Function code	Function Name	Setting scope	Factory Value
P6.0.00	Fault Record 1 ( Last Time)	0~40	00
P6.0.01	Fault Record 2	0~40	00
P6.0.02	Fault Record 3	0~40	00

The above function codes record the fault types in the last three times, 0 indicates no fault. Concerning possible cause of each fault code and solutions, refer to related explanation of Chapter IX.

Function code	Function name	Description for Parameters													
P6.0.03	Fault Frequency 1	Frequency of the fault in the last time													
P6.0.04	Fault Current1	Current of the fault in the last time													
P6.0.05	Bus Voltage 1 when at Fault	Bus voltage of the fault in the last time													
P6.0.06	Input Terminal State 1 when at fault	<p>Input terminal state of the fault in the last time with the sequence as below</p> <table border="1" style="margin-left: 20px;"> <tr> <td>VF2</td><td>VF1</td><td>D11</td><td>D10</td><td>D19</td><td>D18</td><td>D17</td><td>D16</td><td>D15</td><td>D14</td><td>D13</td><td>D12</td><td>D11</td> </tr> </table> <p>When the input terminal is ON and its corresponding binary digit is 1. OFF is 0, it is to convert binary digit into denary digit.</p>	VF2	VF1	D11	D10	D19	D18	D17	D16	D15	D14	D13	D12	D11
VF2	VF1	D11	D10	D19	D18	D17	D16	D15	D14	D13	D12	D11			
P6.0.07	Output Terminal State 1 when at fault	<p>Input terminal state of the fault in the last time with the sequence as below</p> <table border="1" style="margin-left: 20px;"> <tr> <td>M5</td><td>M4</td><td>M3</td><td>M2</td><td>M1</td><td>YO2</td><td>YO1</td><td>T2</td><td>T1</td><td>YO</td> </tr> </table> <p>When the input terminal is ON and its corresponding binary digit is 1. OFF is 0, it is to convert binary digit into denary digit.</p>	M5	M4	M3	M2	M1	YO2	YO1	T2	T1	YO			
M5	M4	M3	M2	M1	YO2	YO1	T2	T1	YO						
P6.0.08	Frequency inverter State 1 when at fault	Use of manufacturer													
P6.0.09	Power-on Time 1 when at fault	Current power-on time of the fault in the last time													
P6.0.10	Running Time 1 when at fault	Current running time of the fault in the last time													



Function code	Function name	Description of parameter
P6.0.11	Fault Frequency 2	Same as P6.0.03~P6.0.10
P6.0.12	Fault Current2	
P6.0.13	Bus Voltage 2 when at Fault	
P6.0.14	Input Terminal State 2 when at fault	
P6.0.15	Output Terminal State 2 when at fault	
P6.0.16	Frequency inverter State 2 when at fault	
P6.0.17	Power-on Time 2 when at fault	
P6.0.18	Running Time 2 when at fault	
P6.0.19	Fault Frequency 3	
P6.0.20	Fault Current3	
P6.0.21	Bus Voltage 3 when at Fault	
P6.0.22	Input Terminal State 3 when at fault	
P6.0.23	Output Terminal State 3 when at fault	
P6.0.24	Frequency inverter State 3 when at fault	
P6.0.25	Power-on Time 3 when at fault	
P6.0.26	Running Time 3 when at fault	

### P6.1 Protection Control Group

Function code	Function Name	Setting scope	Factory Value
P6.1.00	Input Default Phase Protection	0: Prohibited 1: Allowed	1

This function code is used to set whether the frequency inverter protects the input default phase.

When at P6.1.00=0, the frequency inverter can't provide protection to input default phase.

When at P6.1.00=1, if the input default phase or three-phase input imbalance is detected out, the frequency inverter gives an alarm of Fault Err11. The allowable degree of three-phase input imbalance is determined by Function Code P6.1.26, the higher the value is, the duller the response is and the higher the allowed degree of three-phase imbalance is. Attention shall be paid that if the frequency inverter cannot operate or the load of the motor is lighter, even the setting value of P6.1.26 is set smaller, it is possible that no alarm is given.

Function code	Function Name	Setting scope	Factory Value
P6.1.01	Output Default Phase Protection	0: Prohibited 1: Allowed	1

This function code is used to set whether the frequency inverter protects the output default phase.

When at P6.1.01=0, the frequency inverter can't provide protection to output default phase.

When at P6.1.01=1, if the output default phase or three-phase input imbalance is detected out, the frequency inverter gives an alarm of Fault Err12.

Function code	Function Name	Setting scope	Factory Value
P6.1.02	Overvoltage Stall Protection Sensitivity	000: without protection to overvoltage and stalling speed 001~100	000
P6.1.03	Overvoltage Stall Protection Sensitivity	120%~150%	130

In the deceleration process of the frequency inverter, after the DC Bus Voltage exceeds over-voltage stall protection voltage point, the frequency inverter stops reducing the speed and keeps current running frequency until the bus voltage is reduced to below over-voltage stall protection voltage point and then the frequency inverter continues to reduce the speed. The setting value of Function Code P6.1.03 is the percentage relative to normal bus voltage.

Over-voltage stall protection sensitivity is used to adjust the ability of the frequency inverter on suppressing the overvoltage. The higher this value is, the stronger the ability of suppressing the overvoltage is.

Function code	Function Name	Setting scope	Factory Value
P6.1.04	Overvoltage Stall Protection Voltage Point	000: without protection to overcurrent and stalling speed 001~100	020
P6.1.05	Overcurrent Stall Protection Sensitivity	100%~200%	150

In the acceleration and deceleration process of the frequency inverter, after the output current exceeds the overcurrent stall protection current, the frequency inverter stops the acceleration and deceleration process and keeps current running frequency, and then continues to accelerate and decelerate after the decline of the output current. The setting value of the function code P6.1.05 is the percentage relative to rated current of the motor.

The Overcurrent Stall Protection Sensitivity is used to adjust the capability of the frequency inverter on restraining the overcurrent in its acceleration and deceleration process. The greater this value is, the stronger the capability of restraining the overcurrent is, under the precondition that no overcurrent fault occurs, the smaller the setting value is, and the better it is.

Function code	Function Name	Setting scope	Factory Value
P6.1.06	Fault Auto Reset Number	00: no auto-reset under failure 01~20	00
P6.1.07	Waiting Interval Time of Fault Auto Reset	000.1s~100.0s	001.0

When at P6.1.06=0, the frequency inverter keeps fault state for there is no automatic fault reset function.

When at P6.1.06>0, the frequency inverter selects the times of automatic fault reset. In case of exceeding the selected times, the frequency inverter keeps fault state.

Function P6.1.07 refers to the waiting time from fault alarm of the frequency inverter to automatic fault reset.

Function code	Function Name	Setting scope	Factory Value
P6.1.08	Fault Protective Action Selection 1	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Motor Overload Tens: Input Default Phase Hundreds: Output Default Phase Thousands: External Default Ten Thousands: Communication Abnormality	00000
P6.1.09	Fault Protective Action Selection 2	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Motor Overload Tens: Feedback Loss Hundreds: User Customized Fault 1 Thousands: User Customized Fault 2 Ten Thousands: Power-on Time Arrival	00000
P6.1.10	Fault Protective Action Selection 3	Ones: Running Time Arrival 0: Free Stop 1: Stop by its Mode 2: Continuous Running Tens: Encoder Abnormality 0: Free Stop Hundreds: Parameter Read-Write Abnormity 0: Free Stop 1: Stop by its Mode Thousands: Motor Overhear 0: Free Stop 1: Stop by its Mode 2: Continuous Running Ten Thousands: Fault of 24V Power Supply 0: Free Stop 1: Stop by its Mode	00000
P6.1.11	Fault Protective Action Selection 4	0: Free Stop 1: Stop by its Mode 2: Continuous Running Ones: Larger Speed Deviation Tens: Motor Overspeed Hundreds: Initial Position Error Thousands: Reservation Ten Thousands: Reservation	00000

The above function codes are used to set the actions of the frequency inverter after fault alarm. Each digit among the options for fault protection action corresponds to a kind of fault protection, if it is 0, it indicates that the frequency inverter stops freely; if it is 1, it indicates that the frequency inverter shuts down in stop mode after fault alarm; if it is 2, it indicates that the frequency inverter continues to run at frequency selected by Function Code P6.1.12 after fault alarm.

Function code	Function Name	Setting scope	Factory Value
P6.1.12	Continuous Running Frequency Selection when at Fault	0: Running at Current Frequency 1: Running at Reference frequency 2: Running at Upper Frequency 3: Running at Lower Frequency 4: Running at Back Frequency for Abnormality	0

When the frequency inverter breaks down in the running process, if the handling mode of this fault is continuous running, the frequency inverter displays A\*\* (A\*\* is its fault code), it continues to run at frequency selected by P6.1.12. If the handling mode of this fault is shut-down by reducing the speed, the frequency inverter displays A\*\* in the process of deceleration, the stop state display Err\*\*.

0: Run at Current Frequency

When the frequency inverter gives an alarm of fault, run at current frequency

1: Run at Reference Frequency

When the frequency inverter gives an alarm of fault, run at reference frequency

2: Run at Upper Frequency

When the frequency inverter gives an alarm of fault, run at upper frequency

3: Run at Lower Frequency

When the frequency inverter gives an alarm of fault, run at lower frequency

4: Run at Standby Frequency for Abnormality

When the frequency inverter gives an alarm of fault, run at frequency set by Function Code

P6.1.13.

Function code	Function Name	Setting scope	Factory Value
P6.1.13	Backup Frequency for Abnormality	000.0%~100.0%	100.0


When at Function Code P6.1.12=4, the setting value of this function code determines the running frequency when the frequency inverter gives an alarm of fault, which is the percentage relative to highest frequency.

Function code	Function Name	Setting scope	Factory Value
P6.1.14	Action Selection for Momentary Interruption	0: Invalid 1: Deceleration 2: Stop by Deceleration	0
P6.1.15	Judgment Time of Momentary Interruption Voltage Recovery	000.00s~100.00s	000.50
P6.1.16	Voltage Judgment for Momentary Interruption Action	60.0%~100.0% (Standard Bus Voltage)	080.0
P6.1.17	Voltage Judgment for Suspension of Momentary Action	80.0%~100.0% (Standard Bus Voltage)	090.0

When at P6.1.14=0, the frequency inverter continues to run at current frequency in interrupt power-supply or sudden reduction of voltage.

When at P6.1.14=1, in case of interrupt power-supply or sudden reduction of voltage, after the bus voltage reduces to corresponding voltage of the setting value of P6.1.16 below, the frequency inverter slows down and runs; after the bus voltage resets to corresponding voltage of the setting value of P6.1.16 above and the duration of time exceeds the time set by P6.1.15, the frequency inverter runs after it is normally accelerated to reference frequency. In the process of deceleration, if the bus voltage resets to corresponding voltage of the setting value of P6.1.17, the frequency inverter stops slowing down and keeps running at current frequency.

When at P6.1.14=2, in case of interrupt power-supply or sudden reduction of voltage, after the bus voltage reduces to below corresponding voltage of the setting value of P6.1.16, the frequency inverter slows down and runs; after it slows down to 0Hz and the bus voltage hasn't recovered, the frequency inverter stops.



Function code	Function Name	Setting scope	Factory Value
P6.1.18	Off-load Protection Selection	0: Valid 1: Invalid	0
P6.1.19	Off-load Detection Level	00.0%~100.0% (Motor Rated Rotating Speed)	010.0
P6.1.20	Off-load Detection Time	0.0s~60.0s	01.0

The Function Code P6.1.18 is sued to set whether the off-load protection function is valid, 0 and 1 respectively indicates invalid and valid.

If the off-load protection function is valid and the fault handling mode is continuous run or stop by speed reduction, when the output current of the frequency inverter is less than corresponding current value of off-load detection level of P6.1.19 and the duration is over off-load detection level of P6.1.20, the output frequency of the frequency inverter automatically reduces to 7% of rated frequency, the frequency inverter gives an alarm of A19 in running or decelerating state; in shutdown state, the frequency inverter gives an alarm of Err19, if the load is recovered, the frequency inverter is automatically recovered to run at reference frequency.

Function code	Function Name	Setting scope	Factory Value
P6.1.21	Overspeed Detection	0.0%~50.0% (maximum frequency)	20.0
P6.1.22	Overspeed Detection Time	0.0s~60.0s	01.0

This function is only valid when the frequency inverter runs with speed sensor vector control. When the frequency inverter detects out actual speed of the motor over reference frequency and the exceeding value is greater than corresponding speed of speed detection value P6.1.21 and the duration is over speed detection value P6.1.22, the frequency inverter gives an alarm of Fault Err29 and the handling to fault is conducted based on fault protection action mode.

Function code	Function Name	Setting scope	Factory Value
P6.1.23	Speed Deviation greater than Detection Value	0.0%~50.0% (maximum frequency)	20.0
P6.1.24	Speed Deviation greater than Detection Time	0.0s~60.0s	05.0

This function is only valid when the frequency inverter runs with speed sensor vector control. When the frequency inverter detects out the deviation between actual speed of the motor and reference frequency, if the deviation value is greater than detection value P6.1.23 of excessive speed deviation and the duration is longer than detection time P6.1.24 of excessive speed deviation, the frequency inverter gives an alarm of Fault Err28 and the handling to fault is conducted based on fault protection action mode. When the detection time of excessive speed deviation is 0.0s, this function is invalid.

Function code	Function Name	Setting scope	Factory Value
P6.1.25	Fault Output Terminal Action Selection during Fault Auto Reset Period	0: No Action 1: Action	0

This function code is used to set whether the fault output terminals act during the period of automatic fault reset.

When at P6.1.25=0, the fault output terminals cannot act during the period of automatic fault reset.

When at P6.1.25=1, the fault output terminals act during the period of automatic fault reset. After automatic fault reset, the fault output terminals also reset.

## 6.8 Group P7 User Function Customization

### P7.0 Basic Group

Function code	Function Name	Setting scope	Factory Value
P7.0.00	User Function 0	U0.0.01	U0.0.01
P7.0.01	User Function 1	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.02
P7.0.02	User Function 2	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.03
P7.0.03	User Function 3	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.07
P7.0.04	User Function 4	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.08
P7.0.05	User Function 5	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.17
P7.0.06	User Function 6	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.18
P7.0.07	User Function 7	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.08	User Function 8	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.09	User Function 9	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.10	User Function 10	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.11	User Function 11	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.12	User Function 12	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.13	User Function 13	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.14	User Function 14	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.15	User Function 15	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.16	User Function 16	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.17	User Function 17	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.18	User Function 18	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.19	User Function 19	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.20	User Function 20	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.21	User Function 21	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.22	User Function 22	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.23	User Function 23	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.24	User Function 24	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.25	User Function 25	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.26	User Function 26	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.27	User Function 27	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.28	User Function 28	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00
P7.0.29	User Function 29	U0.0.00~UX.X.XX (exclude P7, P8)	U0.0.00

The function codes of this group are User Customized Parameter Group. The users can summarize the parameters of the function codes (except Group P7 and P8) selected from function codes for display to Group P7.0 as User Customized Parameter for easy operation as view and medication, and the User Customized Parameter Group is not more than 30.

## 6.9 Group P8 Manufacturer Function

### P8.0 Manufacturer Function

Function code	Function Name	Setting scope	Factory Value
P8.0.00	Manufacturer Code	00000~65535	00000

This function code is the manufacturer password entry and displays dedicated function code of the manufacturer, the users don't operate it.

### P8.1 Correction Group

Function code	Function Name	Setting scope	Factory Value
P8.1.00	Voltage Input of Potentiometer Correction Point 1	00.00V~P8.1.02	00.00
P8.1.01	Corresponding reference of Potentiometer Correction Point 1	-100.0%~100.0%	000.0
P8.1.02	Voltage Input of Potentiometer Correction Point 2	P8.1.00~10.00V	10.00
P8.1.03	Corresponding reference of Potentiometer Correction Point 2	-100.0%~100.0%	100.0
P8.1.04	Filtering time of potentiometer	00.00s~10.00s	00.10

The function codes of this group are used to correct the potentiometer to get rid of the impact of zero-offset or voltage attenuation caused by overlong keyboard lines. When leaving the factory, the function parameters of this group have been corrected, when resetting to factory value, the reset value is the value after factory correction. Generally, the application site is not required to conduct correction.

Function code	Function Name	Setting scope	Factory Value
P8.1.05	VF1 actual voltage 1	0.500V~4.000V	2.000
P8.1.06	VF1 indicated voltage 1	0.500V~4.000V	2.000
P8.1.07	VF1 actual voltage 2	6.000V~9.999V	8.000
P8.1.08	VF1 indicated voltage 2	6.000V~9.999V	8.000
P8.1.09	VF2 actual voltage 1	0.500V~4.000V	2.000
P8.1.10	VF2 indicated voltage 1	0.500V~4.000V	2.000
P8.1.11	VF2 actual voltage 2	6.000V~9.999V	8.000
P8.1.12	VF2 indicated voltage 2	6.000V~9.999V	8.000

The function codes of this group are used to correct analog input VF to get rid of the impact of VF input zero-offset or gain. When leaving the factory, the function parameters of this group have been corrected, when resetting to factory value, the reset value is the value after factory correction. Generally, the application site is not required to conduct correction.

Actual Voltage: use the measuring instruments to measure the voltage between terminal VF and terminal GND, such as multi-meter, etc.

Voltage Display: the voltage display value from the sampling of the frequency inverter refers to voltage (P9.0.19, P9.0.20)display before VF correction of Group P9.

When correcting, input two voltage values on each VF input terminal and then input actually measured voltage value and display voltage to corresponding function codes, the frequency inverter can conduct correction automatically.



Function code	Function Name	Setting scope	Factory Value
P8.1.13	FM1 target voltage 1	0.500V~4.000V	2.000
P8.1.14	FM1 actual voltage 1	0.500V~4.000V	2.000
P8.1.15	FM1 target voltage 2	6.000V~9.999V	8.000
P8.1.16	FM1 actual voltage 2	6.000V~9.999V	8.000
P8.1.17	FM2 target voltage 1	0.500V~4.000V	2.000
P8.1.18	FM2 actual voltage 1	0.500V~4.000V	2.000
P8.1.19	FM2 target voltage 2	6.000V~9.999V	8.000
P8.1.20	FM2 actual voltage 2	6.000V~9.999V	8.000

The function codes of this group are used to correct analog output FM. If the correction has been done when leaving the factory, when resetting to factory value, the reset value is the value after factory correction. Generally, the application site cannot need to conduct correction.

Actually Measured Voltage: use the measuring instruments to measure the voltage between terminal VF and terminal GND, such as multi-meter, etc.

Target Voltage: refer to theoretical voltage value of the frequency inverter based on corresponding relationship of analog output.

When correcting, output two voltage values on each FM terminal and then input actually measured voltage value and target voltage to corresponding function codes, the frequency inverter can conduct correction automatically.

## 6.10 Group P9 Monitoring Parameter

### P9.0 Basic Monitoring Parameter

P9 Parameter Group is used to monitor running state information of the frequency inverter, the users can set corresponding parameter as required, which can not only be rapidly viewed through panel for easy debugging and maintenance on site, but also read through communication for monitoring of upper computer.


Function code	Function name	Description	Unit
P9.0.00	Running Frequency	Output frequency when the frequency inverter runs	0.01Hz
P9.0.01	Reference frequency	Reference frequency of the frequency inverter	0.01Hz
P9.0.02	Output Current	Output current when the frequency inverter runs	0.01A
P9.0.03	Output Voltage	Output current when the frequency inverter runs	1V
P9.0.04	Bus Voltage	Voltage on DC Bus of the frequency inverter	0.1V
P9.0.05	Output Torque	When the frequency inverter runs, the output torque is the percentage of rated torque of the motor	0.1%
P9.0.06	Output Power	Output frequency when the frequency inverter runs	0.1kW
P9.0.07	Input Terminal Status	Check whether the input terminal has signal input	
P9.0.08	Output Terminal Status	Check whether the output terminal has signal output	
P9.0.09	VF1 Voltage	Check the voltage between VF1 and GND	0.01V
P9.0.10	VF2 Voltage	Check the voltage between VF2 and GND	0.01V
P9.0.11	Custom Display Value	Display coefficient P5.0.15 and the value after conversion of Decimal Point P5.0.16 through customization	
P9.0.12	Actual Counting Value	View actual counting value of the frequency inverter for counting function	1
P9.0.13	Actual Length Value	View actual counting value of the frequency inverter for fixed-length function	1m
P9.0.14	PID Reference	Product of PID reference value and PID reference feedback quantity	
P9.0.15	PID Feedback	Product of PID feedback value and PID reference feedback rang	
P9.0.16	PULS Impulse frequency	View the frequency of PULSE Impulse Input	0.01kHz
P9.0.17	Feedback Speed	Actual output frequency when the frequency inverter runs	0.1Hz
P9.0.18	PLC Stage	Display which stage the Simple PLC runs at	1
P9.0.19	Voltage before Vf1 Correction	Voltage between VF1 and GND before Vf1 correction	0.001V
P9.0.20	Voltage before Vf2 Correction	Voltage between VF2 and GND before VF2 correction	0.001V
P9.0.21	Line Speed	The sampling line speed of DI6 impulse is equal to the acquisition of impulse count per minute/ per meter	1m/min
P9.0.22	Current Power-on Time	Length of current power-on time	1min
P9.0.23	Current Running Time	Length of current running time	0.1min
P9.0.24	Residual Running Time	Residual running time at Timing Function of P3.1.00	0.1min
P9.0.25	Frequency of Frequency Source A	View the frequency given by Frequency A	0.01Hz

Function code	Function name	Description	Unit
P9.0.26	Frequency of Frequency Source B	View the frequency given by Frequency B	0.01Hz
P9.0.27	Communication Set value	The value set by corresponding communication address A001 is the percentage of the highest frequency	%
P9.0.28	Impulse frequency	View the frequency of PULSE Impulse Input	1Hz
P9.0.29	Encoder Feedback Speed	Actual running frequency of the motor from feedback of the encoder	0.01Hz
P9.0.30	Actual Distance Value	View actual distance value of the distance value of the frequency inverter	
P9.0.31~P9.0.45	Reservation		
P9.0.46	Operation Result 1	Check the value of operation result 1	
P9.0.47	Operation Result 2	Check the value of operation result 2	
P9.0.48	Operation Result 3	Check the value of operation result 3	
P9.0.49	Operation Result 4	Check the value of operation result 4	
P9.0.50	User Standby Monitoring Value 1	Check the value of user special function	
P9.0.51	User Standby Monitoring Value 2	Check the value of user special function	
P9.0.52	User Standby Monitoring Value 3	Check the value of user special function	
P9.0.53	User Standby Monitoring Value 4	Check the value of user special function	
P9.0.54	User Standby Monitoring Value 5	Check the value of user special function	


**Corresponding Relationship of Input and Output Terminal State**

Whether the vertical line of the digital tube of each digit lights on, it indicates that whether the input and output terminal of each digit has the signal or not. If it lights on, it indicates that corresponding input terminal of this vertical line has signal input or the output terminal has signal output.

The display rules of Function Code P9.0.07 are shown as below:



The display rules of Function Code P9.0.08 are shown as below:  
(M is internal Intermediate Delay Relay)



## Chapter 7 Common Function and Application Case

### 7.1 Common Function

#### 7.1.1 Start and Stop Control

E Series Frequency inverter has three kinds of start and stop control modes: keyboard control, terminal control and communication control.

##### 1.Keyboard Control (Set P0.0.03=0)

Press “RUN” Key on the keyboard, the frequency inverter starts; press “ Stop” Key on the keyboard, the frequency inverter stops; the running direction is controlled by Function Code P0.0.06, it is forward rotation when at P0.0.06=0 and it is reverse rotation when at P0.0.06=1.

##### 2.Terminal Control (Set P0.0.03=1)


Provide four kinds of terminal start and stop modes for option of the users: two-line mode 1, two-line mode 2, three-line mode 1 and three-line mode 2. Specific use methods are as below:

##### ● Two-line Mode 1 (Set P2.0.11=0)

Any two terminals of DIx and DIy among multifunctional terminals are used to determine forward and reverse running of the more and all are the active level. The terminal function references are as below:

Terminal	Reference Value	Description
DIx	1	Forward Running (FWD)
DIy	2	Reverse Running (REV)

K1	K2	Run Command
0	0	Stop
0	1	REV
1	0	FWD
1	1	Stop




● Two-line Mode 2 ( Set P2.0.11=1)

Any two terminals of DIx and DIy among multifunctional terminals are used to determine forward and reverse running of the motor, in which Terminal DIx is used as running enable terminal and DIy is used as terminal of confirming the running direction, all are the active level. The terminal function references are as below:

Terminal	Reference Value	Description
DIx	1	Forward Running (FWD)
DIy	2	Reverse Running (REV)


K1	K2	Run Command
0	0	Stop
0	1	Stop
1	0	REV
1	1	Forward



● Three-line Mode 1 ( Set P2.0.11=2)

Any three terminals of DIx, DIy and DIIn among multifunctional terminals are used to determine forward and reverse running of the motor, in which Terminal DIx is used as running enable terminal and DIx & DIy are used as terminal of confirming the running direction, DIIn is the active level and DIx & DIy are the active PLS. When the running is needed, the Terminal DIIn must be closed at first and then the PLS of DIx or DIy are used to realize forward or reverse control of the motor. When the shutdown is needed, it is realized through disconnecting the signal of Terminal DIIn. The terminal function references are as below:

Terminal	Reference Value	Description
DIx	1	Forward Running (FWD)
DIy	2	Reverse Running (REV)
DIIn	3	3-line Running Control




SB1 is the button of normally opened forward running, SB2 is the button of normally opened reverse running and SB3 is the button of normally closed stop.

● 3-line Control Mode 2 (Set P2.0.11=3)

Any three terminals of DIx, DIy and DIIn among multifunctional terminals are used to determine forward and reverse running of the motor, in which Terminal DIIn is used as enable terminal, DIx is used as running terminal and DIy is used as terminal of confirming the running direction, DIIn and DIx are the active level and DIy is the active PLS. When the running is needed, the Terminal DIIn must be closed at first and then the PLS of DIx is used to realize the running of the motor and the state of DIy is used to determine the running direction. When the shutdown is needed, it needs to be realized through disconnecting the signal of Terminal DIIn. The terminal function references are as below:

Terminal	Reference Value	Description
DIx	1	Forward Running (FWD)
DIy	2	Reverse Running (REV)
DIIn	3	3-line Running Control



SB1 is the button of normally opened forward running, SB3 is the button of normally closed stop and K is the button of running direction option

**3. Communication Control (Set P0.0.03=2)**

The start, stop, FWD and REV of the frequency inverter is realized by the upper computer through Communication Mode RS-485. E Series Frequency inverter supports Standard MODBUS Protocol, refer to Chapter VIII Communication RS-485 for more details.


**7.1.2 Start and Stop Mode**

**1. Start Mode**

E Series Frequency inverter has three kinds of start modes: direct start, speed tracking start and start after brake.


● Direct Start (Set P1.0.10=0)

The frequency inverter starts according to given start frequency (P1.0.12)and start frequency hold time (P1.0.13)and then speeds up to the reference frequency according to the selected acceleration time.




● Speed Tracking Start (Set P1.0.10=1)

The frequency inverter starts the speed tracking according to the speed tracking mode given by speed tracking mode P1.0.11 to track the running speed of the motor at which the frequency inverter starts until being accelerated or decelerated to reference frequency. When the motor hasn't stopped stably or is unable to stop, this function shall be adopted.



● Speed Tracking Start (Set P1.0.10=2)

Before starting the motor normally, the frequency converter firstly deploys DC braking in accordance with the data set up in the parameters about starting DC braking current (P1.0.14) and starting DC braking time (P1.0.15). If the motor rotates reversely at low speed before starting, this function shall be used when starting the motor by rotating it forward.



## 2. Stop Mode


E Series Frequency inverter has two kinds of shutdown modes: Deceleration Stop and Free Stop

### ● Deceleration Stop (Set P1.0.16=0)

After the stop command is effective, the frequency inverter reduces the output frequency according to the selected deceleration time, and it stops when the output frequency is reduced to 0.


When it is required to prevent the frequency inverter from sliding and jittering when it quickly stops or stops at low speed, the stop DC brake function can be used, after the frequency inverter is reduced to frequency given by P1.0.17, it is to wait for the time given by P1.0.18 and start DC brake at current given by P1.0.19 until the time given by P1.0.20 is reached and then the frequency inverter stops DC brake.

When it is required to quickly stop at high speed, the dynamic braking shall be adopted. The built-in brake units of E Series Frequency inverter 15kW and below set the parameters of brake utilization rate P1.0.21 and externally connect brake resistance to adopt dynamic braking; the frequency inverters with power above 15kW can adopt dynamic braking only when they are configured with brake units and brake resistance. Refer to Appendix A2.5 for externally configured brake units and brake resistance.



### ● Free Stop (Set P1.0.16=1)

After the stop command is effective, the frequency inverter immediately terminates the output and the motor stop freely by mechanical inertia. The users haven't had the stop requirements for load or when the load itself has the brake function, the function of free stop can be selected.





### 7.1.3 Acceleration and Deceleration Mode

Different load characteristics have different requirements for acceleration and deceleration time, E Series Frequency inverter provides three kinds of acceleration and deceleration modes: Straight Line, Curve S 1 and Curve S 2, which are selected through Function Code P0.1.19. Additionally, the acceleration and deceleration time unit can be adjusted and set through Function Code P0.2.03.

- Straight Line (Set P0.1.19=0)

Start the linear speed from start frequency to reference frequency. E Series Frequency inverter provides four kinds of linear acceleration and deceleration modes, which can be switched among different terminal combinations that are selected through acceleration and deceleration time.

- Curve S 1 (Set P0.1.19=1)

The output frequency increases or decrease by Curve S. Curve S is the used for occasions required gentle start or stop. Parameter P0.1.20 and P0.1.21 respectively define the time scale of starting period and ending period of Curve S 1.

- Curve S 2 (Set P0.1.19=2)

In acceleration and deceleration of Curve S, the rated frequency of the motor is always the inflection point of Curve S. Generally, it is used for occasions that the high-speed areas above rated frequency require acceleration and deceleration.

### 7.1.4 Jogging Function

E Series Frequency inverter provides two kinds of the modes to realize jogging function: Keyboard Control and Terminal Control.

- Keyboard Control

Set the function of multi-functional Key JOG as forward jogging or reverse jogging (P5.0.00=1or 2).The frequency inverter can use Key JOG to realize Jogging Function when it stops, and the jogging running frequency and acceleration and deceleration time can be set through Function Code P0.1.08~P0.1.10.

- Terminal Control


Set the function of multi-functional Dix and DIy as forward jogging or reverse jogging. When the frequency inverter stops, it can use Dix and DIy to realize Jogging Function, and the jogging running frequency and acceleration and deceleration time can be set through Function Code P0.1.08~P0.1.10.

**Note: The jogging function of the above reference modes is the jogging effect when the frequency inverter is at stop state. If the frequency inverter is required to be at running state and the priority is given to the effect of Jogging Function, it is to set Function Code P0.1.25=1.**

### 7.1.5 Running Frequency Control


E Series Frequency inverter provides two Frequency Source Input Channels, that is, Frequency Source A and Frequency Source B respectively, they not only can work independently, but in combination mode through computer. Each frequency source has 14 kinds of references for option, so the optional requirements for different frequencies at different sites can be greatly satisfied. The factory default of the frequency inverter is Frequency Source A Reference. When two frequency sources are combined, Frequency Source A is main channel and Frequency Source B is auxiliary channel by default

Detailed explanation for realization process of frequency selection is shown as the figure below:




### 7.1.6 Multi-speed Function

E Series Frequency inverter can realize the switch of 16-stage speed at most through different combination state of multiplex directive terminal. As for missing set digit, the calculation is made at state 0.



### 7.1.7 Simple PLC

E Series Frequency inverter can automatically run at 16-stage speed at most, the acceleration and deceleration time and the length of running time of each stage can be set independently (refer to Function Code P3.0.03~P3.0.50). Additionally, the times of cycle required can be set through P3.0.00 and P3.0.01.



**7.1.8 Timing Function**

Function Code	Function name	Setting Scope	Factory Value
P3.1.00	Timing Function Selection	0: Invalid 1: Valid	0
P3.1.01	Tinning Running Time Selection	0: Digital Reference (P3.1.02) 1: External Terminal VF1 Reference 2: External Terminal VF2 Reference (Analog input range corresponds to P3.1.02)	0
P3.1.02	Tinning Running Time	0000.0min~6500.0min	0000.0

E Series Frequency inverter has built-in Timing Function to complete its timing running.


Function Code P3.1.00 determines whether the timing function is valid.

Function Code P3.1.01 determines the source of fixed running time.

When at P3.1.01=0, the fixed running time is given by the value set by Function Code P3.1.02.

When at P3.1.01=1 or 2, the fixed running time is given by external analog input terminal. E Series Frequency inverter provides 2-way analog input terminal (VF1, VF2). VF1 and VF2 can input 0V~10V voltage or 0/4mA~20mA current. As for corresponding relation curve between the input of VF1 and VF2 and fixed running time, the users can freely choose from four kinds of the relation curves through function code P2.1.02, in which Curve 1 and Curve 2 are linear relationship able to be set through Function Code P2.0.13~P2.0.22, and Curve 3 and Curve 4 are broken line relationship with two inflection points able to be set through Function Code P2.1.04~P2.1.19. At this time, the analog input range corresponds to the value given by Function Code P3.1.02.

When the Timing Function is effective, the frequency inverter needs to restart timing for every start, when reaching the reference time, the frequency inverter stops automatically. During the process of stop, the multi-functional output terminals of the frequency inverter output Signal ON. When the stop process ends, multi-functional output terminals output Signal OFF. Corresponding multi-functional output terminals are Timing Arrival Output (30). When the reference time is 0, the fixed time is not limited. Actual time of current running can be viewed through Function Code P9.0.23 (when the frequency inverter shuts down, the display value of P9.0.23 automatically resets to 0).



### 7.1.9 Fixed-length Function

Function Code	Function name	Setting Scope	Factory Value
P3.1.08	Reference Length	00000m~65535m	01000
P3.1.09	Actual Length	00000m~65535m	00000
P3.1.10	Impulse Count per meter	0000.1~6553.5	0100.0


E Series Frequency inverter has built-in fixed-length function to realize fixed-length control. In the application, corresponding digital input terminal is required to be set as “Length Counting Input” (Function 30). When the input impulse frequency is higher, Terminal DI16 must be adopted. The formula for length calculation is as below:

$$\text{Actual Length} = \text{Total Impulses from Acquisition of Terminal} / \text{Impulses per meter}$$

When actual length reaches the reference length (value set by P3.1.08), the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is Length Arrival (10).

In the process of fixed-length control, the reset operation to actual length can be realized through digital input terminal. Corresponding digital input terminal function is Length Reset (31).

Actual length can be viewed through Function Code P3.1.09 or P9.0.13.



**7.1.10 Counting Function**

Function Code	Function name	Setting Scope	Factory Value
P3.1.11	Reference Count Value	00001~65535	01000
P3.1.12	Designated Count Value	00001~65535	01000


The counting function of E Series Frequency inverter has two-level signal output, that is, reference counting value arrival and designated counting value arrival. In the application, corresponding digital input terminal function is required to be set as “Counter Input” (Function 28). When the impulse frequency is higher, Terminal DI6 must be adopted.

When actual counting value reaches the reference value (set by P3.1.11), the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is Reference Counting Value Arrival (8).

When actual counting value reaches the reference value (set by P3.1.12), the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is Reference Counting Value Arrival (9).

In the counting process, the reset operation to actual counting value can be realized through digital input terminal. Corresponding digital input terminal function is Counter Reset (29)

Actual counting value can be viewed through Function Code P9.0.12.



**7.1.11 Distance Control Function**

Function Code	Function name	Setting Scope	Factory Value
P3.1.13	Distance Set value 1	-3200.0~3200.0	0000.0
P3.1.14	Distance Set value 2	-3200.0~3200.0	0000.0
P3.1.15	Impulse Count per Distance	000.00~600.00	000.00

E Series Frequency inverter has built-in Distance Control Function. In the application, corresponding digital input terminal function is required to be set as “Encoder A Input” (Function 52) and “Encoder B Input” (Function 53). Terminal DI5 and DI6 of CDI-E100 Series can connect high-speed impulse of the encoder, the impulse frequency of the encoder of other terminals is not allowed more than 200Hz. The impulse frequency of the encoder of other terminals is not allowed more than 200Hz. In case of exceeding 200Hz, the open-collector encoder expansion card is required to be configured (set P0.1.26=10). The phase sequence of the encoder determines the plus-minus of actual distance.

$$\text{Actual Distance} = \pm \text{Total Impulses from Acquisition of Terminal} / \text{Impulses per distance}$$


For the digital tube has five digits, when the distance is less than -999.9, all displayed decimal points of the digital tube completely indicate minus value, e.g. “1.0.1.0.0” means -1010.0.

When actual distance reaches the set value 1 (value set by P3.1.13), the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is the Distance Set Value 1 Arrival (56).

When actual distance reaches the set value 2 (value set by P3.1.14), the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is the Distance Set Value 2 Arrival (57).


In the process of distance control, the reset operation to actual distance can be realized through digital input terminal. Corresponding digital input terminal function is the Distance Reset (54).

Actual distance can be viewed through Function Code P9.0.30.



**7.1.12 Simple Internal Relay Programmable Function**

E Series Frequency inverter has five built-in virtual Intermediate Delay Relays, which not only can collect the physical signals of digital input terminal of the frequency inverter, but virtual signals of multi-functional output terminals (00~59). And then it is to conduct simple logic running and output the results to multi-functional output terminals or equivalent digital input terminal.




Description for Control Logic Function of Intermediate Delay Relay Control Word B

Function code	Setting value for unit's digit	Function	Description
P3.2.02 P3.2.03 P3.2.04 P3.2.05 P3.2.06	0	Input 1	If input 1 is true, the logic result is true, If input 1 is false, the logic result is false
	1	Input 1 and NOT	If input 1 is true, the logic result is false If input 1 is false, the logic result is true
	2	Input 1 and Input 2 AND	If Input 1 and Input 2 are true, the logic result is true or false
	3	Input 1 and Input 2 OR	Any one of Input 1 and Input 2 is true, the logic result is true,
	4	Input 1 and Input 2 XOR	If Input 1 and Input 2 are opposite logic, the logic result is true If Input 1 and Input 2 have same logic, the logic result is false
	5	The valid reference of Input 1 is valid The valid Reference of Input 2 is invalid	If input 1 is true, the logic result is true, If input 2 is true and input 1 is false, the logic result is true, the logic result is false




Function code	Setting value for unit's digit	Function	Description
P3.2.02 P3.2.03 P3.2.04 P3.2.05 P3.2.06	6	Valid reference of Input 1 Rise Edge is valid Valid reference of Input 2 Rise Edge is invalid	If Input 1 Rising Edge is true, the logic result is true If Input 2 Rising Edge is true, the logic result is false
	7	Reverse valid signal of Input 1 Rising Edge	If Input 1 Rising Edge is true, the logic result is reverse
	8	Input 1 Rise Edge is valid and output a impulse signal with width of 200ms	If Input 1 Rising Edge is true, the logic result is true, after keeping it 200ms, the logic result becomes false
	9	Input 1 Rise Edge and Input 2 AND	If Input 1 Rising Edge and Input 2 Rising Edge are true, the logic result is true or false

e.g. in case of setting Function Code P3.2.00 (Intermediate Delay Relay Control)=00112, we can learn from referring to the explanation of Function Code P3.2.00 that Relay 5(M5) & Relay 5(M5) are determined by Control Word A and Relay 3(M3) & Relay 2(M2) are determined by Control Word B, and Relay 1 (M1) is determined by thousands and hundreds of Control Word C, as shown in the figure below:




In combination with the example above, in case of setting P3.2.01 (Intermediate Delay Relay Control Word A)=10111, it is to compulsively set M5=1 and M4=0.


For M3, M2 and M1 are not determined by Control Word A, so the setting of P3.2.01 to M3, M2 and M1 is invalid.




In combination with the example above, in case of setting P3.2.03 (Control Word B of Corresponding M2)=01022, we can learn from referring to the explanation of Function Code P3.2.03 that M2=DI2&&DI3, as shown in the figure below:



In combination with the example above, in case of setting the tens and ones of P3.2.08 (Control Word C of Corresponding M2) at 01 (input terminal function of corresponding digital), it indicates that the function of M2 is forward running. If 51(Synchronous Intermediate Relay M2) is set among P2.0.28~P2.0.32 at the same time, corresponding multi-functional output terminal outputs the signal.




The Intermediate Relay can not only respectively preset the delay time for its connection and disconnection through Function Code P3.2.12~P3.2.16 and P3.2.17~P3.2.21, but preset whether the reverse operation is conducted for output signals through Function Code P3.2.22. In combination with the example above, in case of setting P3.2.13 (delay time of corresponding M2 connection) =10.0s and P3.2.18 (delay time of corresponding M2 disconnection)=5.0s, when DI2 and DI3 are connected, M2 is not immediately connected, but connected after waiting for 10.0s. Similarly, when one of DI2 or DI3 is disconnected, M2 is not immediately disconnected, but disconnected after waiting for 5.0s.



### 7.1.13 Internal Timer Function

E Series Frequency inverter has two built-in timers, their start, shutdown timing and timer reset can be realized through digital input terminal. The fixed time arrival can output the signals through multi-functional output terminal.




When the signal of the output terminal of the timer (terminal function 48~49) is valid, the timer starts timing. When the signal of the input terminal of the timer is invalid, the timer stops timing and keeps current value.

When actual timing value of Timer 1 reaches the value set by P3.2.24, the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is the Timer 1 TimeArrival (42).

When actual timing value of Timer 2 reaches the value set by P3.2.25, the multi-functional output terminals of the frequency inverter can output Signal ON. Corresponding multi-functional output terminal function is the Timer 2 TimeArrival (43).


When actual timing value of Timer 1 reaches the value set by P3.2.24, but actual timing value of Timer 2 fails to reach the value set by P3.2.25, the multi-functional output terminals of the frequency inverter output Signal ON. When actual timing value of Timer 2 reaches the value set by P3.2.25, the multi-functional output terminals of the frequency inverter output Signal OFF. Corresponding multi-functional output terminal function is Timer 1 TimeArrival, but Timer 2 Time Non-Arrival (44).

In the process of timing, the reset operation to actual timing value can be realized through digital input terminal. Corresponding digital input terminal function is the Timer Reset Terminal (50~51).



### 7.1.14 Internal Operation Module Function

E Series Frequency inverter has four built-in operation modules, which collect the data of two function codes of the frequency inverter (remove the value after the decimal point) to conduct simple operation and finally output the operation results into special use occasions. Certainly, the operation results can also be used to realize the actions of multi-functional output terminals and the output of the analog signal.



#### Control Explanation for Operation Module

Function code	Corresponding setting value	Function	Description
b	0	No Operation	No operation conducted
	1	Add Operation	Address A data + Address B data
	2	Subtraction Operation	Address A data - Address B data
	3	Multiply Operation	Address A data × Address B data
	4	Division Operation	Address A data ÷ Address B data
	5	Greater than Judgment	If Address A data > Address B data, the non-setting operation result is 1, or it is 0.
	6	Equal to Judgment	If Address A data = Address B data, the non-setting operation result is 1, or it is 0.
	7	Equal to or Greater than Judgment	If Address A data ≥ Address B data, the non-setting operation result is 1, or it is 0.
	8	Integration	Time of every Address B Data (ms as unit) means Address A Data added to non-setting operation result, e.g. If Address A Data is 100 and Address B Data is 1000, it indicates that 10 is added to non-setting operation result per 1000ms. The scope of the operation results is -32767~32767. When the operation results is less than -9999, all displayed decimal points of the digital tube completely indicate minus value, e.g. "1.0.1.0.0" means -10100.
9~F	Reservation	Reservation	

## Explanation for Setting Coefficient Property of Operation

Function code	Corresponding setting value	Function	Description
P3.2.27	0	Conduct setting at no decimal fraction to system by multiplication algorithm	Non-setting Operation Result $\times$ Setting Coefficient of Operation
	1	Operate the Setting Coefficient by multiplication with one decimal	Non-setting Operation Result $\times$ Setting Coefficient of Operation $\div 10$
	2	Operate the Setting Coefficient by multiplication with two decimals	Non-setting Operation Result $\times$ Setting Coefficient of Operation $\div 100$
	3	Operate the Setting Coefficient by multiplication with three decimals	Non-setting Operation Result $\times$ Setting Coefficient of Operation $\div 1000$
	4	Operate the Setting Coefficient by multiplication with four decimals	Non-setting Operation Result $\times$ Setting Coefficient of Operation $\div 10000$
	5	Operate the Setting Coefficient by division without decimal	Non-setting Operation Result $\div$ Setting Coefficient of Operation
	6	Operate the Setting Coefficient by division with one decimal	Non-setting Operation Result $\div$ Setting Coefficient of Operation $\times 10$
	7	Operate the Setting Coefficient by division with two decimals	Non-setting Operation Result $\div$ Setting Coefficient of Operation $\times 100$
	8	Operate the Setting Coefficient by division with three decimals	Non-setting Operation Result $\div$ Setting Coefficient of Operation $\times 1000$
	9	Operate the Setting Coefficient by division with four decimals	Non-setting Operation Result $\div$ Setting Coefficient of Operation $\times 10000$

## Control Explanation for Operation Results

Operation Results oriented	Scope of Operation Results
Operation Results Oriented Reference Frequency	-Highest Frequency~Highest Frequency (Remove Decimal Point)
Operation Results Oriented Reference Upper Frequency	0~Highest Frequency (Remove Decimal Point)
Operation Results Oriented PID Reference	-1000~1000 means -100.0%~100.0%
Operation Results Oriented PID Feedback	-1000~1000 means -100.0%~100.0%
Operation Results Oriented Torque Reference	-1000~1000 means -100.0%~100.0%
Operation Results Oriented Analog Output	Operation Result 1: -1000~1000
	Operation Result 2: 0~1000
	Operation Result 3: -1000~1000
	Operation Result 4: 0~1000

The operation result 1 can be reviewed through Function Code P9.0.46.

The operation result 2 can be reviewed through Function Code P9.0.47.

The operation result 3 can be reviewed through Function Code P9.0.48.


The operation result 4 can be reviewed through Function Code P9.0.49.

e.g. the sum of VF1 Reference and VF2 Reference can be used to torque reference through operation. When the scope of torque reference is 0.0%~100.0%,the desired scope of operation results is 0~1000. For the scope of reference voltage of VF1 and VF2 is 00.00~10.00m, the scope of the non-setting operation results of Operation 2 is 0~2000, but the desired scope of operation results can be reached through division by two. The parameters of the function code are required to be set as below:

Function code	Function name	Setting value	Explanation
P1.1.14	Torque Reference Source	9	Torque Reference Source from Operation Result 2
P3.2.26	Operation Module	H.0010	Select addition operation for operation 2
P3.2.27	Operation Setting Coefficient Property	0050	Operate the setting coefficient by division without decimals
P3.2.31	Input A of Operation 2	09009	Operate corresponding Function Code P9.0.09 by unsigned number
P3.2.32	Input B of Operation 2	09010	Operate corresponding Function Code P9.0.10 by unsigned number
P3.2.33	Setting Coefficient of Operation 2	2	The setting coefficient is 2

### 7.1.15 PID FUNCTION

E Series Frequency inverter has built-in PID Regulator, which is configured with the option for signal reference channel and signal feedback channel, the users can easily realize automatic regulation of process control and control applications on constant voltage, constant flow, constant temperature, tension, etc. When in use of PID Frequency Closed-loop Control, the users need to preset the running frequency and reference mode and select P0.0.04 as 8 (PID Control), that is, PID Automatic Regulation on Output Frequency, related parameters of PID are given in Group P4 and the use methods of PID are as below:



The frequency inverter has 2 built-in equivalent PID computing units ,the performance parameters can be preset separately to realize optimum usage of regulating speed and accuracy, the users can use multi-functional terminals or setting deviation adjustment to freely switch different regulation performance required by different stage.

**7.1.16 Wobblulating Function**

Function code	Function name	Setting scope	Factory Value
P3.1.03	Wobblulating Reference Mode	0: Relative to Reference frequency 1: Relative to Highest Frequency	0
P3.1.04	Wobblulating Range	000.0%~100.0%	000.0
P3.1.05	Kicking Range	00.0%~50.0%	00.0
P3.1.06	Wobblulating Cycle	0000.1s~3000.0s	0010.0
P3.1.07	Rise Time of Wobblulating Triangular Wave	000.1%~100.0%	050.0

In some occasions, the Wobblulating can improve the control performance of the equipments, e.g. winding equipments in textile, fiber, etc., the use of the Wobblulating Function can improve the uniform tightness of the winding of spindle. Through setting Function Code P3.1.03~P3.1.07, it is to realize the reference frequency as wobblulating performance of the central frequency.

The Function Code P3.1.03 is used to confirm the reference quantity of amplitude. The Function Code P3.1.04 is used to determine the size of the amplitude. The Function Code P3.1.05 is used to confirm the size of mutation frequency of the wobblulating.

When at P3.1.03=0, the amplitude is variable amplitude system in relative to reference frequency, which will change along the reference frequency

$$\text{Amplitude} = \text{Reference Frequency} \times \text{Amplitude of Wobblulating}$$

$$\text{Mutation Frequency} = \text{Reference Frequency} \times \text{Amplitude of Wobblulating} \times \text{Sudden Jump of Amplitude}$$

When at P3.1.03=1, the amplitude is fixed amplitude system in relative to reference frequency, which is a fixed amplitude.

$$\text{Amplitude} = \text{Reference Frequency} \times \text{Amplitude of Wobblulating}$$

$$\text{Mutation Frequency} = \text{Reference Frequency} \times \text{Amplitude of Wobblulating} \times \text{Sudden Jump of Amplitude}$$


Wobblulating Cycle: refer to the time value of a complete wobblulating cycle.


Triangular Wave Rise Time of Wobblulation: refer to the percentage of Triangular Wave Rise Time relative to wobblulating cycle (P3.1.06) .

Triangular Wave Rise Time = Wobblulating Cycle × Triangular Wave Rise Time of Wobblulation, Unit: Second.

Triangular Wave Fall Time = Wobblulating Cycle × (1-Triangular Wave Rise Time of Wobblulation), Unit: Second.

Refer to the figure below for explanation:





Note: the output frequency of wobble is subject to upper frequency and lower frequency


### 7.1.17 Analog Input/Output Use

#### 1. Analog Input

E Series Frequency inverter support 2-way analog input, which can be voltage signal or can also be current signal.

Input	VF1	Voltage source	Shift switch J5-1 to U side, which enable to receive the signal at 0V~10V DC.
		Current source	Shift switch J5-1 to I side, which enable to receive the signal at 0/4mA~20mA.
	VF2	Voltage source	Shift switch J5-2 to U side, which enable to receive the signal at 0V~10V DC.
		Current source	Shift switch J5-2 to I side, which enable to receive the signal at 0/4mA~20mA.

When the frequency inverter uses the analog input as frequency source reference, torque reference, PID reference or feedback, corresponding curve can be chosen for the relationship between the voltage or current value and reference value or feedback quantity through function code P2.1.02, and the corresponding curve parameters are set. The sampling value of Terminal VF can be viewed through Function Code P9.0.09 and P9.0.10. Refer to the figure below for explanation:






2. Analog Output

E Series Frequency inverter support 2-way analog output, which can be voltage signal or can also be current signal.

Output	FM1	Voltage source	Shift switch J6 to U side, which enable to receive the signal at 0V~10V DC.
		Current source	Shift switch J6 to I side, which enable to receive the signal at 4mA~20mA.
	FM2	Voltage source	Shift switch J7 to U side, which enable to receive the signal at 0V~10V DC.
		Current source	Shift switch J7 to I side, which enable to receive the signal at 4mA~20mA.

FM1 and FM2 can indicate internal running parameters through output analog mode. The indicated contents of the parameters can be selected through Function Code P2.0.33 and P2.0.34. The analog output signal can be corrected through Function Code P2.0.36and P2.0.37 before output, the correction effect is shown in the figure below:



Corrected Output  $Y = aX + b$  (X means running parameters to be output, a means output gain and b is output offset) .


7.1.18 Digital Input/Output Use

1. Digital Input

CDI-E100 Series Frequency inverter has 6 digital input terminals with No. DI1~DI6, in which DI6 is high speed input terminal. CDI-E180 Series Frequency inverter is configured with 6 digital input terminals with No. DI1~DI6, in which DI6 is high speed input terminal. Besides, it can externally connect I/O Expansion Card and additional 4 I/O Expansion Cards with No. DI7~DI10 can be adopted. VF1 and VF2 can also be set as digital input through Function Code P2.1.23 and P2.1.24.

The digital input terminal adopts internal power by factory default, which is valid for short circuit to Terminal COM (indicated as 1) and invalid for disconnection (indicated as 0), it also can make its indicated effect reverse through setting Function Code P2.1.00 and P2.1.01. When VF is used as digital input, the short circuit of 10V Power Terminal of the frequency inverter and VF is valid, but invalid for disconnection, and the indicated effect can also be reversed through Function Code P2.1.25.

Terminal DI1~DI3 can also be used to set the delay effect time through Function Code P2.1.26~P2.1.2 and available for the occasions that require to delay the signal effect.




T is the delayed time

2.Digital Output

CDI-E100 Series Frequency inverter has three multi-functional output terminals, that is, YO, T1 and T2. CDI-E180 Series Frequency inverter is configured with three multi-functional output terminals, that is, YO, T1 and T2. Besides, it can externally connect I/O Expansion Card and then additional two I/O Expansion Cards can be adopted, that is, YO1 and Yo2.

Name of Terminal	Function Code	Configuration	Description for Output
YO1	P2.0.28	E180 Expansion Card	Transistor; drive capability: 48VDC, 50mA below
T1 Relay	P2.0.29	E Series Control Panel	Relay; drive capability: 250VAC, 3A below or 30 VDC, 1A below
T2 Relay	P2.0.30	E Series Control Panel	Relay; drive capability: 250VAC, 3A below or 30 VDC, 1A below
YO2	P2.0.31	E180 Expansion Card	Transistor; drive capability: 48VDC, 50mA below
FMP(YO/FMP) (P2.1.20=0)	P2.0.35 P2.1.21	E Series Control Panel	Transistor; able to output high-frequency impulse 0.01 kHz~100kHz; drive capability: 24VDC, 50mA below
YO(YO/FMP) (P2.1.20=1)	P2.0.32	E Series Control Panel	Transistor; drive capability: 48VDC, 50mA below

Output Terminal YO, T1 and T2 can also be used to set the delay effect time through Function Code P2.1.29~P2.1.31 and available for the occasions that require to delay the signal effect.





T is the delayed time

### 7.1.19 Communication of Upper Computer

As the automation control is more widely used, the applications on controlling the running of the frequency inverter the upper computer through communication mode have been too much, so the use of Network RS485 can conduct communication with E Series Frequency inverter of Delixi. CDI-E100 Series Frequency inverter has communication interface terminal on control panel, that is, SG+ and SG-, so the communication can be realized by connecting the communication line and programming on upper computer. While E180 Series Frequency inverter hasn't had communication interface terminal on control panel, so the communication can be realized by externally connecting the expansion card and programming on upper computer.

E Series Frequency inverter adopts MODBUS-RTU Protocol, which can only be used as slave station, namely, it can only handle and reply the data from upper computer, but not initiatively send the data. When communicating, it is required to set the parameters of Function Code P4.1.00~P4.1.05. These parameters need to be set based on actual conditions, if the setting is improper, it may cause the communication unable to be done or abnormal communication. When the communication timeout (P4.1.04) is set at non-zero data, the frequency inverter automatically shuts down after the fault of communication timeout to avoid the frequency inverter from running without control to lead to adverse consequence when the communication or upper computer breaks down. As for specific use of Communication Protocol, refer to the Description of Chapter VIII for more details. The figures below are communication diagram of E180 and E100.



**7.1.20 Parameter Identification**

When the control mode of the frequency inverter is vector control mode (P0.0.02=1 or 2), the accuracy for the parameters of motor of P0.0.19~P0.0.23 directly effects the control performance of the frequency inverter, if the frequency inverter has good control performance and running efficiency, the frequency inverter must acquire the accurate parameters of the controlled motor. If exact parameters of motor have been acquired, the parameters of motor can be manually input into P0.0.19~P0.0.23, or the Parameter Identification Control Function is required to be used.

The Parameter Identification Control Modes include Static Identification, Complete Identification, Load Synchronous Machine Identification and Non-load Synchronous Machine Identification. As for Parameter Identification Control of the asynchronous motor, it suggests using the Complete Identification Mode at on-load run. (P0.0.24=2)

Parameter Identification Control Mode	Applicable Occasions	Identification Effect
Static Identification	Only applicable for occasions not convenient to separate the motor and rotating system from asynchronous motor	Worse
Complete Identification	Only applicable for occasions able to completely separate the motor and rotating system from asynchronous motor	Best
Load Synchronous Machine Identification	Only applicable for occasions not convenient to separate the motor and rotating system from synchronous motor	Not bad
Non-load Synchronous Machine Identification	Only applicable for occasions able to completely separate the motor and rotating system from synchronous motor	Best

As for the occasions hard to separate the asynchronous motor and rotating system, the motor with same brand and type can be used, after complete identification, the parameters for properties of the motor are copied to corresponding parameter of P0.0.19~P0.0.23.

Function code	Function name	Setting scope	Factory Value
P0.0.24	Parameter Identification Control	00: No action 01: Static identification 02: Complete identification  11: Synchronous machine on-load identification (Invalid E100) 12: Synchronous machine non-load identification (Invalid E100)	00

CDI-E100 Series only supports Static Identification and Complete Identification, but not Load Synchronous Machine Identification and Non-load Synchronous Machine Identification. While E180 Series supports all modes.

0: No Action

When the frequency inverter is under normal operating state, the parameter identification is not required to be done.

### 1: Static Identification

When the load cannot completely separate from the asynchronous motor, this mode can be adopted. Before conducting the identification, the parameter value of P0.0.13~P0.0.18 must be set correctly. After completing the setting and pressing Key RUN, the frequency inverter operates the static identification, the completion of the identification only can acquire three parameter values of P0.0.19~P0.0.21.

### 2. Complete Identification

When the load completely separates from the asynchronous motor, this mode can be adopted (if the conditions allow, please try to adopt this mode, for it has better effect). Before conducting the identification, the parameter value of P0.0.13~P0.0.18 must be set correctly. After completing the setting and pressing Key RUN, the frequency inverter operates the complete identification, the completion of the identification only can acquire five parameter values of P0.0.19~P0.0.23.

### 11. Load Synchronous Machine Identification

When the load cannot completely separate from the synchronous motor, this mode can be adopted. Before conducting the identification, the parameter value of P 0.0.13~P0.0.18, P0.1.26, P0.1.27 and P0.1.34 must be set correctly. After completing the setting and pressing Key RUN, the frequency inverter operates the Load Synchronous Machine Identification, the completion of the identification can acquire initial position angle of the synchronous, and the initial position angle is the necessary conditions for normal operation of the synchronous motor, so the first use of the synchronous motor must conduct identification.

### 12: Non-load Synchronous Machine Identification

When the load completely separates from the synchronous motor, this mode can be adopted (if the conditions allow, please try to adopt this mode, for it has better effect), such a mode can acquire accurate parameters of the motor so as to achieve better running performance of the synchronous motor. Before conducting the identification, the parameter value of 0.0.13~P0.0.18, P0.1.26, P0.1.27 and P0.1.34 must be set correctly.


## Steps for Motor Parameter Identification:

- 1.If the motor can completely separate from the load, please confirm its state and the motor cannot influence other related devices when the motor is rotating.
- 2.After power-on, please confirm that the Parameter P0.0.13~P0.0.18 of the frequency inverter is the same with corresponding parameter on the nameplate of the motor.
- 3.Please confirm that when the running control mode of the frequency inverter is at P0.0.03=0, the panel control is adopted (i.e. only Key RUN on the control panel can identify the running signal).
- 4.Set Function Code P0.0.24 and select the mode of parameter identification. If the Complete Identification is selected, the Function Code is at P0.0.24=2, press Key “ENTER” and then press Key “RUN”, the keyboard displays “fE5f”, the indicator of “RUN” lights on and the indicator of “TUNE” keeps flashing. The parameter identification continues running about 30s~60s, when the display of “fE5f” disappears, the indicator of “TUNE” lights off, such a condition means the end of parameter identification, the frequency inverter can automatically store the identified the characteristic parameters of the motor into corresponding function code.

When CDI-E180 Series Frequency inverter drives the synchronous motor, the feedback signal of the encoder is required, before identification, the parameters of the encoder must be set correctly. In the process of identifying the synchronous motor, the rotating action is required, the best identification mode is no-load dynamic identification, if the conditions don't allow, and the load dynamic identification can be conducted.

## 7.2 Application Case

### 7.2.1 PID control for Water Supply at Permanent Pressure



Note: if it is the remote pressure gauge, put J5-1 (VF1 Dial Switch) to U side, and if it is the pressure transmitter, put J5-1 to I side.

Description for Constant Voltage Water Supply Parameter (◆: Means that the users don't need to modify the parameters in general; ◇: Means that the users can set the parameters based on actual conditions)

Function code	Function name	Factory value	Description	Attribution
P0.0.03	Option for Running Control Mode	0	Start Key Run on Control Panel	◇
		1	Start the External Terminal DI1 (P2.0.00=01)	
P0.0.04	Frequency Source A	8	The frequency source is PID Reference	◆
P0.0.11	Acceleration Time	Machine type	Set based on actual conditions	◇
P0.0.12	Deceleration Time	Machine type	Set based on actual conditions	◇
P4.0.00	PID Reference Source	0	The reference source is given from P4.0.01	◆
P4.0.01	PID Value Reference	50%	The reference value is given by the users based on actual needs, which is the percentage relative to P4.0.04.	◇
P4.0.02	PID Feedback Source	0	The feedback source inputs from Terminal Vf1	◆
P4.0.03	PID Action Direction	0	PID Direct Action. The feedback is, the smaller the frequency is.	◇
		1	PID Reverse Action. The smaller the feedback is, the smaller the frequency is.	
P4.0.04	PID Action Direction	1000	Set based on actual feedback range (1000 means 1MPa)	◇
P9.0.14	PID Reference (Display Value)		Display PID Reference	
P9.0.15	PID Feedback (Display Value)		Display PID Feedback	

Function code	Function name	Factory value	Description	Attribution
P2.1.02	Analog Input Curve Selection	H.11	Define VF1 Select Curve 1	◆
P2.0.13	Minimum Input of Curve 1	00.00V	Define the relation curve between VF1 Input and PID Feedback	◆
P2.0.14	Corresponding reference for Minimum Input of Curve 1	000.0%		
P2.0.15	Maximum Input of Curve 1	10.00V		
P2.0.16	Corresponding reference for Maximum Input of Curve 1	100.0%		
P2.0.17	VF1 Filtering time	00.10s	When the site analog is easily interrupted, please increase the filtering time to make the detected analog tend to be stable, but the longer the filtering time is, the response speed to the analog detection gets slow as the filtering time become longer.	◆
P4.0.05	Proportional Gains KPI	020.0	The greater the value of proportional gain KPI is, the larger the adjustment volume is and the faster the response is, but the too large value can generate the system oscillation, the smaller the value of KPI is, the more stable the system is and the slower the response is.	◆
P4.0.06	Integral Time TI1	02.00	The greater the value of Integral Time TI1 is, the slower the response is and the more stable the output is, the worse the fluctuation control ability of the feedback quantity is, the smaller the value of TI1 is, the faster the response is and the greater the output fluctuation is, the too small value can generate the oscillation.	◆
P4.0.07	Derivative Time TD1	00.000	The Derivative Time TD1 can set the limit for gain provided by the derivator to ensure that a pure derivative gain can be obtained at low frequency and a constant derivative gain can be obtained at high frequency. The longer the derivative time is, the greater the adjusting strength is.	◆

#### Constant-voltage Control Sleep Function:

For the feedback value and VF1 Voltage Signal have constituted a certain linear relationship (PID feedback value is 100% and corresponding voltage value is 10V), the sleep function can be realized through the collection of the size of the voltage signal of VF1. When the voltage of VF1 is larger than upper limit of VF1 Input (that is, corresponding voltage value of sleep threshold), the frequency inverter stops automatically after lasting for some time. When the voltage of VF1 is less than lower limit of VF1 Input (that is, corresponding voltage value of awaking threshold), the frequency inverter automatically starts and runs.

**Note: in shut-down state, if the voltage of VF1 is larger than upper limit of VF1 Input, the frequency inverter cannot start running.**

Corresponding Voltage Value of Sleep Threshold = Sleep Threshold (PID Value)X 10V

Corresponding Voltage Value of Awaking Threshold = Awaking Threshold (PID Value)X 10V

The setting parameters of Constant-voltage Control Sleep Function are as below:


Function code	Function name	Setting value	Function code	Attribution
P3.2.00	Intermediate Delay Relay M1 Control Word B	00112	M3 and M2 are determined by Control B. M1 is determined by Control Word C.	◆
P3.2.07	Intermediate Delay Relay M1 Control Word C	2248	M1:take VF1 Input more than upper limit and use it for Input of Timer 1	◆
P3.2.03	Intermediate Delay Relay M2 Control Word B	00101	M2:Reverse M1 Signal	◆
P3.2.08	Intermediate Delay Relay M2 Control Word C	0050	Take M2 Signal and use it for Reset of Timer 1	◆
P3.2.04	Intermediate Delay Relay M3 Control Word B	41626	M3:take Arrival Signal of Timer 1	◆
P3.2.09	Intermediate Delay Relay M3 Control Word B	0014	Take M3 Signal and use it for Suspension of Frequency inverter	◆
P3.2.23	Internal Timer Control Word	00001	Define Timer 1	◆
P3.2.24	Timing Time of Timer 1	5.0	Continuous Delay Time of arriving at Upper Limit of VFI Input (Sleep Threshold)	◇
P2.2.19	VF1 Input Lower Limit	03.10	Corresponding Voltage value of Awaking Threshold)	◇
P2.2.20	VF1 Input Upper Limit	06.80	corresponding Voltage value of Sleep Threshold	◇

The parameters for optimal performance of constant pressure water supply are shown in the table below, they don't need to be set in normal conditions. If the setting is required, please refer to the explanation for setting of the function codes.

Function code	Setting value	Function code	Attribution	Function code
P4.0.08	PID Deviation Limit	000.0	Refer to Description for Setting of Function Codes	◆
P4.0.09	PID Feedback Filtering time	00.00		
P4.0.10	Proportional Gains KP2	020.0		
P4.0.11	Integral Time TI2	02.00		
P4.0.12	Derivative Time TD2	00.000		
P4.0.13	PID Switch Conditions	0		
P4.0.14	PID Switch Deviation 1	020.0		
P4.0.15	PID Switch Deviation 2	080.0		
P4.0.16	PID Initial Value	000.0		
P4.0.17	PID Initial Value Hold Time	000.00		
P4.0.18	PID Feedback Loss Detection	000.0		
P4.0.19	PID Feedback Loss Detection Time	00.0		
P4.0.20	PID Stop Operation	0		



7.2.2. Application for Injection Molding Machine Energy-saving Transformation



Note: if the analog input is 0~10V, the voltage signal will put J5-1 and J5-2 (VF1 and VF2 Dial Switch) to U side; if the analog input is 4~20mA, the current signal will put J5-1 and J5-2 to I side. If the analog input is Current Signal 0~1A, it is required to add Expansion Card E180-ZS and convert the current signal to voltage signal 0~10V. Refer to Appendix 6 for use of Expansion Card E180-ZS.

Connection Method of Main Circuit for Energy Saving Modification of Injection Molding Machine

For injection molding machine with direct starting and stopping oil pump motor, see circuit as following.



The power supply cable is the lead taken behind the breaker is connected to the power supply incoming end of the frequency inverter during modification, the incoming terminal of the Electromagnetic Switch is connected to output end of the frequency inverter.

For injection molding machine with reduced VOLTAGE starting oil pump motor, see circuit as following



Power supply cable is lead from front end of main cable of the reduced voltage starting device or back end of the circuit breaker and is connected to the power supply incoming end of the frequency inverter during modification, the output end of the frequency inverter is connected to the input end of main circuit with the reduced voltage starting.


Chapter 7 Common Function and Application Case

Description for Parameters of Injection Molding Machine (◆: Means that the users don't need to modify the parameters in general; ◇: Means that the users can set the parameters based on actual conditions)

Function code	Function name	Factory value	Description	Attribution
P0.0.03	Option for Running Control Mode	1	Start through External Terminal DI1	◆
P0.0.04	Option of A Frequency Source	3	Frequency Source A selects VF1 Channel and connects voltage signal	◆
P0.1.01	Option of B Frequency Source	4	Frequency Source B selects VF2 Channel and connects flow signal	◆
P0.1.00	Option of Frequency Source	0	Selects Frequency Source A (Voltage Signal of VF1 Channel)	◆
P0.0.07	Maximum frequency	50.00Hz	Highest frequency of the frequency inverter that allows running	◆
P0.0.09	Lower frequency	10.00Hz	Lowest frequency of the frequency inverter that allows running	◇
P0.0.10	Lower frequency operation mode	0	When the reference frequency is less than lower frequency, the frequency inverter runs at lower frequency	◆
P0.1.03	Upper Limit Frequency Source	3	Multiplex Directive Terminal Reference. Upper frequency is determined by different combinations of DI2,DI3,DI4 and DI5	◆
P2.0.00	DI1 Terminal Function	01	Define that Terminal DI1 is forward start	◆
P2.0.01	DI2 Terminal Function	9	Define the functions of Terminal Di2, DI3,DI4 and DI5 and determine the upper frequency through their different combinations	◆
P2.0.02	DI3 Terminal Function	10		
P2.0.03	DI4 Terminal Function	11		
P2.0.04	DI5 Terminal Function	12		
P3.0.03	Phase Directive 0	100.0%	Upper frequency at disconnection of DI5, DI4, DI3 and DI2 ( refer to percentage of the highest frequency)	◇
P3.0.05	Phase Directive 1	090.0%	Upper frequency only when DI2 is connected (Ditto)	◇
P3.0.07	Phase Directive 2	080.0%	Upper frequency only when DI3 is connected (Ditto)	◇
P3.0.11	Phase Directive 4	070.0%	Upper frequency only when DI4 is connected (Ditto)	◇
P3.0.19	Phase Directive 8	060.0%	Upper frequency only when DI5 is connected (Ditto)	◇
P2.1.02	Analog Input Curve Selection	H.43	Define VF1 Select Curve 3 and VF2 Select Curve 4	◆
P2.0.17	VF1 Filtering time	0.10 Sec.	When the on-site analog is easily to be interrupted, the filtering time shall be increased to make the detected analog tend to be stable, but the greater filtering time makes the response speed of the analog detection become slow,	◆
P2.0.22	VF2 Filtering time	0.10 Sec.		
P0.0.11	Acceleration Time	Machine type		◇
P0.0.12	Deceleration Time	Machine type		◇

Function code	Function name	Factory value	Description	Attribution
P2.1.04	Min. Input of Curve 3	00.00V	<p>Corresponding Reference</p> <p>P2.1.11</p> <p>P2.1.09</p> <p>P2.1.07</p> <p>P2.1.05</p> <p>P2.1.04 P2.1.06 P2.1.08 P2.1.10</p> <p>VF Input</p>	◆
P2.1.05	Corresponding reference for Min. Input of Curve 3	000.0%		
P2.1.06	Curve 3 Inflection Point 1 Input	03.00V		
P2.1.07	Corresponding reference for Curve 3 Inflection Point 1 Input	030.0%		
P2.1.08	Curve 3 Inflection Point 2 Input	06.00V		
P2.1.09	Corresponding reference for Curve 3 Inflection Point 2 Input	060.0%		
P2.1.10	Max. Input of Curve 3	10.00V		
P2.1.11	Corresponding reference for Max. Input of Curve 3	100.0%		
P2.1.12	Min. Input of Curve 4	00.00V		
P2.1.13	Corresponding reference for Min. Input of Curve 4	000.0%		
P2.1.14	Curve 4 Inflection Point 1 Input	03.00V		
P2.1.15	Corresponding reference for Curve 4 Inflection Point 1 Input	030.0%		
P2.1.16	Curve 4 Inflection Point 2 Input	06.00V		
P2.1.17	Corresponding reference for Curve 4 Inflection Point 2 Input	060.0%		
P2.1.18	Max. Input of Curve 4	10.00V		
P2.1.19	Corresponding reference for Max. Input of Curve 4	100.0%		
P3.2.00	Intermediate Delay Relay Control	00002	M1 is determined by Control Word C	◆
P3.2.07	Intermediate Delay Relay M1 Control	3714	Lower Frequency Arrival Signal is sued to realize suspension of stop	◆
P6.1.06	Fault Auto Reset Number	00	No automatic fault reset	◆
P6.1.07	Waiting Interval Time of Fault Auto Reset	001.0s	After the frequency inverter gives an alarm of fault, refer to the waiting time to automatic fault reset	◆

7.2.3 PID Constant Speed and Fixed-length Control Function



$$\text{Rotating Speed } n = \frac{\text{PULS Max. Input } \times 60 \times \text{PID Reference}}{\text{Impulses of Encoder}}$$

If the diameter of detected pressurizing roller is Dmm, it is line speed = 3.14 \* D \* n

$$\begin{aligned} \text{Line Speed } v &= \pi \times D \times \frac{\text{PULS Max. Input } \times 60 \times \text{PID Reference}}{\text{Impulses of Encoder} \times \text{PID Reference Feedback Range}} \\ &= K \times \text{PID Reference} \end{aligned}$$

If K=1000, PID Reference value is the line speed with unit m/m.

If K=100, PID Reference value is the line speed with unit dm/m.

Calculation for Impulse per meter

$$P = \frac{\text{Impulses of Encoder} \times 1000}{\pi \times D}$$

Description for Parameters of Fixed-Length of PID Constant Line Speed (◆: Means that the users don't need to modify the parameters in general; ◇: Means that the users can set the parameters based on actual conditions)

Function code	Function name	Factory value	Description	Attribution
P0.0.03	Option for Running Control Mode	0	Start Key Run on Control Panel	◇
		1	Start the External Terminal DI1 (P2.0.00=01)	
P0.0.04	Frequency Source A	8	The frequency source is PID Reference	◆
P0.0.11	Acceleration Time	Machine type	Set based on actual conditions	◇
P0.0.12	Deceleration Time	Machine type	Set based on actual conditions	◇
P4.0.00	PID Reference Source	0	The reference source is given from P4.0.01	◆
P4.0.01	PID Value Reference	50%	The reference value is given by the users based on actual needs	
P4.0.02	PID Feedback Source	4	The feedback source is given by PULS Reference (DI6)	◆
P4.0.03	PID Action Direction	0	PID Direct Action. The feedback is, the smaller the frequency is.	◇
		1	PID Reverse Action. The smaller the feedback is, the smaller the frequency is.	
P4.0.04	PID Reference Feedback Range	1000	Calculate the setting based on formula	◇
P3.1.08	Reference Length		The users preset based on actual needs	◇
P3.1.10	Impulse Count per meter		Calculate the setting based on formula	◇
P2.0.01	DI2 Terminal Function	31	Define Terminal DI2 as Length Reset Terminal	◆
P2.0.05	DI6 Terminal Function	30	Define Terminal DI6 as Length Input Terminal	◆
P9.0.14	PID Reference (displayed value)		Display the given line speed	
P9.0.15	PID Feedback (displayed value)		Display actual line speed	
P9.0.13	Actual Length Value (displayed value)		Display actual length value	
P2.0.23	Minimum Input of PULS	000.00	Define relation curve between impulse frequency input and PID feedback	◆
P2.0.24	Corresponding reference for Minimum Input of PULS	000.0		
P2.0.25	Maximum Input of PULS	050.00		
P2.0.26	Corresponding reference for Maximum Input of PULS	100.0		
P2.0.27	PULS Filtering time	00.10	When the field impulse signal is easily interrupted, please increase the filtering time to make the detected analog tend to be stable, but the longer the filtering time, the slower the detected response speed is	◆

Chapter 7 Common Function and Application Case

Function code	Function name	Factory value	Description	Attribution
P4.0.05	Proportional Gains KPI	020.0	The greater the value of proportional gain KPI is, the larger the adjustment volume is and the faster the response is, but the too large value can generate the system oscillation, the smaller the value of KPI is, the more stable the system is and the slower the response is.	◆
P4.0.06	Integral Time TI1	02.00	The greater the value of Integral Time TI1 is, the slower the response is and the more stable the output is, the worse the fluctuation control ability of the feedback quantity is, the smaller the value of TI1 is, the faster the response is and the greater the output fluctuation is, the too small value can generate the oscillation.	◆
P4.0.07	Derivative Time Td1	00.000	The Derivative Time TD1 can set the limit for gain provided by the derivator to ensure that a pure derivative gain can be obtained at low frequency and a constant derivative gain can be obtained at high frequency. The longer the derivative time is, the greater the adjusting strength is.	◆

If the length is required to reach automatic shutdown and the frequency inverter is desired to stop stably, the shutdown DC brake can be configured, or the following parameters need to be set:

Function code	Setting value	Function code	Attribution
P3.2.00	00002	M1 is determined by Control Word C	◆
P3.2.07	1039	M1:take the length to reach the signal used for shutdown of the frequency inverter	◆
P1.0.17	000.00	Stop DC Braking Initial Frequency	◇
P1.0.18	000.0	Stop DC Braking Hold Time	◇
P1.0.19	000	Stop DC Braking Current	◇
P1.0.20	000.0	Stop DC Braking Time	◇


If the length is required to reach automatic reset, the following parameters need to be set. After completing the shutdown of the frequency inverter every time, the length is reset to zero automatically.

Function code	Setting value	Function code	Attribution
P2.0.01	00	Remove manual length reset function of DI2	◆
P3.2.00	00122	M3 is determined by Control B. M1 and M2 are determined by Control C	◆
P3.2.04	00111	M3: take Reverse signal output of M2	◆
P3.2.08	0100	M2:take signal in operation	◆
P3.2.09	0031	M3 signal used for length automatic reset	◆

The parameters for optimal performance of constant line speed fixed-length control are shown in the table below, they don't need to be set in normal conditions. If the setting is required, please refer to the explanation for setting of the function codes.

Function code	Function name	Factory value	Description	Attribution
P4.0.08	PID Deviation Limit	000.0	Refer to Description for Setting of Function Codes	◆
P4.0.09	PID Feedback Filtering time	00.00		
P4.0.10	Proportional Gains KP2	020.0		
P4.0.11	Integral Time TI2	02.00		
P4.0.12	Derivative Time TD2	00.000		
P4.0.13	PID Switch Conditions	0		
P4.0.14	PID Switch Deviation 1	020.0		
P4.0.15	PID Switch Deviation 2	080.0		
P4.0.16	PID Initial Value	000.0		
P4.0.17	PID Initial Value Hold Time	000.00		
P4.0.18	PID Feedback Loss Detection	000.0		
P4.0.19	PID Feedback Loss Detection Time	00.0		
P4.0.20	PID Stop Operation	0		

7.2.4PID Constant Speed and Fixed-distance Control Function



$$\text{Rotating Speed } n = \frac{\text{PULS Max. Input } X 60 \times \text{PID Reference}}{\text{Impulses of Encoder}}$$

If the diameter of detected pressurizing roller is Dmm, it is line speed=3.14\*D\*n

$$\begin{aligned} \text{Line Speed } v &= \frac{\text{PULS Max. Input } X 60 \times \text{PID Reference}}{\text{Impulses of Encoder } X \text{ PID Reference Feedback Range}} \\ &= K \times \text{PID Reference} \end{aligned}$$

If K=1000, PID Reference value is the line speed with unit m/m.

If K=100, PID Reference value is the line speed with unit dm/m.

Calculation for Impulse per meter

$$P = \frac{\text{Impulses of Encoder} \times 1000}{\pi \times D}$$

If the operation result P Value is larger than 600, the P Value can be reduced 10 by times. The unit of corresponding distance value can also be reduced 10 by times from meter to decimeter.



Explanation for PID Constant Speed Fixed-Length Control Parameters

Function code	Function name	Factory value	Description	Attribution
P0.0.03	Option for Running Control Mode	0	Start Key Run on Control Panel	◇
		1	Start the External Terminal DI1 (P2.0.00=01)	
P0.0.04	Option of A Frequency Source	8	The frequency source is PID Reference	◆
P0.0.11	Acceleration Time	Machine type	Set based on actual conditions	◇
P0.0.12	Deceleration Time	Machine type	Set based on actual conditions	◇
P4.0.00	PID Reference Source	0	The reference source is given from P4.0.01	◇
P4.0.01	PID Value Reference	50%	The reference value is given by the users based on actual needs, which is the percentage relative to P4.0.04.	◇
P4.0.02	PID Feedback Source	4	PULS Reference (DI6)	
P4.0.03	PID Action Direction	0	PID Direct Action. The feedback is, the smaller the frequency is.	◇
		1	PID Reverse Action. The smaller the feedback is, the smaller the frequency is.	
P4.0.04	PID Reference Feedback Range	1000	Set based on actual feedback range	◇
P3.1.13	Distance Set value 1		The users preset based on actual needs (unit determined based on calculation)	◇
P3.1.14	Distance Set value 2			
P3.1.15	Impulse Count per Distance			
P2.0.01	Option of DI2 Terminal function	54	Define Terminal DI2 as Length Reset Terminal	◆
P2.0.04	Option of DI5 Terminal function	52	Define DI5 Terminal as Encoder Phase A Input	◆
P2.0.05	Option of DI6 Terminal function	53	Define DI5 Terminal as Encoder Phase B Input	◆
P9.0.14	PID Reference (displayed value)		Display the given line speed	
P9.0.15	PID Feedback (displayed value)		Display actual line speed	
P9.0.30	Actual Distance Value (displayed value)		Display actual distance	
P2.0.23	Minimum Input of PULS	000.00	Define relation curve between impulse frequency input and PID feedback	◆
P2.0.24	Corresponding reference for Minimum Input of PULS	000.0		
P2.0.25	Maximum Input of PULS	050.00		
P2.0.26	Corresponding reference for Maximum Input of PULS	100.0		
P2.0.27	PULS Filtering time	00.10	When the field impulse signal is easily interrupted, please increase the filtering time to make the detected analog tend to be stable, but the longer the filtering time, the slower the detected response speed is	◆

Function code	Function name	Factory value	Description	Attribution
P4.0.05	Proportional Gains KP1	020.0	The greater the value of proportional gain KP1 is, the larger the adjustment volume is and the faster the response is, but the too large value can generate the system oscillation, the smaller the value of KP1 is, the more stable the system is and the slower the response is.	◆
P4.0.06	Integral Time Ti1	02.00	The greater the value of Integral Time Ti1 is, the slower the response is and the more stable the output is, the worse the fluctuation control ability of the feedback quantity is, the smaller the value of Ti1 is, the faster the response is and the greater the output fluctuation is, the too small value can generate the oscillation.	◆
P4.0.07	Derivative Time TD1	00.000	The Derivative Time TD1 can set the limit for gain provided by the derivator to ensure that a pure derivative gain can be obtained at low frequency and a constant derivative gain can be obtained at high frequency. The longer the derivative time is, the greater the adjusting strength is.	◆

If speed reduction is to be realized by setting value, the setting value 1 of the distance is the speed switch point and the setting value 2 of the distance is the target value. When actual distance reaches the setting value 1 of the distance, one signal is output to suspend PID Regulation and another one provides a low frequency rate to the frequency inverter (Frequency Source B).

Function code	Setting value	Function code	Attribution
P3.2.00	00012	M1 is determined by Control C.	◆
P3.2.07	5625	M1:take distance set value 1 arrival signal to be used for PID suspension	◆
P3.2.03	00100	M2:take M1 signal	◆
P3.2.08	0018	M2:switch Frequency Source B	◆
P0.1.00	8	Frequency source is selected by terminal	◆
P0.0.05	5.00	Low-speed frequency	◇

If the distance is required to reach automatic shutdown and the frequency inverter is desired to stop stably, the shutdown DC brake can be configured and the following parameters are required to be set as below:

Function code	Setting value	Function code	Attribution
P3.2.00	00212	M3 is determined by Control C.	◆
P3.2.09	5739	M3:take target length arrival to be used for shutdown of the frequency inverter	◆
P0.1.16	5.0	Decelerating time 4	◇
P1.0.17	000.00	Stop DC Braking Initial Frequency	◇
P1.0.18	000.0	Stop DC Braking Hold Time	◇
P1.0.19	000	Stop DC Braking Current	◇
P1.0.20	000.0	Stop DC Braking Time	◇


If the automatic distance reset is required, the following parameters are required to set. After the shutdown of the frequency inverter is completed every time, the distance is automatically reset to zero.

Function code	Setting value	Function code	Attribution
P2.0.01	00	Remove manual length reset function of DI2	◆
P3.2.00	12212	M5 is determined by Control B. M4 is determined by Control C	◆
P3.2.06	00131	M5: take Reverse signal output of M4	◆
P3.2.10	0100	M4:take signal in operation	◆
P3.2.11	0054	M5 signal used for length automatic reset	◆

The parameters for optimal performance of constant line speed fixed-distance control are shown in the table below, they don't need to be set in normal conditions. If the setting is required, please refer to the explanation for setting of the function codes.

Function code	Function name	Factory value	Description	Attribution
P4.0.08	PID Deviation Limit	000.0	Refer to Description for Setting of Function Codes	◆
P4.0.09	PID Feedback Filtering time	00.00		
P4.0.10	Proportional Gains KP2	020.0		
P4.0.11	Integral Time TI2	02.00		
P4.0.12	Derivative Time TD2	00.000		
P4.0.13	PID Switch Conditions	0		
P4.0.14	PID Switch Deviation 1	020.0		
P4.0.15	PID Switch Deviation 2	080.0		
P4.0.16	PID Initial Value	000.0		
P4.0.17	PID Initial Value HoldTime	000.00		
P4.0.18	PID Feedback Loss Detection	000.0		
P4.0.19	PID Feedback Loss Detection Time	00.0		
P4.0.20	PID Stop Operation	0		

7.2.5 Double Pumps Switching Function



Description for Double Pumps Switching Function Parameter

Function code	Function name	Setting value	Description	Attribution
P0.0.03	Option for Running Control Mode	0	Start Key Run on Control Panel	◇
		1	Start the External Terminal Di 1 (P2.0.00=01)	
P0.0.04	Option of A Frequency Source	7	Call the simple PLC program	◆
P3.0.00	Simple PLC Running Mode	0	End of Single Running and Stop	◇
		1	End of Single Running and Save Final Value	
		2	Continuous Running	
		3	Cycle N Times	
P3.0.01	Cycle Times N	0	Switching times of double pump cycle when at P3.0.00=3	◇
P3.0.02	Option of PLC Power-off Memory	11	Memory for shutdown and power-off	
P3.2.00	Intermediate Delay Relay Control	112	M3 and M2 are determined by Control B. M1 is controlled by Control Word C.	◆
P3.2.03	Intermediate Delay Relay M2 Control Word B	00100	M2:take M1 Signal Delayed Output	◆
P3.2.04	Intermediate Delay Relay M3 Control Word B	00117	M3:take M2 Signal used for signal inverse	◆

Function code	Function name	Setting value	Description	Attribution
P3.2.07	Intermediate Delay Relay M1 Control Word C	3914	M1:take completion signal in Simple PLC stage to realize shutdown function	◆
P3.2.13	Pump Switching Time Point	5.0s	This setting value is larger than actual deceleration time of the frequency inverter	◇
P3.2.17	Restart Time Point	7.0s	his setting value is larger than the setting value of P3.2.13	◇
P3.0.04	Pump 1 Run time	0	Pump 1 Run time	◇
P3.0.06	Pump 2 Run time	0	Pump 2 Run time	◇
P3.0.51	Pump Run Time Unit	0	Second	◇
		1	Hour	
P3.0.35	Running Frequency of 10-digit Selection Pump 1	H.10	Running frequency of Pump 1 is determined by keyboard potentiometer	◆
P3.0.36	Running Frequency of 10-digit Selection Pump 2	H.10	Running frequency of Pump 2 is determined by keyboard potentiometer	◆
P2.0.29	Option for Relay T1 Function	52	Define Synchronous M3 of Relay T1	◆

## Chapter 8 E Series Frequency Inverter RS-485 Communication

### 1 Explanation for E Series Frequency inverter RS-485 Communication Terminal

CDI-E180 Series Frequency inverter hasn't had RS-485 Communication Terminal on control panel.

SG+:485 Signal Positive

SG-:485 Signal Negative

CDI-E180 Series Frequency inverter hasn't had RS-485 Communication Terminal on control panel. If the communication is required, the external expansion card must be connected.

### 2 Explanation for E Series Frequency inverter Communication Parameter

Before the use of RS-485 Communication, must use the keyboard to set “Baud Rate”, “Data Format” and “Communication Address” .

Function code	Function name	Setting scope	Factory Value
P4.1.00	Baud Rate	0:1200 1:2400 2:4800 3:9600 4:19200 5:38400 6:57600	3
P4.1.01	Data Format	0:No Verification (8-N-2) 1:Even Parity Verification (8-E-1) 2:Odd Parity Verification (8-O-1) 3:No Verification (8-N-1)	0
P4.1.02	Local Machine Address	000:Broadcast Address 001~249	1
P4.1.03	Response Delay	00~20ms	2
P4.1.04	Communication Timeout	00.0 (Invalid) 00.1s~60.0s	0.0
P4.1.05	Data Transmission Format	0:ASCII Mode (Reservation) 1:RTU Mode	1


**Response Delay:** when the frequency inverter receives the data and after the time set by Function Code P4.1.03 is delayed, the frequency inverter starts recovering the data.

**Communication Timeout:** the interval between data frames received by the frequency inverter is over the time set by Function Code P4.1.04, the frequency inverter gives an alarm of Fault Err14, it is deemed as abnormal communication. If it is set at 0.0, the communication timeout is invalid.


3Description for Standard MODBUS Communication Format

3.1String Structure


(8-N-2, P4.1.01=0)




(8-E-1, P4.1.01=1)



(8-O-1, P4.1.01=2)



(8-N-1, P4.1.01=3)



3.2 Communication Data Structure

ADR	Slave Machine (Frequency inverter) Address The address scope of the frequency inverter is (001~249) ,( 8-digit hexadecimal number) <b>Note:</b> When the address is ADR=000H, it is valid for all slave machines and all slave machines can't respond message (broadcast mode)
CMD	Function Code of Data Package (06: write the contents of a register; 03: read out the contents of one or more than one register(s)) (8-digit hexadecimal number)
ADDRESS	Sending of Host Machine: when at Function Code 06, it means data address (16-digit hexadecimal number); when at Function Code 03, it means data initial address (16-digit hexadecimal number) Slave Station Responds: refer to data address when at function code 06 (16-digit hexadecimal number); refer to data number when at function code 03
DATA	Sending of Host Machine: when at Function Code 06, it means data address (16-digit hexadecimal number); when at Function Code 03, it means data initial address (16-digit hexadecimal number) Slave Station Responds: when at Function Code 06, it means data address (16-digit hexadecimal number); when at Function Code 03, it means data initial address (16-digit hexadecimal number in N)
CRC	CHK (CHECKSUM) (16-digit hexadecimal number)

RTU adopts CRC CHK (CHECKSUM), which is calculated as per the following steps:

Step 1: Load 16-digit register with content of FFFFH (CRC Register).

Step 2: Conduct XOR operation for the first byte of the communication data and the contents of CRC Register and store the results into CRC Register.

Step 3: Move 1bit of the contents of CRC Register to the minimum significant bit and fill in 0 to the maximum significant bit, and check the minimum significant bit of CRC Register.

Step 4: If the minimum significant bit is 1, the CRC Register and preset value conduct XOR operation. If the minimum significant bit is 0, no action is taken.

Step 5: After repeat 8 times of Step 3 and 4, the handling to this byte is finished.

Step 6: Repeat Step 2-5 for next byte of the communication data until the handling to all bytes are completed, the final content of CRC Register is the value of CRC. When transmitting CRC Value, first add the low byte and then high byte, that is, the low byte is first transmitted.



In case of any fault of the communication, the slave machine responds the data of ADDRESS and DATA are as below:

ADDRESS	DATA	Description	ADDRESS	DATA	Description
FF01	0001	Invalid address	FF01	0005	Invalid parameter
FF01	0002	CRC Check Error	FF01	0006	Invalid Modification to Parameter
FF01	0003	Read and Write Command Error	FF01	0007	System Lock
FF01	0004	Password Error	FF01	0008	Parameter under Storage

The master station writes the command string format:

Name Character	of	Slave Station	Write Command 06H	Function Code Address	Data content	CRC Check
Length Character	of	1Byte	1Byte	2Byte	2Byte	2Byte
Example		01H	06H	0005H	1388H	949DH

The slave station responds the command string format:

Name Character	of	Slave Station	Write Command 06H	Function Code Address	Data content	CRC Check
Length Character	of	1Byte	1Byte	2Byte	2Byte	2Byte
Example		01H	06H	0005H	1388H	949DH

The master station reads the command string format:

Name Character	of	Slave Station	Read Command 03H	Initial Address of Function Code	Data content	CRC Check
Length Character	of	1Byte	1Byte	2Byte	2Byte	2Byte
Example		01H	03H	9000H	0003H	28CBH

The slave station responds the read command string format:

Name Character	of	Slave Station	Read Command 03H	Data content 1	Data content 2	Data content 3	CRC Check
Length Character	of	1Byte	1Byte	2Byte	2Byte	2Byte	2Byte
Example		01H	03H	0000H	0000H	0000H	2175H

The slave station responds the write command error string format:

Name Character	of	Slave Station	Write Command 06H	Read and Write Error Mark	Read and Write Error Type	CRC Check
Length Character	of	1Byte	1Byte	2Byte	2Byte	2Byte
Example		01H	03H	Ff01H	0005H	281DH

The slave station responds the read command error string format:

Name of Character	Slave Station	Read Command 03H	Read and Write Error Mark	Read and Write Error Type	CRC Check
Length of Character	1Byte	1Byte	2Byte	2Byte	2Byte
Example	01H	03H	FF01H	0005H	E41DH

4Definition for Parameter Address of Communication Protocol

E Series Frequency inverter not only has many multifunctional function code parameters, but some non- multifunctional function code parameters. Specific read and write properties are as below:

Function Code Parameter	P1~P8	Readable, writable
	p9	Only Readable,
Non-function Code Parameter	A000H、A001H、A002H、A003H、A004H、A005H、A010H、A011H	Only writable
	B000H、B001H	Only Readable

**Explanation for Read and Write Address of Function Code Parameters:**

High-order parameter address is composed of groups and levels by the function code parameters.

For the service life of EEPROM is limited, the EEPROM cannot be stored frequently in the process of communication. Therefore, some function codes don't need to be stored in EEPROM in the process of communication, but only need to modify the value in RAM.

If it is required to write them into EEPROM, the high-order parameter address adopts the hexadecimal number and low parameter address adopts decimal number that then is converted to the hexadecimal number. And then the high-order and low-order parameter address constitutes a four-digit hexadecimal number.

E.g. The address of writing P2.1.12 to EEPROM is as below:

High-order address is 21 by hexadecimal system and lower-order address is 12 by decimal system, which is 0C after conversion into hexadecimal system, so the address indicates 0x210C.

If it is not required to write it into EEPROM, the high-order parameter address adopts hexadecimal number and adds 4 digits, and low-order parameter address adopts decimal number then is converted to the hexadecimal number. And then the high-order and low-order parameter address constitutes a four-digit hexadecimal number.

E.g. The address of not writing P2.1.12 to EEPROM is as below:

High-order address is 21 by hexadecimal system and then adds 4 digits, that is, 25. The lower-order address is 12 by decimal system, which is 0C after conversion into hexadecimal system, so the address indicates 0x250C.

Table of Definitions for Non-functional Function Code Parameter Address

Definition	Function Code	Parameter Address	Description for Function	
Command to Frequency inverter	06H	A000H	0001H	Forward Run
			0002H	Reverse Run
			0003H	Forward Jogging
			0004H	Reverse Jogging
			0005H	Free Stop
			0006H	Shutdown By Speed Reduction
			0007H	Fault Rest
		A001H	Frequency Command or Upper Frequency Source (refer to the percentage of the highest frequency without storage) (00.00~100.00 indicates 00.00%~100.00%)	
		A002H	BIT0	Multi-functional Output Terminal YO1 (valid only when E180 adds I/O expansion card, E100 is invalid)
			BIT1	Multi-functional Output Terminal YO2 (valid only when E180 adds I/O expansion card, E100 is invalid)
			BIT2	Multi-functional Output Terminal T1
			BIT3	Multi-functional Output Terminal T2
			BIT4	Multi-functional Output Terminal YO((when Terminal YO/FMP is used as YO, that is, P2.1.20=1)
		If it is required to make multi-functional output terminal valid, set corresponding position to 1, after transfer binary system to hexadecimal system, send it to address A002.		
		A003H	FM1 Output Address (00.0~100.0 indicates 00.0%~100.0%)	
		A004H	FM2 Output Address (00.0~100.0 indicates 00.0%~100.0%)	
		A005H	FMP Output Address (when Terminal YO/FMP is used as FMP, that is, P2.1.20=0) (0000H~7FFFH indicates 0.00%~100.00%)	
A010H	PID Reference Value			
A011H	PID Feedback Value			
Running status of monitoring frequency inverter	03H	B000H	0001H	Forward Run
			0002H	Reverse Run
			0003	HStop

**Table of Definitions for Non-functional Function Code Parameter Address**

Definition	Function Code	Parameter Address	Description for Function	
Monitoring to Fault of Frequency inverter	03H	B001H	00	No fault
			01	Over-current at constant speed
			02	Over-current at acceleration
			03	Over-current at deceleration
			04	Over-voltage at constant speed
			05	Over-voltage at acceleration
			06	Over-voltage at deceleration
			07	Module Fault
			08	Undervoltage
			09	Frequency inverter Overload
			10	Motor Overload
			11	Input Default Phase
			12	Output Default Phase
			13	External Fault
			14	Abnormal Communication
			15	Frequency inverter Overheat
			16	Hardware Fault of Frequency inverter
			17	Motor Earthing Short Circuit Motor
			18	Motor Identification Error
			19	Motor Off-load
			20	PID Feedback Loss
			21	User-Defined Fault 1
			22	User-Defined Fault 2
			23	Accumulative Power-on Time Arrival
			24	Accumulative Running Time Arrival
			25	Encoder Fault
			26	Parameter Read-Write Abnormity
			27	Motor Overheat
			28	Larger Speed Deviation
			29	Motor Overspeed
			30	Initial Position Error
			31	Current Detection Fault
			32	Contactors
			33	Abnormity of Current Detection
			34	Fast Current-limiting Timeout
			35	Motor Switch at Running
			36	24V Power Fault
			40	Buffer Resistance Fault

5Example

E.g. 1. Forward Start No.1 Frequency inverter

The host machine sends data package

ADR	01H
CMD	06H
ADDRESS	A0H
	00H
DATA	00H
	01H
CRC	6AH
	0AH

The slave machine responds the data package

ADR	01H
CMD	06H
ADDRESS	A0H
	00H
DATA	00H
	01H
CRC	6AH
	0AH

E.g. 2. Reference No.1 Frequency inverter Frequency (Not store)

The frequency value of Reference 1# Frequency inverter is the highest frequency 100.00%.

Methods are as below: after removal of the decimal point of 100.00, it is 10000D=2710H.

The host machine sends data package

ADR	01H
CMD	06H
ADDRESS	A0H
	01H
DATA	27H
	10H
CRC	E0H
	36H

Respond the data package

ADR	01H
CMD	06H
ADDRESS	A0H
	01H
DATA	27H
	10H
CRC	E0H
	36H

E.g. 3. Inquire the running frequency of No.1 Frequency inverter Frequency

In running state, inquire the “Output Frequency” of the Frequency inverter 1#

Methods are as below: the Function Code Parameter No. of the output frequency is P9.0.00, after conversion into address, it is 9000H.

If the “Output Frequency” of the Frequency inverter 1# is 50.00Hz, it is 5000D=1388H

The host machine sends data package

ADR	01H
CMD	03H
ADDRESS	90H
	00H
DATA	00H
	01H
CRC	A9H
	0AH

The slave machine responds the data package

ADR	01H
CMD	03H
ADDRESS	02H
DATA	13H
	88H
CRC	B5H
	12H

## Chapter 9 Fault Handling

### 9.1 Frequency inverter Fault and Exclusion Measure

Fault display	Description	Details	Fault elimination
Err00	No Fault		
Err01	Over-current at constant speed	The output current exceeds the over-current value while the frequency inverter is running at a constant speed	<ul style="list-style-type: none"> <li>● Check whether the output circuit of the frequency inverter has short circuit;</li> <li>● Check whether the input voltage is relatively low;</li> <li>● Check whether the load has mutation;</li> <li>● Conduct parameter identification or improve low frequency torque compensation;</li> <li>● Check whether the rated power of the motor or frequency inverter is large enough;</li> </ul>
Err02	Over-current at acceleration	When the frequency inverter accelerates, output current exceeds overcurrent (2.2 times of rated current of the frequency inverter)	<ul style="list-style-type: none"> <li>● Check whether the motor is and its lines are short circuit, grounded or too long;</li> <li>● Check whether the input voltage is relatively low;</li> <li>● Delay the acceleration time</li> <li>● Conduct parameter identification or improve low frequency torque compensation or adjust V/F Curve;</li> <li>● Check whether the load has mutation;</li> <li>● Check whether it is to select speed tracking or start after the motor stops stably;</li> <li>● Check whether the rated power of the motor or frequency inverter is large enough;</li> </ul>
Err03	Over-current at deceleration	When the frequency inverter decelerates, output current exceeds overcurrent (2.2 times of rated current of the frequency inverter)	<ul style="list-style-type: none"> <li>● Check whether the motor is and its lines are short circuit, grounded or too long;</li> <li>● Conduct parameter identification</li> <li>● Delay the deceleration time;</li> <li>● Check whether the input voltage is relatively low;</li> <li>● Check whether the load has mutation;</li> <li>● Install additional brake unit and brake resistance;</li> </ul>
Err04	Over-voltage at constant speed	When the frequency inverter runs at constant speed, DC voltage of the main circuit exceeds this set value. Detected DC overvoltage value: Level T2 : 400V Level T4: 750V Level T6: 1300V	<ul style="list-style-type: none"> <li>● Check whether the input voltage is too high;</li> <li>● Check whether the bus voltage display is normal;</li> </ul> <p>Check whether the motor is dragged to run by external force in the running process;</p>

Fault display	Description	Details	Fault elimination
Err05	Over-voltage at acceleration	When the frequency inverter runs at constant speed, DC voltage of the main circuit exceeds this set value. The detected overvoltage value is the same as above.	<ul style="list-style-type: none"> <li>● Check whether the input voltage is too high;</li> <li>● Check whether the bus voltage display is normal;</li> <li>● Delay the deceleration time;</li> <li>● Check whether the motor is dragged to run by external force in the process of deceleration;</li> <li>● Install additional brake unit and brake resistance;</li> </ul>
Err06	Over-voltage at deceleration	When the frequency inverter runs at constant speed, DC voltage of the main circuit exceeds this set value. The detected overvoltage value is the same as above.	<ul style="list-style-type: none"> <li>● Check whether the input voltage is too high;</li> <li>● Check whether the bus voltage display is normal;</li> <li>● Delay the deceleration time;</li> <li>● Check whether the motor is dragged to run by external force in the process of deceleration;</li> <li>● Install additional brake unit and brake resistance;</li> </ul>
Err07	Module fault	External fault has triggered automatic module protection	<ul style="list-style-type: none"> <li>● Check the coil resistance of the motor;</li> <li>● Check the isolation of the motor;</li> <li>● Damage by inverse module breakdown;</li> </ul>
		<p>Under-voltage in the main circuit, check the electric level:</p> <p>Detected DC undervoltage value:</p> <p>Level T2 : 190V</p> <p>Level T4: 380V</p> <p>Level T6: 700V</p>	<ul style="list-style-type: none"> <li>● Check the lines of supply power contact well;</li> <li>● Check whether the incoming voltage is within regulated scope;</li> <li>● Check whether there is momentary interruption;</li> <li>● Check whether the display of the bus voltage is normal;</li> <li>● Check whether the setting bridge and charge resistance are normal;</li> </ul>
Err08	Frequency inverter voltage overloaded	Motor and current exceed the rated load	<ul style="list-style-type: none"> <li>● Check whether the motor is in locked-rotor conditions or the load to motor needs to be reduced;</li> <li>● Replace the frequency inverter with larger power;</li> </ul>
Err10	Motor overload	Motor and current exceed the rated current	<ul style="list-style-type: none"> <li>● Check the protection parameter P1.0.25 Reference of the motor is proper;</li> <li>● Check whether the motor is in locked-rotor conditions or the load to motor needs to be reduced;</li> <li>● Correctly preset the rated current of the motor;</li> <li>● Replace the frequency inverter with larger power;</li> </ul>
Err11	Missing phase	Error of missing phase or unbalanced three phases	<ul style="list-style-type: none"> <li>● Check main circuit voltage whether it is missing phase or unbalanced three phases</li> <li>● Check whether the connecting terminal is loosening.</li> <li>● Seek technical support</li> </ul>

Fault display	Description	Details	Fault elimination
Err21	User-Defined Fault 1	Fault 1 Signal given by the users through multi-functional terminals or PLC Programming Function	<ul style="list-style-type: none"> <li>● Check whether the User-Defined Fault 1 is removed and then run after reset;</li> </ul>
Err22	User-Defined Fault 2	Fault 2 Signal given by the users through multi-functional terminals or PLC Programming Function	<ul style="list-style-type: none"> <li>● Check whether the User-Defined Fault 2 is removed and then run after reset;</li> </ul>
Err23	Accumulative Power-on Time Arrival	Refer to the time given by accumulative power-on time arrival P5.1.01 of the frequency inverter	<ul style="list-style-type: none"> <li>● Use the parameter initialization function to clear the record information</li> </ul>
Err24	Accumulative Running Time Arrival	Refer to the time given by accumulative power-on time arrival P5.1.00 of the frequency inverter	<ul style="list-style-type: none"> <li>● Use the parameter initialization function to clear the record information</li> </ul>
Err25	Encoder Fault	The frequency inverter is unable to identify the data of the encoder	<ul style="list-style-type: none"> <li>● Check whether the type of the encoder matches</li> <li>● Check whether the wiring connection of the encoder is correct</li> <li>● Check whether the encoder or PG card is damaged;</li> </ul>
Err26	Parameter Read-Write Abnormity	Damage of EEPROM Chip	<ul style="list-style-type: none"> <li>● Change main control panel</li> </ul>
Err27	Motor Overheat	Detection on excessive temperature of the motor	<ul style="list-style-type: none"> <li>● Check whether the temperature of the motor is too high;</li> <li>● Check whether the temperature sensor is damaged or its wirings are loose;</li> </ul>
Err28	Larger Speed Deviation	Refer to the value of speed deviation larger than P6.1. 23 and duration of P6.1.24	<ul style="list-style-type: none"> <li>● Check whether the parameters of the encoder is set correctly;</li> <li>● Check whether P6.123 and P6.124 are set rationally;</li> <li>● Check whether the motor parameter identification has been conducted;</li> </ul>
Err29	Motor Overspeed	Refer to the value of motor speed over P6.1. 21 and duration of P6.1.22 Check whether the parameters of the encoder is set correctly;	<ul style="list-style-type: none"> <li>● Check whether P6.121 and P6.122 are set rationally;</li> <li>● Check whether the motor parameter identification has been conducted;</li> </ul>
Err30	Initial Position Error	Large deviation between motor parameters and actual parameters	<ul style="list-style-type: none"> <li>● Check whether the motor parameters are correct, especially for rated current of the motor;</li> </ul>



Fault display	Description	Details	Fault elimination
Err31	Current Detection Fault	Circuit fault after current detection	<ul style="list-style-type: none"> <li>● Check whether the Hall device has defaults;</li> <li>● Check whether the circuit has fault after detection of the driver board</li> <li>● Check whether the driver board has fault</li> </ul>
Err32	Contactor	Abnormal power supply of driver board caused by the fault of the contactor	<ul style="list-style-type: none"> <li>● Check whether the contactor is normal;</li> <li>● Check whether the power supply of the driver board is normal;</li> </ul>
Err33	Abnormity of Current Detection	Circuit fault after current detection leads to abnormal current detection value	<ul style="list-style-type: none"> <li>● Check whether the Hall device has defaults;</li> <li>● Check whether the circuit has fault after detection of the driver board</li> <li>● Check whether the driver board has fault</li> </ul>
Err34	Fast Current-limiting Timeout	The running current of the frequency inverter continues to be larger, which exceeds allowable current limit time	<ul style="list-style-type: none"> <li>● Check whether the load is too large or is stalled;</li> <li>● Check whether the size of the frequency inverter is too small;</li> </ul>
Err35	Motor Switch at Running	Conduct motor switch in the running process of the frequency inverter	<ul style="list-style-type: none"> <li>● Conduct the switch operation of the motor after shutdown of the frequency inverter</li> </ul>
Err36	Power Fault	External 24V power supply is short circuit or the load of External 24V power supply is too large	<ul style="list-style-type: none"> <li>● Check whether external 24V power supply is short circuit</li> <li>● Reduce the load of external 24V power supply</li> </ul>
Err40	Buffer Resistance	The bus voltage fluctuates strongly	<ul style="list-style-type: none"> <li>● Check whether the contactor is normal</li> <li>● Check the fluctuations of incoming voltage</li> </ul>

## 9.2 Motor Fault and Exclusion Measure

If any of the faults below occurs to your motor, find out the causes and take corresponding corrective measures. If the fault persists, please contact your DELIXI distributor immediately.

Motor Fault and Its Elimination:

Fault	Tips for checking	Corrective measures
The motor does not rotate.	Has the power voltage been delivered to the terminals R, S and T?	Switch on the power supply; switch it off and on again; check power voltage; make sure the terminal bolts have been tightened
	Measure the voltages of terminals U, V and W with a rectifier-type voltmeter. Are they right?	Cut off power supply and switch it on again
	Has the motor been locked due to overload?	Reduce load and lift the lock
	Is there any fault information displayed on the monitor of the operator?	Check the fault according to the table of faults
	Has the instruction for forward or reverse rotation been fed in?	Check the wiring
	Has the frequency-setting signal been fed in?	Change the wiring, check the frequency-setting voltage
	Has the running mode been set up correctly?	Put in the correct setup
The motor rotates in opposite direction	Is the wiring of terminals U, V and W correct?	Wire them to the lead wires U, V and W of the motor in accordance with the phase sequence
	Is the input signal connection right for the forward/backward rotation?	Change the wiring
The motor rotates, but is incapable of speed changing.	Is the wiring of the frequency reference circuit correct?	Change the wiring
	Has the operation mode been correctly set up?	Check the selected running mode with an operator
	Is the load too much?	Reduce load
The rotation speed (rpm/min) of the motor is too high or too low.	Are the rated values (number of poles, voltage) right?	Check the technical data on the nameplate of the motor
	Is the acceleration/deceleration gear shifting ratio of the gear wheel right?	Checking the shifting gears (like the gear wheel and so on)
	Has the maximum output frequency been correctly set up?	Check the set value of the maximum output frequency
	Check the voltage between the terminals of the motor with a rectifier-type voltmeter. Is there too much voltage drop?	Check the V/F characteristic value
The rotation speed of the running motor is unsteady	Is the load too much?	Reduce load
	Is the change of load too much?	Reduce load change, increase the motor capacity of the frequency inverter
	What about the power supply. Is it a 3-phase or a single-phase one? If it is a 3-phase one, is there any phase loss?	Check the wiring of the 3-phase power supply for possible phase loss.

## Appendix 1 Regular Maintenance and Inspection Methods

Inspection location	Items for inspection	Description	Period			Inspection method	Criteria	Measuring instrument
			Daily	Yearly	Biennial			
Exterior	Surroundings	Is there any dust? Are the ambient temperature and humidity appropriate?	√			See the precautions	Temperature: -10~+40°C; no dust; humidity: below 90% and no dew formation	Thermometer, hygrometer and a recorder
	Equipment	Is there any abnormal vibration or noise?	√			Look, see	No abnormality	
	Input voltage	Is the input voltage of the main circuit normal?	√			Measure the voltage between the terminals R, S and T		Digital AVO meter/ tester
	The entire operating site	Megger examination (of the resistance between the main circuit and earth) for any loosened parts. Overheat on any parts? Clean?		√		Disconnect the frequency inverter, Short-circuit the terminals R, S, T, U, V, W and measure the resistance between them and the earth. Tighten the bolts. Check with naked eyes	Over 5 MΩ and fault free	DC 500V-type megger
	Conductor wiring	Conductor rusty? Wire sheath damaged?		√		Check with naked eyes	No fault	
	Terminals	Any damage?		√		Check with naked eyes	No Fault	
	IGBT module / diode	Check the impedance between terminals			√	Disconnect the frequency inverter, and measure with a tester the resistance between the group of R, S, T <-> +, - and the group of U, V, W <-> +, - respectively		Digital AVO meter / analog measuring meter
	Insulation resistance	Megohmmeter inspection (between output terminal and grounding terminal)			√	Release connection of U, V and W and fasten motor wire	Exceed 5MΩ	500V type megohm meter

Appendix 2 Guideline for Option of Optional parts

Inspecti on location	Items for inspection	Description	Period			Inspection method	Criteria	Measuring instrument
			Daily	Yearly	Biennial			
Main Circuit	Filter capacitor	Is there any liquid seepage? Is the safety hole bulging out? Is the capacitor bulging out?	✓	✓		Check with naked eyes Measure with capacitance meters	No fault exceeds 85% of the rated capacity	Devices for measuring capacitance
	Relay	Any wobbling noise during operation? Any damage to the contacts?		✓		Listen Check with naked eyes.	No fault	
	Resistance	Whether resistance insulation is damaged Whether resistor wire is damaged (open circuit)		✓		Visual inspection Disconnect one and measure it with test instrument.	There is no fault Error must be within $\pm 10\%$ of resistance value	Digital multimeter/simulation test instrument
Protecti on circuit and control circuit	Operation check	Is the output voltage balanced for all the phases? After executing sequential protection, there should be no fault in the display circuit		✓		Measure the voltage among terminals U, V and W Short circuit and open frequency inverter protection circuit output	For 200V (400) model, the difference in the voltage of each phase should not exceed 4V (8V)	Digital AVO meter/calibrating voltmeter
Cooling system	Cooling fan	Any abnormal vibration or noise? Any loosened connections?	✓	✓		Turn the tightening connection of the fan after switching off the power supply	Rotation smooth and no fault	
Display	Meter	Is the displayed value correct?	✓	✓		Check the reading of the meter outside the panel	Check the set values	Voltmeter/ammeter
Motor	The entire operating site	Any abnormal vibration or noise? Any abnormal smells?	✓			Check with your ears, nose, and eyes; Check for overheat or damage	No fault	

Note: the values in brackets apply to 400V-type frequency inverters.

## Appendix 2 Guideline for Option of Optional parts

Users of this series product can choose to install additional peripherals in accordance with the operating conditions and needs.

### A2.1 Alternative Current Reactor (ACL)

Alternative current reactor can be used to suppress the high-order harmonic of the input current from the frequency inverter, thus improve its power factors. It is recommended for the following situations:

- 1 The ratio of the capacity of the power source to that of the frequency inverter exceeds 10:1.
- 2 Silicon controlled load or power factor compensation devices with switch control is wired to the same power supply.
- 3 The 3-phase power has a high degree of voltage unbalance. ( $\approx 3\%$ )

**Table of Matching Alternating Current Reactors:**

S2/T2 Series					
Power (kW)	Current (A)	Inductance (mH)	Power (kW)	Current (A)	Inductance (mH)
0.4	2.0	4.6	2.2	10	1.0
0.75	4.0	2.4	3.7	16	0.6
1.5	7.0	1.6			

T4 Series					
Power (kW)	Current (A)	Inductance (mH)	Power (kW)	Current (A)	Inductance (mH)
0.75	2.3	7.6	18.5	37	0.5
1.5	3.7	4.8	22	45	0.42
2.2	5.0	3.2	30	60	0.32
3.7	8.8	2.0	37	75	0.26
5.5	13	1.5	45	90	0.21
7.5	17	1.2	55	110	0.18
11	25	0.8	75	152	0.13
15	32	0.6			

### A2.2 DC reactor

When the capacity of the power grid far exceeds that of the frequency inverter or when the power capacity is beyond 1000KVA, or when the user expects greatly improved power factor of the power supply, direct current reactors will be necessary. Direct current reactors can be used simultaneously with alternating current reactors, which is effective in reducing higher-order harmonic input.

CDI-E100 Series is DC-free electric reactor. In CDI-E180 Series Frequency inverter, the types with power 1kW above can be configured with DC reactor.

**Table of Matching Direct Current Reactors:**

T4 Series					
Power KW	Current A	Inductance $\mu$ H	Power KW	Current A	Inductance $\mu$ H
11~15	40	1500	37~55	150	300
18.5~30	75	600	75~90	220	200

### A2.3 Radio noise filter

Radio noise filters are used to restrain the transmission of electromagnetic interfering noises generated by the frequency inverter. They can also be used to restrain interference with the motor from external radio, instantaneous impact and surges.

Table of matching 3-phase 3-wire Radio Noise Filters:

Voltage V	Motor power (kW)	Voltage V	Motor power (kW)	Filter model	Key filter parameters					
					Common-mode input loss dB			Derivation-mode input loss dB		
					0.1 MHz	1 MHz	30 MHz	0.1 MHz	1 MHz	30 MHz
220	0.4~0.75	380	0.75~1.5	DL-5EBT1	75	85	55	55	80	60
	1.5~2.2		2.2~3.7	DL-10EBT1	70	85	55	45	80	60
	3.7		5.5~7.5	DL-20EBT1	70	85	55	45	80	60
			11~15	DL-35EBT1	70	85	50	40	80	60
			18.5~22	DL-50EBT1	65	85	50	40	80	50
			30~37	DL-80EBT1	50	75	45	60	80	50
			45	DL-100EBK1	50	70	50	60	80	50
			55~75	DL-150EBK1	50	70	50	60	70	50

In situations requiring stronger anti-radio interference capability or conformity to CE, UL, or CSA standards, or when there are devices with poor anti-interference capabilities in the vicinity, filters should be installed. While installing, make sure the wiring is as short as possible, that is, the filter should be as close to the frequency inverter as possible.

### A2.4 Remote Operation Keyboard

Our series frequency inverters have all been equipped with operation keyboards, exquisitely designed and easily operated. If you wish to use it away from the frequency inverter or other places, an extended cable would serve the purpose. You just need to demand it when you place an order. Since the serial communication mode is employed to link the keyboard and the frame, you can remove the keyboard to work area as far as 10 meters away. Or if you want to or need to work farther away, then you can buy a remote operation keyboard from the suppliers concerned, or from our company.

### A2.5 Energy Consumption Brake Unit and Brake Resistance

CDI-E100 Series frequency inverter is configured with built-in brake unit, if the brake torque is required to be added, it is to directly connect the brake resistance. CDI-E180 Series Frequency inverter with power 15kW and below is configured with built-in brake unit, if the brake torque is required to be added, it is only required to externally connect brake resistance. The types with power 15kW and above is not configured with built-in brake unit, if the brake torque is required to be added, it is required to externally connect brake unit and brake resistance.

**The formula for simple calculation for brake unit and brake resistance is as below:**

Generally, the brake current is  $1/2 I$  of the rated current of the motor, the generated brake torque is approximately equal to the rate torque of the motor. Therefore, proper brake current  $I_B$  shall be selected based on requirements of load inertia and shutdown time. The greater the load inertia is, the shorter the shutdown time requires and the greater the selected brake current  $I_B$  is.

$$I_B = (1/2 \sim 3/2) * I$$

According to brake current, the value of resistance to brake unit and brake resistance can be selected.

The peak current of the brake unit (only aim at brake unit of Delixi) is larger than  $I_B$ .

Size of Brake Resistance Value

$$R_B = U / I_B \text{ (in S2 and T2 Series, U takes 400V; in T4 Series, U takes 700V)}$$

Size of Brake Resistance Power

$$P_B = K * U * U / R_B$$

In formula, K indicates braking coefficient with range of 0.1~0.5, and the braking coefficient shall be selected based on requirements of load inertia and shutdown time. The greater the load inertia is, the shorter the shutdown time requires and the greater the selected braking coefficient K is. General load can select 0.1~0.2 and the large load inertia selects 0.5.

The following sizing table is available when  $I_D$  is approximately equal to  $1/2I$  and K is between 0.1~0.2. The greater the load inertia is, the shorter the shutdown time requires, and proper adjustment shall be made according to the formula above.

## 1. CDI-E100 Series

Type of Frequency inverter	Type of Brake Unit	Brake Resistance Value( $\Omega$ )	Brake Resistance Power(W)
S2 (Single Phase 220V)			
CDI-E100G0R4S2B	Built-in, allowable Max. Current 8A	400	80
CDI-E100G0R7S2B	Built-in, allowable Max. Current 8A	200	160
CDI-E100G1R5S2B	Built-in, allowable Max. Current 15A	120	250
CDI-E100G2R2S2B	Built-in, allowable Max. Current 15A	80	400
T2 (Three Phase 220V)			
CDI-E100G0R4T2B	Built-in, allowable Max. Current 8A	400	80
CDI-E100G0R7T2B	Built-in, allowable Max. Current 8A	200	160
CDI-E100G1R5T2B	Built-in, allowable Max. Current 15A	120	250
CDIE100G2R2T2B	Built-in, allowable Max. Current 25A	80	400
T4 (Three Phase 220V)			
CDI-E100G0R75T4B	Built-in, allowable Max. Current 8A	600	160
CDI-E100G1R5T4B	Built-in, allowable Max. Current 8A	400	250
CDI-E100G2R2T4B	Built-in, allowable Max. Current 15A	250	400
CDI-E100G3R7T4B	Built-in, allowable Max. Current 15A	150	600

Appendix 2 Guideline for Option of Optional parts

2.CDI-E180 Series

Type of Frequency inverter	Type of Brake Unit	Brake Resistance Value( $\Omega$ )	Brake Resistance Power(W)
CDI-E180G0R75T4B	Built-in, allowable Max. Current 10A	600	160
CDI-E180G1R5T4B	Built-in, allowable Max. Current 10A	400	250
CDI-E180G2R2T4B	Built-in, allowable Max. Current 15A	250	400
CDI-E180G3R7/P5R5T4B	Built-in, allowable Max. Current 25A	150	600
CDI-E180G5R5MT4B	Built-in, allowable Max. Current 40A	100	1000
CDI-E180G5R5/P7R5T4B	Built-in, allowable Max. Current 40A	100	1000
CDI-E180G7R5/P011T4B	Built-in, allowable Max. Current 15A	80	1200
CDI-E180G011MT4B	Built-in, allowable Max. Current 50A	50	2000
CDI-E180G011/P015T4BL	Built-in, allowable Max. Current 50A	50	2000
CDI-E180G015/P018.5T4BL	Built-in, allowable Max. Current 75A	40	2500
CDI-E180G018.5/P022T4	CDI-BR-50	35	2800
CDI-E180G022/P030T4	CDI-BR-50	30	3200
CDI-E180G030/P037T4	CDI-BR-100	20	5000
CDI-E180G037/P045T4	CDI-BR-100	16	6000
CDI-E180G045/P055T4	CDI-BR-200	15	6500
CDI-E180G055/P075T4	CDI-BR-200	10	10000
CDI-E180G075/P093T4	CDI-BR-200	8	12000



## Appendix 3 Multi-function I/O Expansion Card

### 1.Introduction


Expansion Card E180-I/O is developed by Delixi (Hangzhou) Inverter Co., Ltd and is applied for CDI-E180 Series Terminal I/O. Its specific configuration is as below:

Configuration	Function name
Input Terminal	4-way Digital Input (DI7~DI10)
	1-way Analog Input (VF3)
Output Terminal	2-way Multi-functional Open Collector Output (YO1、YO2)
Communication	RS-485 Communication Interface (SG+,SG-)

### 2.Mechanical Installation

The frequency inverter shall be installed when it switched off completely.

Align I/O expansion card with expansion card interface and positioning hole on the control panel of the frequency inverter and then fix them with screws.



Installation Mode of I/O Expansion Card



Appearance of I/O Expansion Card

### 3.Description for Control Terminal

Category	Terminal	Name of Terminal	Explanation for Function
Digital Input Terminal	DI7-COM	Digital Input 7	Specific functions refer to explanation for use of Function Code P2.0.06~P2.0.09
	DI8-COM	Digital Input 8	
	DI9-COM	Digital Input 9	
	DI10-COM	Digital Input 10	
Multi-functional Output Terminal	YO1	Multi-functional Open Collector Output 1	Specific functions refer to explanation for use of Function Code P2.0.08~P2.0.31 Drive Capability: DC48V 50mA below
	CME		
	YO2	Multi-functional Open Collector Output 2	
	CME		
Analog Input Terminal	VF3-GND	Analog Input Terminal 3	Be used for receiving external analog signal input, which is voltage signal 0V~10V or current signal 0/4mA~20mA
24V Power Supply	COM	24V Power Supply Output	Externally provide DC 24V Supply Voltage, which is generally used for digital input terminal or working power supply of external low-voltage devices. Drive Capability: Max. Output Current 300mA
	P24		
Communication Terminal	SG+	Positive Signal Terminal of RS485 Communication	
	SG-	Negative Signal Terminal of RS485 Communication	

**Note: if Terminal VF3 is adopted, it is to short J9 on I/O expansion card. At this moment, the function of keyboard potentiometer will be replaced by the function of Terminal Vf3.**

## Appendix 4 Expansion Card of Encoder

### 1.Introduction


CDI-E180 Series can realize Closed-loop Vector Control against different load motor, which is required to different encoder. Accordingly, there are many various expansion cards of the encoder with specific types as below:

Type	Name	Description
E180-PG1	Differential input of PG card without frequency dividing output	Max.Speed:100kHz Differential Input Signal Amplitude: =7V
E180-PG2	UVW differential input of PG card without frequency dividing output	Max.Speed:100kHz Differential Input Signal Amplitude: =7V
E180-PG3	Open collector input of PG Card	Max.Speed:100kHz

### 2.Mechanical Installation

The frequency inverter shall be installed when it switched off completely.

Align I/O expansion card with expansion card interface and positioning hole on the control panel of the frequency inverter and then fix them with screws.



Appearance of E180-PG1



Appearance of E180-PG2



Appearance of E180-PG3

### 3.Description for Control Terminal

Definition for E180-PG1 Wiring Terminal Signal

Name of Terminal	Description
A+	Positive Encoder A Signal
A-	Negative Encoder A Signal
B+	Positive Encoder B Signal
B-	Negative Encoder B Signal
Z+	Positive Encoder Z Signal
Z-	Negative Encoder Z Signal
5V	Externally provide Power 5V and Max. output current is 100mA
COM	Power Ground

Definition for E180-PG2 Wiring Terminal Signal

Name of Terminal	Description
A+	Positive Encoder A Signal
A-	Negative Encoder A Signal
B+	Positive Encoder B Signal
B-	Negative Encoder B Signal
Z+	Positive Encoder Z Signal
Z-	Negative Encoder Z Signal
U+	Positive Encoder U Signal
U-	Negative Encoder U Signal
V+	Positive Encoder V Signal
V-	Negative Encoder V Signal
W+	Positive Encoder W Signal
W-	Negative Encoder W Signal
5V	Externally provide Power 5V and Max. output current is 100mA
COM	Power Ground

Definition for E180-PG3 Wiring Terminal Signal

Name of Terminal	Description
A	Encoder A signal
B	Encoder B signal
Z	Encoder Z signal
24V	Externally provide Power 24V and Max. output current is 100mA
COM	Power Ground

## Appendix 5 Expansion Card of RS485 Communication

### 1.Introduction



For CDI-E180 Series and E102 are not configured with communication function,if communication required, the expansion card for communication needs to be added. Specific types are as below:

Type	Name	Description
E180-485	Expansion Card for E180 Communication	SG+:Positive Signal Terminal of RS485 Communication SG-:Negative Signal Terminal of RS485 Communication Support MODBUS-RTU Protocol
E102-485	Expansion Card for E102 Communication	SG+:Positive Signal Terminal of RS485 Communication SG-:Negative Signal Terminal of Rs485 Communication Support MODBUS-RTU Protocol

### 2Mechanical Installation

The frequency inverter shall be installed when it switched off completely.

Align RS485 Communication with expansion card interface and positioning hole on the control panel of the frequency inverter and then fix them with screws.



Appearance of E180-485



Appearance of E102-485

## Appendix 6 Expansion Card of Injection Molding Machine

### 1 Introduction


E180-I/O Expansion Card is developed by Delixi (Hangzhou) Inverter Co., Ltd and applied for CDI-E180 Series Terminal I/O, its specific configuration is as below:

Configuration	Description
2-way Digital Input Terminal (DI7~DI8)	Refer to Description for use of specific functions of Function Code P2.0.06~P2.0.07
2-way Analog Input Terminal (G1-S1 ,G2-S2)	G1:Connect proportional flow signal negative S1:Connect proportional flow signal positive G2:Connect proportional voltage signal negative S2:Connect proportional voltage signal positive <b>Note:proportional flow and proportional voltage signal are DC Current Signal 0~1A, and corrective wiring shall be made according to the flow of circuit current</b>

### 2.Mechanical Installation

The frequency inverter shall be installed when it switched off completely.

Align Expansion Card E180-ZS with expansion card interface and positioning hole on the control panel of the frequency inverter and then fix them with screws.



Appearance of E180-ZS